

GROUP 13C

MULTIPOINT FUEL INJECTION (MPI) <Vehicles for Australia and New Zealand>

CONTENTS

GENERAL INFORMATION	13C-3	ON-VEHICLE SERVICE	13C-335
SERVICE SPECIFICATIONS	13C-7	THROTTLE BODY (THROTTLE VALVE AREA) CLEANING	13C-335
SEALANT	13C-7	FUEL PRESSURE TEST	13C-335
SPECIAL TOOLS	13C-8	FUEL PUMP RELAY DISCONNECTION (HOW TO REDUCE PRESSURIZED FUEL LINES)	13C-337
TROUBLESHOOTING	13C-11	FUEL PUMP OPERATION CHECK	13C-337
DIAGNOSIS TROUBLESHOOTING FLOW	13C-11	COMPONENT LOCATION	13C-339
DIAGNOSIS FUNCTION	13C-11	ENGINE CONTROL RELAY CONTINUITY CHECK	13C-340
INSPECTION CHART FOR DIAGNOSIS CODE	13C-21	FUEL PUMP RELAY CONTINUITY CHECK	13C-340
INSPECTION PROCEDURE FOR DIAGNOSIS CODES	13C-24	THROTTLE VALVE CONTROL SERVO RELAY CONTINUITY CHECK	13C-340
INSPECTION CHART FOR TROUBLE SYMPTOMS	13C-242	INTAKE AIR TEMPERATURE SENSOR CHECK	13C-340
SYMPTOM PROCEDURES	13C-246	ENGINE COOLANT TEMPERATURE SENSOR CHECK	13C-341
Data List Reference Table	13C-313	OXYGEN SENSOR CHECK	13C-342
Actuator Test Reference Table	13C-321	INJECTOR CHECK	13C-344
CHECK AT THE ECU TERMINALS	13C-322	THROTTLE VALVE CONTROL SERVO CHECK	13C-345
INSPECTION PROCEDURE USING OSCILLOSCOPE	13C-329	OIL CONTROL VALVE CHECK	13C-345

Continued on next page

INJECTOR	13C-346	ENGINE-A/T-ECU	13C-350
REMOVAL AND INSTALLATION	13C-346	REMOVAL AND INSTALLATION	13C-350
THROTTLE BODY ASSEMBLY	13C-348		
REMOVAL AND INSTALLATION	13C-348		

GENERAL INFORMATION

M1131000102387

The Multipoint Fuel Injection System consists of sensors which detect the engine conditions, the engine-A/T-ECU which controls the system based on signals from these sensors, and actuators which operate under the control of the engine-A/T-ECU.

FUEL INJECTION CONTROL

The injector drive times and injection timing are controlled so that the optimum air/fuel mixture is supplied to the engine to correspond to the continually-changing engine operation conditions. A single injector is mounted at the intake port of each cylinder. Fuel is sent under pressure from the fuel tank by the fuel pump, with the pressure being regulated by the fuel pressure regulator. The fuel thus regulated is distributed to each of the injectors.

Fuel injection is normally carried out once for each cylinder for every two rotations of the crankshaft. The firing order is 1-3-4-2. This is called sequential fuel injection. The engine-A/T-ECU provides a richer air/fuel mixture by carrying out "open-loop" control

THROTTLE VALVE OPENING CONTROL

This system electrically controls the opening of the throttle valve. The engine-A/T-ECU detects the amount of travel of the accelerator pedal via the accelerator pedal position sensor, and controls the

IDLE AIR CONTROL

The idle speed is kept at the optimum speed by controlling the amount of air that passes through the throttle valve in accordance with changes in idling conditions and engine load during idling. The engine-A/T-ECU drives the throttle valve control servo to keep the engine running at the pre-set idle target speed in accordance with the engine coolant

IGNITION TIMING CONTROL

The power transistor located in the ignition primary circuit turns ON and OFF to control the primary current flow to the ignition coil. This controls the ignition timing in order to provide the optimum ignition timing

SELF-DIAGNOSIS FUNCTION

- When an abnormality is detected in one of the sensors or actuators related to emission control, the engine warning lamp (check engine lamp) illuminates as a warning to the driver.
- When an abnormality is detected in one of the sensors or actuators, a diagnosis code corresponding to the abnormality is output.

The engine-A/T-ECU carries out activities such as fuel injection control, idle speed control and ignition timing control. In addition, the engine-A/T-ECU is equipped with several diagnosis modes which simplify troubleshooting when a problem develops.

when the engine is cold or operating under high load conditions in order to maintain engine performance. In addition, when the engine is warm or operating under normal conditions, the engine-A/T-ECU controls the air/fuel mixture by using the oxygen sensor signal to carry out "closed-loop" control in order to obtain the theoretical air/fuel mixture ratio that provides the maximum cleaning performance from the three way catalyst.

actuation of the throttle valve control servo, which is mounted on the throttle body, in order to attain the target throttle valve opening that has been predetermined in accordance with driving conditions.

temperature and A/C and other electrical load. In addition, when the air conditioning switch is turned off and on while the engine is idling, the throttle valve control servo adjusts the throttle valve passes through air amount according to the engine load conditions to avoid fluctuations in the engine speed.

with respect to the engine operating conditions. The ignition timing is determined by the engine-A/T-ECU from the engine speed, intake air volume, engine coolant temperature and atmospheric pressure.

- The RAM data inside the engine-A/T-ECU that is related to the sensors and actuators can be read by means of the M.U.T.-III. In addition, the actuators can be force-driven under certain circumstances.

OTHER CONTROL FUNCTIONS**1. Fuel Pump Control**

Turns the fuel pump relay ON so that current is supplied to the fuel pump while the engine is cranking or running.

2. A/C Relay Control

Turns the compressor clutch of the A/C ON and OFF.

3. Oil Control Valve Control

The engine-A/T-ECU effects duty cycle control on the engine oil control valve, in accordance with the engine speed. This regulates the supply of engine oil to the intake rocker shaft, which switches the cams.

4. Fan Motor Control

The revolutions of the radiator fan and condenser fan are controlled in response to the engine coolant temperature and vehicle speed.

5. Alternator Output Current Control

Prevents alternator output current from increasing suddenly and idle speed from dropping at times such as when the headlamp are turned on.

6. Purge Control Solenoid Valve Control

(Refer to [P.17-40](#), GROUP 17 –Engine And Emission Control –Evaporative Emission Control System).



7. EGR Control Solenoid Valve Control

[Refer to [P.17-43](#), GROUP 17 –Engine And Emission Control –Exhaust Gas Recirculation (EGR) System].

GENERAL SPECIFICATIONS

Items		Specifications
Throttle body	Throttle bore mm	60
	Throttle position sensor	Hall element type
	Throttle valve control servo	DC motor type, having broshes
Engine-A/T-E CU	Identification No.	E6T41890
Sensors	Air flow sensor	Heat sensitizing type
	Barometric pressure Sensor	Semiconductor type
	Intake air temperature sensor	Thermistor type
	Engine coolant temperature sensor	Thermistor type
	Oxygen sensor	Zirconia type
	Accelerator pedal position sensor	Hall element type
	Inhibitor switch	Contact switch type
	Camshaft position sensor	Magneto resistance element type
	Crank angle sensor	Magneto resistance element type
	Detonation sensor	Piezoelectric type
	Power steering fluid pressure sensor	Semiconductor type
Actuators	Engine control relay type	Contact switch type
	Fuel pump relay type	Contact switch type
	Injector type and number	Electromagnetic type, 4
	Injector identification mark	HDA305E
	Throttle actuator control motor relay	Contact switch type
	Oil control valve	Duty cycle type solenoid valve
	EGR valve	Stepper motor
	Purge control solenoid valve	Duty cycle type solenoid valve
Fuel pressure regulator	Regulator pressure kPa	328

MULTI-POINT FUEL INJECTION SYSTEM DIAGRAM



SERVICE SPECIFICATIONS

M1131000301429

Items		Specifications
Intake air temperature sensor resistance kΩ	-20° C	13 – 17
	0° C	5.3 – 6.7
	20° C	2.3 – 3.0
	40° C	1.0 – 1.5
	60° C	0.56 – 0.76
	80° C	0.30 – 0.45
Engine coolant temperature sensor resistance kΩ	-20° C	14 – 17
	0° C	5.1 – 6.5
	20° C	2.1 – 2.7
	40° C	0.9 – 1.3
	60° C	0.48 – 0.68
	80° C	0.26 – 0.36
Oxygen sensor output voltage (at racing) V		0.6 – 1.0
Oxygen sensor heater resistance (at 20° C) Ω	front	4.5 – 8.0
	rear	11 – 18
Fuel pressure kPa	Vacuum hose disconnection	324 – 334 at curb idle
	Vacuum hose connection	Approximately. 248 at curb idle
Injector coil resistance (at 20° C) Ω		10.5 – 13.5
Throttle valve control servo coil resistance (at 20° C) Ω		0.3 – 100
Oil control valve (at 20° C) Ω		6.9 – 7.9









SEALANT







M1131000500981





Item	Specified sealant	Remark
Engine coolant temperature sensor Threaded portion	3M Nut Locking Part No. 4171 or equivalent	Drying sealant

SPECIAL TOOLS

M1131000601561

Tool	Number	Name	Use
<p>A</p>  <p>MB991824</p> <p>B</p>  <p>MB991827</p> <p>C</p>  <p>MB991910</p> <p>D</p>  <p>MB991911</p> <p>E</p>  <p>MB991825</p> <p>F</p>  <p>MB991826</p> <p>MB991955</p>	<p>MB991955</p> <p>A: MB991824</p> <p>B: MB991827</p> <p>C: MB991910</p> <p>D: MB991911</p> <p>E: MB991825</p> <p>F: MB991826</p>	<p>M.U.T.-III sub assembly</p> <p>A: Vehicle communication interface (V.C.I.)</p> <p>B: M.U.T.-III USB cable</p> <p>C: M.U.T.-III main harness A (Vehicles with CAN communication system)</p> <p>D: M.U.T.-III main harness B (Vehicles without CAN communication system)</p> <p>E: M.U.T.-III measurement adapter</p> <p>F: M.U.T.-III trigger harness</p>	<ul style="list-style-type: none"> • Reading diagnosis code • MPI system inspection • Measurement of fuel pressure <p>⚠ CAUTION</p> <p>For vehicles with CAN communication, use M.U.T.-III main harness A to send simulated vehicle speed. If you connect M.U.T.-III main harness B instead, the CAN communication does not function correctly.</p>
	MB991709	Test harness	<ul style="list-style-type: none"> • Measurement of voltage during troubleshooting • Inspection using an oscilloscope
	MB991316	Test harness (4-pin, square)	<ul style="list-style-type: none"> • Measurement of voltage during Troubleshooting • Inspection of oxygen sensor (front)

Tool	Number	Name	Use
	MD998464	Test harness (4-pin, square)	<ul style="list-style-type: none"> • Measurement of voltage during Troubleshooting • Inspection of oxygen sensor (rear)
 MB991658	MB991658	Test harness	<ul style="list-style-type: none"> • Measurement of voltage during Troubleshooting • Inspection using an oscilloscope • Inspection of data list
	MD998709	Adaptor hose	Measurement of fuel pressure
	MD998742	Hose adaptor	
 MB991637	MB991637	Fuel pressure gauge set	
 MB991981	MB991981	Fuel pressure gauge set	

Tool	Number	Name	Use
 MD998706	MD998706	Injector test set	Checking the spray condition of injectors
 MB991607	MB991607	Injector test harness	
 MD998741	MD998741	Injector test adaptor	
 MB991976	MB991976	Injector test holder assembly	

TROUBLESHOOTING

DIAGNOSIS TROUBLESHOOTING FLOW

Refer to [P.00-5](#), GROUP 00 –How to Use Troubleshooting/Inspection Service Points.

DIAGNOSIS FUNCTION


ENGINE WARNING LAMP (CHECK ENGINE LAMP)

M1131155501497

M1131150001561

If an abnormality occurs in any of the following items related to the Multipoint Fuel Injection (MPI) system, the engine warning lamp will illuminate.

If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output.



ENGINE WARNING LAMP INSPECTION ITEMS

Code No.	Diagnosis item
–	Engine-A/T-ECU
P0100	Air flow sensor system
P0105	Barometric pressure sensor system
P0110	Intake air temperature sensor system
P0115	Engine coolant temperature sensor system
P0122*	Throttle position sensor (main) circuit low input
P0123*	Throttle position sensor (main) circuit high input
P0125*	Feedback system monitor
P0130	Cylinder 1, 4 oxygen sensor (front) system
P0135	Cylinder 1, 4 oxygen sensor (front) heater system
P0136	Cylinder 1, 4 oxygen sensor (rear) system
P0141	Cylinder 1, 4 oxygen sensor (rear) heater system
P0150	Cylinder 2, 3 oxygen sensor (front) system
P0155	Cylinder 2, 3 oxygen sensor (front) heater system
P0156	Cylinder 2, 3 oxygen sensor (rear) system
P0161	Cylinder 2, 3 oxygen sensor (rear) heater system
P0170	Abnormal fuel system (cylinder 1,4)
P0173	Abnormal fuel system (cylinder 2,3)
P0201	No.1 injector system
P0202	No.2 injector system
P0203	No.3 injector system
P0204	No.4 injector system

Code No.	Diagnosis item
P0222*	Throttle position sensor (sub) circuit low input
P0223*	Throttle position sensor (sub) circuit high input
P0300*	Random/multiple cylinder misfire detected
P0301*	No.1 cylinder misfire detected
P0302*	No.2 cylinder misfire detected
P0303*	No.3 cylinder misfire detected
P0304*	No.4 cylinder misfire detected
P0325	Detonation sensor system
P0335	Crank angle sensor system
P0340	Camshaft position sensor system
P0403	Exhaust gas recirculation control system
P0421	Warm up catalyst malfunction (cylinder 1,4)
P0431	Warm up catalyst malfunction (cylinder 2,3)
P0443	Purge control solenoid valve system
P0500	Vehicle speed signal system
P0505	Idle speed control (ISC) system
P0513	Immobilizer malfunction
P0551*	Power steering fluid pressure sensor system
P0603	EEP ROM system
P0606*	Engine-A/T-ECU main processor malfunction
P0622	Alternator FR terminal system
P0638*	Throttle valve control servo circuit range/performance problem
P0642*	Throttle position sensor power supply
P0657*	Throttle valve control servo relay circuit malfunction
P0705	Inhibitor switch system
P0710	A/T fluid temperature sensor system
P0715*	Input shaft speed sensor system
P0720*	Output shaft speed sensor system
P0740*	Torque converter clutch solenoid valve system
P0750*	Low-reverse solenoid valve system
P0755*	Underdrive solenoid valve system
P0760*	Second solenoid valve system
P0765*	Overdrive solenoid valve system
P1021	Oil control valve system
P1602*	Communication malfunction (between engine-A/T-ECU main processor and system LSI)
P1603*	Battery backup circuit malfunction
P1751*	A/T control relay system
P2100*	Throttle valve control servo circuit (open)
P2101*	Throttle valve control servo magneto malfunction

Code No.	Diagnosis item
P2102*	Throttle valve control servo circuit (shorted low)
P2103*	Throttle valve control servo circuit (shorted high)
P2122*	Accelerator pedal position sensor (main) circuit low input
P2123*	Accelerator pedal position sensor (main) circuit high input
P2127*	Accelerator pedal position sensor (sub) circuit low input
P2128*	Accelerator pedal position sensor (sub) circuit high input
P2135*	Throttle position sensor (main and sub) range/performance problem
P2138*	Accelerator pedal position sensor (main and sub) range/performance problem
P2173*	Abnormal intake air amount
U1108*	Combination meter time-out

NOTE:

- If the engine warning lamp illuminates because of a malfunction of the engine-A/T-ECU, communication between M.U.T.-III and the engine-A/T-ECU is impossible. In this case, the diagnosis code cannot be read.
 - After the engine-A/T-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a "*" in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.
 - After the engine warning lamp illuminates, it will be switched off under the following conditions.
 - When the engine-A/T-ECU monitored the power train malfunction three times* met set condition requirements, it detected no malfunction.
- *: In this case, "one time" indicates from engine start to stop.
- For misfiring malfunction, when driving conditions (engine speed, engine coolant temperature, etc.) are similar to those when the malfunction was first recorded.
 - Sensor 1 indicates, the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.

**METHOD OF READING AND ERASING
DIAGNOSIS CODES**

Refer to [P.00-5](#), GROUP 00 –How to Use Troubleshooting/Inspection Service Points.

DIAGNOSIS USING DIAGNOSIS 2 MODE

1. Switch the diagnosis mode of the engine control unit to DIAGNOSIS 2 mode using the M.U.T.-III.
2. Carry out a road test.
3. Take a reading of the diagnosis code and repair the problem location.
4. Turn the ignition switch to OFF and then back to ON again.

NOTE: By turning the ignition switch to OFF, the engine-A/T-ECU will switch the diagnosis mode from DIAGNOSIS 2 mode to DIAGNOSIS 1 mode.

5. Erase the diagnosis codes.

**INSPECTION USING M.U.T.-III DATA LIST
AND ACTUATOR TESTING**

1. Carry out inspection by means of the data list and the actuator test function, if there is an abnormality, check and repair the chassis harness and components.
2. After repairing, re-check using the M.U.T.-III and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the M.U.T.-III, and then start the engine again and carry out a road test to confirm that the problem has disappeared.

FREEZE FRAME DATA

When the engine-A/T-ECU detects a malfunction and stores a diagnosis code, it also stores a current status of the engine. This function is called "Freeze frame data". By analyzing this "Freeze frame" data with the M.U.T.-III, an effective troubleshooting can be performed.

The display items of freeze frame data are shown below.

DISPLAY ITEM LIST

Item No.	Data	Unit
12	Air flow sensor	gm/s
13	Intake air temperature sensor	°C
21	Engine coolant temperature sensor	°C
22	Crank angle sensor	r/min
24	Vehicle speed	km/h
44	Ignition advance	deg
81	Long-term fuel compensation (cylinder 1, 4)	%
82	Short-term fuel compensation (cylinder 1, 4)	%
83	Long-term fuel compensation (cylinder 2, 3)	%
84	Short-term fuel compensation (cylinder 2, 3)	%
87	Calculation load value	%
88	Fuel control condition (cylinder 1, 4)	Open loop
		Closed loop
		Open loop owing to drive condition
		Open loop owing to system malfunction
		Closed loop based on one oxygen sensor
89	Fuel control condition (cylinder 2, 3)	Open loop
		Closed loop
		Open loop owing to drive condition
		Open loop owing to system malfunction
		Closed loop based on one oxygen sensor
8A	Throttle position sensor (main)	%
—	Diagnosis code during data recording	-

NOTE: If malfunctions have been detected in multiple systems, store one malfunction only, which has been detected first.

DRIVE CYCLE

The following five drive cycle patterns are performed on the diagnosis codes monitored during the vehicle driving. The vehicle driving requires the patterns to identify the fault. In other words, doing such a drive allows to regenerate any kind of trouble which involves illuminating the engine warming lamp (check engine lamp) and to verify the repair procedure has eliminated the trouble [the engine warming lamp (check engine lamp) is no longer illuminated].

CAUTION

Two technicians should always be in the vehicle when carrying out a test drive.

NOTE: Check that the diagnosis code is not output before traveling in the Drive cycle pattern. Erase the diagnosis code if it has been output.

DRIVE CYCLE PATTERN LIST

Procedure	Monitor item	Diagnosis code
1	Catalytic converter monitor	P0421, P0431
2	Oxygen sensor (front) monitor	P0130, P0150
3	Other monitor	P0135, P0136, P0141, P0155, P0156, P0161, P0201, P0202, P0203, P0204, P0300, P0301, P0302, P0303, P0304, P0325, P0500, P0551, P0638


Procedure 1

Catalytic converter monitor	
Diagnosis code No.	P0421, P0431
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 16 minutes or more.</p> <p style="text-align: right;">AK301815AB</p>
Inspection condition	<ul style="list-style-type: none"> Atmospheric temperature: -10°C or more
Test procedure	<ol style="list-style-type: none"> Engine: start Accelerate until the vehicle speed is 90 km/h or more. Travel for 6 minutes or more while keeping the vehicle speed at 90 km/h or more. Decelerate until the vehicle speed is within 80 km/h or less. While traveling at 55 –80 km/h for 10 minutes or more, fully close the throttle at least once in 2 minutes and decelerate for 10 seconds or more. <ul style="list-style-type: none"> Do not repeat deceleration too often. Vehicle speed may go below 55 km/h after the deceleration. Stopping and braking are permitted. (If stopped or drive at 55 km/h or less for more than 5 minutes the monitoring may be stopped. In this case please restart monitoring from the beginning.) After completing the above deceleration, bring the vehicle speed back to 55 –80 km/h and keep it in the range until starting the deceleration again. <ul style="list-style-type: none"> Repeat the above deceleration at least 5 times. Return the vehicle to the shop, then turn the ignition switch to "LOCK" (OFF) position.

Procedure 2

Oxygen sensor (front) monitor	
Diagnosis code No.	P0130, P0150
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 16 minutes or more.</p> <p align="right">AK301816AB</p>
Inspection conditions	<ul style="list-style-type: none"> • Engine coolant temperature: After engine warm up • Atmospheric temperature: -10° C or more
Test procedure	<ol style="list-style-type: none"> 1. Engine: start 2. Accelerate until the vehicle speed is 55 –80 km/h. 3. While keeping the accelerator pedal opening degree constant, keep the vehicle speed at 55 –80km/h and travel for 16 minutes or more. <ul style="list-style-type: none"> • Stopping and braking during this operation are permitted. 4. Return the vehicle to the shop, then turn the ignition switch to "LOCK" (OFF) position.

Procedure 3

Other monitor	
Diagnosis code No.	P0135, P0136, P0141, P0155, P0156, P0161, P0201, P0202, P0203, P0204, P0300, P0301, P0302, P0303, P0304, P0325, P0500, P0551, P0638
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 21 minutes or more.</p>  <p style="text-align: right;">AK301817AC</p>
Inspection conditions	<ul style="list-style-type: none"> Engine coolant temperature: After engine warm up Atmospheric temperature: -10° C or more
Test procedure	<ol style="list-style-type: none"> 1. Engine: start 2. Accelerate until the vehicle speed is 55 km/h. 3. While keeping the accelerator pedal opening degree constant, keep the vehicle speed at 55 km/h and travel for 16 minutes or more. 4. Return the vehicle to the shop. 5. After stopping the vehicle, continue idling for 5 minutes, and then turn the ignition switch to "LOCK" (OFF) position.

READINESS TEST STATUS

The engine-A/T-ECU monitors the following main diagnosis items, judges if these items are in good condition or not, and stores its history. This history can be read out by using M.U.T.-III. (If the ECU has judged an item before, the M.U.T.-III displays "Complete").

In addition, if diagnosis codes are erased or the battery cable is disconnected, this history will also be erased (the memory will be reset).

- Catalyst: P0421, P0431
- Oxygen sensor: P0130, P0136, P0150, P0156
- Oxygen sensor heater: P0135, P0141, P0155, P0161

FAIL-SAFE FUNCTION REFERENCE TABLE

When the main sensor malfunctions are detected by the diagnosis function, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

Malfunctioning item	Control contents during malfunction
Air flow sensor	Uses the throttle position sensor signal and engine speed signal (crankshaft position sensor signal) for basic injector drive time and basic ignition timing from the pre-set mapping.
Intake air temperature sensor	Controls as if the intake air temperature is 25° C.
Barometric pressure sensor	Controls as if the barometric pressure is 101 kPa.
Throttle position sensor (main)	<ul style="list-style-type: none"> Controls the throttle valve position through the use of the throttle position sensor (sub) signal. Renders the amount of accelerator pedal travel as being approximately one-half the normal opening angle. Prohibits the operation of the engine speed feedback control. Cuts off fuel when the engine speed exceeds 3,000 r/min. Suppresses the engine output by stopping the electronic-controlled throttle valve system if the throttle position sensor (sub) is also malfunctioning.
Throttle position sensor (sub)	<ul style="list-style-type: none"> Controls the throttle valve position through the use of the throttle position sensor (main) signal. Renders the amount of accelerator pedal travel as being approximately one-half the normal opening angle. Cuts off fuel when the engine speed exceeds 3,000 r/min. Suppresses the engine output by stopping the electronic-controlled throttle valve system if the throttle position sensor (main) is also malfunctioning.
Accelerator pedal position sensor (main)	<ul style="list-style-type: none"> Detects the amount of the accelerator pedal travel through the use of the accelerator pedal position sensor (sub) signal, but rendering it only as being approximately one-half the normal opening angle. Cuts off fuel when the engine speed exceeds 3,000 r/min. Suppresses the engine output by stopping the electronic-controlled throttle valve system if the accelerator pedal position sensor (sub) is also malfunctioning.
Accelerator pedal position sensor (sub)	<ul style="list-style-type: none"> Detects the amount of the accelerator pedal travel through the use of the accelerator pedal position sensor (main) signal, but rendering it only as being approximately one-half the normal opening angle. Cuts off fuel when the engine speed exceeds 3,000 r/min. Suppresses the engine output by stopping the electronic-controlled throttle valve system if the accelerator pedal position sensor (main) is also malfunctioning.
Engine coolant temperature sensor	Controls as if the engine coolant temperature is 80° C. (This control will be continued until the ignition switch is turned to the "LOCK" (OFF) position even though the sensor signal returns to normal.)
Camshaft position sensor	Injects fuel into the cylinders in the order 1-3-4-2 with irregular timing. (After the ignition switch is turned to the "ON" position, the No. 1 cylinder top dead center is not detected at all.)
Oxygen sensor <front>	Air/fuel ratio closed loop control is not performed.
Oxygen sensor <rear>	Performs the closed loop control of the air/fuel ratio by using only the signal of the oxygen sensor (front) installed on the front side of the catalytic converter.

Malfunctioning item	Control contents during malfunction
Detonation sensor	Switches the ignition timing from ignition timing for high octane to ignition timing for standard octane fuel.
Ignition coil (incorporating power transistor)	Cuts off the fuel supply to cylinders with an abnormal ignition.
Alternator FR terminal	Does not control the output of the alternator according to an electrical load. (works as a normal alternator)
Misfiring	If the detected misfiring causes damage to the catalyst, the misfiring cylinder will be shut down.
Throttle valve position feedback	<ul style="list-style-type: none"> • Suppresses the engine output by stopping the electronic-controlled throttle valve system. • Prohibits the operation of the engine speed feedback control.
Throttle valve control servo	<ul style="list-style-type: none"> • Suppresses the engine output by stopping the electronic-controlled throttle valve system. • Prohibits the operation of the engine speed feedback control.
Engine-A/T-ECU main processor	<ul style="list-style-type: none"> • Suppresses the engine output by stopping the electronic-controlled throttle valve system. • Prohibits the operation of the engine speed feedback control.
Communication between powertrain control module main processor and system LSI	<ul style="list-style-type: none"> • Renders the amount of accelerator pedal travel as being approximately one-half the normal opening angle. • Prohibits the operation of the engine speed feedback control. • Cuts off fuel when the engine speed exceeds 3,000 r/min.
Intake air monitor	<ul style="list-style-type: none"> • Suppresses the engine output by stopping the electronic-controlled throttle valve system. • Prohibits the operation of engine speed feedback.
Oil control valve	<ul style="list-style-type: none"> • Do not switch to high-speed cam. • Cut off fuel when the engine speed exceeds 5,000 r/min.

INSPECTION CHART FOR DIAGNOSIS CODE

M1131151001939

Code No.	Diagnosis item	Reference page
P0100	Air flow sensor system	P.13C-24
P0105	Barometric pressure sensor system	P.13C-29
P0110	Intake air temperature sensor system	P.13C-30
P0115	Engine coolant temperature sensor system	P.13C-36
P0122*	Throttle position sensor (main) circuit low input	P.13C-42
P0123*	Throttle position sensor (main) circuit high input	P.13C-46
P0125*	Feedback system monitor	P.13C-48
P0130	Cylinder 1, 4 oxygen sensor (front) system	P.13C-54
P0135	Cylinder 1, 4 oxygen sensor (front) heater system	P.13C-59
P0136	Cylinder 1, 4 oxygen sensor (rear) system	P.13C-64
P0141	Cylinder 1, 4 oxygen sensor (rear) heater system	P.13C-70
P0150	Cylinder 2, 3 oxygen sensor (front) system	P.13C-76
P0155	Cylinder 2, 3 oxygen sensor (front) heater system	P.13C-82
P0156	Cylinder 2, 3 oxygen sensor (rear) system	P.13C-88
P0161	Cylinder 2, 3 oxygen sensor (rear) heater system	P.13C-94
P0170	Abnormal fuel system (cylinder 1,4)	P.13C-100
P0173	Abnormal fuel system (cylinder 2,3)	P.13C-103
P0201	No.1 injector system	P.13C-106
P0202	No.2 injector system	P.13C-110
P0203	No.3 injector system	P.13C-114
P0204	No.4 injector system	P.13C-118
P0222*	Throttle position sensor (sub) circuit low input	P.13C-122
P0223*	Throttle position sensor (sub) circuit high input	P.13C-126
P0300*	Random/multiple cylinder misfire detected	P.13C-128
P0301*	No.1 cylinder misfire detected	P.13C-129
P0302*	No.2 cylinder misfire detected	P.13C-132
P0303*	No.3 cylinder misfire detected	P.13C-134
P0304*	No.4 cylinder misfire detected	P.13C-137
P0325	Detonation sensor system	P.13C-140
P0335	Crank angle sensor system	P.13C-143
P0340	Camshaft position sensor system	P.13C-151
P0403	Exhaust gas recirculation control system	P.13C-159
P0421	Warm Up Catalyst Malfunction (cylinder 1,4)	P.13C-164
P0431	Warm Up Catalyst Malfunction (cylinder 2,3)	P.13C-165
P0443	Purge control solenoid valve system	P.13C-166
P0500	Vehicle speed signal system	P.13C-170

Code No.	Diagnosis item		Reference page
P0505	Idle speed control (ISC) system		P.13C-171
P0513	Immobilizer malfunction		P.13C-172
P0551*	Power steering fluid pressure sensor system		P.13C-174
P0603	EEP ROM malfunction		P.13C-179
P0606*	Engine-A/T-ECU main processor malfunction		P.13A-147
P0622	Alternator FR terminal system		P.13C-180
P0638*	Throttle valve control servo circuit range/performance problem		P.13C-184
P0642*	Throttle position sensor power supply		P.13C-190
P0657*	Throttle valve control servo relay circuit malfunction		P.13C-191
P0705	Inhibitor switch system	<ul style="list-style-type: none"> A/T DTC No. 27 (Inhibitor switch system: open circuit) A/T DTC No. 28 (Inhibitor switch system: short circuit) 	P.23A-50, P.23A-54
P0710	A/T fluid temperature sensor system	<ul style="list-style-type: none"> A/T DTC No. 15 (A/T fluid temperature sensor system: open circuit) A/T DTC No. 16 A/T (fluid temperature sensor system: short circuit) 	P.23A-19, P.23A-25
P0715*	Input shaft speed sensor system	<ul style="list-style-type: none"> A/T DTC No. 22 (Input shaft speed sensor system) 	P.23A-27
P0720*	Output shaft speed sensor system	<ul style="list-style-type: none"> A/T DTC No. 23 (Output shaft speed sensor system) 	P.23A-36
P0740*	Torque converter clutch solenoid valve system	<ul style="list-style-type: none"> A/T DTC No. 36 (Torque converter clutch solenoid valve system) A/T DTC No. 52 (Torque converter clutch system) 	P.23A-73, P.23A-78
P0750*	Low-reverse solenoid valve system	<ul style="list-style-type: none"> A/T DTC No. 31 (Low-reverse solenoid valve system) A/T DTC No. 41, No. 46 (Gear incorrect ratio) 	P.23A-57, P.23A-77
P0755*	Underdrive solenoid valve system	<ul style="list-style-type: none"> A/T DTC No. 32 (Underdrive solenoid valve system) A/T DTC No. 41, No. 42, No. 43 (Gear incorrect ratio) 	P.23A-61, P.23A-77
P0760*	Second solenoid valve system	<ul style="list-style-type: none"> A/T DTC No. 33 (Second solenoid valve system) A/T DTC No. 42, No. 44 (Gear incorrect ratio) 	P.23A-65, P.23A-77
P0765*	Overdrive solenoid valve system	<ul style="list-style-type: none"> A/T DTC No. 34 (Overdrive solenoid valve system) A/T DTC No. 43, No. 44 (Gear incorrect ratio) 	P.23A-69, P.23A-77
P1021	Oil control valve circuit		P.13C-197
P1602*	Communication malfunction (between engine-A/T-ECU main processor and system LSI)		P.13C-201
P1603*	Battery backup circuit malfunction		P.13C-202

Code No.	Diagnosis item		Reference page
P1751*	A/T control relay system	• A/T DTC No. 54 (A/T control relay system)	P.23A-80
P2100*	Throttle valve control servo circuit (open)		P.13C-204
P2101*	Throttle valve control servo magneto malfunction		P.13C-208
P2102*	Throttle valve control servo circuit (shorted low)		P.13C-211
P2103*	Throttle valve control servo circuit (shorted high)		P.13C-214
P2122*	Accelerator pedal position sensor (main) circuit low input		P.13C-217
P2123*	Accelerator pedal position sensor (main) circuit high input		P.13C-221
P2127*	Accelerator pedal position sensor (sub) circuit low input		P.13C-223
P2128*	Accelerator pedal position sensor (sub) circuit high input		P.13C-227
P2135*	Throttle position sensor (main and sub) range/performance problem		P.13C-229
P2138*	Accelerator pedal position sensor (main and sub) range/performance problem		P.13C-231
P2173*	Abnormal intake air amount		P.13C-235
U1073	Bus off		P.13C-236
U1102	ABS-ECU time-out		P.13C-237
U1108	Combination meter time-out		P.13C-238
U1110	A/C-ECU time-out		P.13C-240


NOTE:

- Do not replace the engine-A/T-ECU until a through terminal check reveals there are no short/open circuit.
- Check that the engine-A/T-ECU earth circuit is normal before checking for the cause of the problem.
- After engine-A/T-ECU has detected a malfunction, a diagnosis code is recorded the next time the engine is started and the same malfunction is re-detected. However, for items marked with "*", the diagnosis code is recorded on the first detection of the malfunction.

INSPECTION PROCEDURE FOR
DIAGNOSIS CODES

Code No. P0100: Air Flow Sensor System

Air flow sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied by the engine control relay (terminal No. 1) to the air flow sensor (terminal No. 2), and the air flow sensor (terminal No. 4) is grounded through the engine-A/T-ECU (terminal No. 96).
- The air flow sensor (terminal No. 3) outputs a sensor signal, which is input into the engine-A/T-ECU (terminal No. 63).

FUNCTION

- The air flow sensor outputs amperage that varies in accordance with the intake air volume.
- The engine-A/T-ECU uses the amperage output by the air flow sensor and the engine speed signal in order to determine the basic injection duration of the injector.

TROUBLE JUDGMENT

Check Condition

- After 3 seconds have passed since the ignition switch was turned to ON position.

Judgment Criterion

- Air flow sensor output voltage has continued to be 0.2 V or lower for 2 seconds.

or

- Air flow sensor output voltage has continued to be 4.9 V or higher for 2 seconds.

PROBABLE CAUSES

- Failed air flow sensor
- Open/short circuit in air flow sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
a. Item 12: Air flow sensor

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-106 air flow sensor connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform voltage measurement at B-106 air flow sensor connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 2 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 5 .


NO : Go to Step 4 .

STEP 4. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-106 (terminal No. 2) air flow sensor connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 5. Check resistance measurement at B-106 air flow sensor connector.


- Disconnect and measure at harness side.
- Resistance between terminal No. 4 and earth.

OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 9 .



NO : Go to Step 6 .

STEP 6. Connector check: C-113 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-106 (terminal No. 4) air flow sensor connector and C-113 (terminal No. 96) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check earthing line for open circuit.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
a. Item 12: Air flow sensor

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 9. Connector check: C-112 engine-A/T-ECU connector.





Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair or replace.

STEP 10. Check harness between B-106 (terminal No. 3) air flow sensor connector and C-112 (terminal No. 63) engine-A/T-ECU connector.






- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Connector check: B-15X engine control relay connector**Q: Is the check result normal?****YES :** Go to Step 12 .**NO :** Repair or replace.**STEP 12. Check harness between B-106 (terminal No. 2) air flow sensor connector and B-15X (terminal No. 1) engine control relay connector.****NOTE:** Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?**YES :** Go to Step 13 .**NO :** Repair.**STEP 13. M.U.T.-III data list**

- Refer to Data List Reference Table [P.13C-313](#).
 - Item 12: Air flow sensor

Q: Is the check result normal?**YES :** Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).**NO :** Go to Step 14 .**STEP 14. Replace air flow sensor.**

- After replacing the air flow sensor, re-check the trouble symptoms.

Q: Is the check result normal?**YES :** Replace the engine-A/T-ECU.**NO :** Check end.

Code No. P0105: Barometric Pressure Sensor System

FUNCTION

- The barometric pressure sensor converts the barometric pressure into a voltage signal and inputs the signal to the engine-A/T-ECU.
- In response to the signal, the engine-A/T-ECU corrects the fuel injection amount, etc.

TROUBLE JUDGMENT

Check Conditions

- 2 seconds later after the ignition switch has been in "ON" position or the engine has started up.
- The battery voltage is 8 V or more.

Judgment Criterion

- The sensor output voltage is 4.5 V or more (Barometric pressure of above 114 kPa or equivalent) for 2 seconds.

or

- The sensor output voltage is 0.2 V or less (Barometric pressure of below 53 kPa or equivalent) for 2 seconds.

PROBABLE CAUSE

- Failed barometric pressure sensor

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code


Q: Diagnosis code set?

YES : Replace engine-A/T-ECU.

NO : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

Code No. P0110: Intake Air Temperature Sensor System

Intake air temperature sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305601AC

OPERATION

- A power voltage of 5 V is applied to the intake air temperature sensor output terminal (terminal No. 1) of the air flow sensor connector from the engine-A/T-ECU (terminal No. 99).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 96) from the air flow sensor (terminal No. 4).

FUNCTION

- The intake air temperature sensor converts the intake air temperature into a voltage and inputs the voltage signal to the engine-A/T-ECU.
- In response to the signal, the engine-A/T-ECU corrects the fuel injection amount, etc.

- The intake air temperature sensor is a kind of resistor, which has characteristics to reduce its resistance as the intake air temperature rises. Therefore, the sensor output voltage varies with the intake air temperature, and becomes lower as the intake air temperature rises.

TROUBLE JUDGMENT

Check Conditions

- 2 seconds later after the ignition switch has been in ON position or the engine has started up.
- The battery voltage is 8 V or more.

Judgment Criterion

- The sensor output voltage is 4.6V or more (intake air temperature of below -45° C or equivalent) for 4 seconds.

or

- The sensor output voltage is 0.2V or less (intake air temperature of above 125° C or equivalent) for 4 seconds.

PROBABLE CAUSES

- Failed intake air temperature sensor
- Open/short circuit in intake air temperature sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
a. Item 13: Intake air temperature sensor


OK: At ambient temperature (atmospheric temperature) or equivalent.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-106 air flow sensor connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check intake air temperature sensor itself.


- Check intake air temperature sensor itself (Refer to [P.13C-340](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace air flow sensor.

STEP 4. Perform resistance measurement at B-106 air flow sensor connector.



- Disconnect connector, and measure at harness side.

- Voltage between terminal No. 4 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 5 .

STEP 5. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

STEP 6. Check harness between B-106 (terminal No. 4) air flow sensor connector and C-113 (terminal No. 96) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. M.U.T.-III data list

- Item No. 13: Intake air temperature sensor


OK: At ambient temperature (atmospheric temperature) or equivalent.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 8. Perform voltage measurement at B-106 air flow sensor connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.



OK: 4.5 –4.9 V

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Go to Step 9 .

STEP 9. Perform voltage measurement at C-113 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Disconnect B-106 air flow sensor connector.
- Ignition switch: ON
- Voltage between terminal No. 99 and earth.



OK: 4.5 –4.9 V

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 11 .

STEP 10. Connector check: C-113 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Check and repair harness between B-106 (terminal No. 1) air flow sensor connector and C-113 (terminal No. 99) engine-A/T-ECU connector.

- Check output line for open circuit.

NO : Repair or replace.

STEP 11. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair or replace.

STEP 12. Check harness between B-106 (terminal No. 1) air flow sensor connector and C-113 (terminal No. 99) engine-A/T-ECU connector.

- Check output line for short circuit.




Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 13. Perform voltage measurement at B-106 air flow sensor connector.



- Use special tool test harness (MB991709) to connect only terminal No. 1 and No. 4, and then measure at pick-up harness.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK:

Ambient temperature at -20° C: 3.8 –4.4 V

Ambient temperature at 0° C: 3.2 –3.8 V

Ambient temperature at 20° C: 2.3 –2.9 V

Ambient temperature at 40° C: 1.5 –2.1 V

Ambient temperature at 60° C: 0.8 –1.4 V


Ambient temperature at 80° C: 0.4 –1.0 V

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 14 .

STEP 14. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair or replace.

STEP 15. Check harness between B-106 (terminal No. 1) air flow sensor connector and C-113 (terminal No. 99) engine-A/T-ECU connector.



- Check output line for damage.


Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

Code No. P0115: Engine Coolant Temperature Sensor System

Engine coolant temperature sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305549 AC

OPERATION

- A power voltage of 5 V is applied to the engine coolant temperature sensor output terminal (terminal No. 1) from the engine-A/T-ECU (terminal No. 98).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 96) from the engine coolant temperature sensor (terminal No. 2).

FUNCTION

- The engine coolant temperature sensor converts the engine coolant temperature into a voltage signal, and inputs the voltage to the engine-A/T-ECU.

- In response to the signal, the engine-A/T-ECU controls the fuel injection amount and the fast idle speed when the engine is cold state.
- The engine coolant temperature sensor is a kind of resistor, which has characteristics to reduce its resistance as the engine coolant temperature rises. Therefore, the sensor output voltage varies with the engine coolant temperature, and becomes lower as the engine coolant temperature rises.

TROUBLE JUDGMENT

Check Condition

- 2 seconds later after the ignition switch has been in ON position or just after the engine has started up.

Judgment Criterion

- The sensor output voltage is 4.6V or more (water temperature of below -45° C or equivalent) for 4 seconds.

Or

- The sensor output voltage is 0.1V or less (water temperature of above 140° C or equivalent) for 4 seconds.

Check Condition

- After the engine has started up.

Judgment Criterion

- The sensor output voltage rises 1.6V or more (engine coolant temperature below 40° C or equivalent) from 1.6V or less (engine coolant temperature above 40° C or equivalent).

PROBABLE CAUSES

- Failed engine coolant temperature sensor
- Open/short circuit in engine coolant temperature sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list

- Item 21: Engine coolant temperature sensor

OK:

Engine cold state: At ambient temperature (atmospheric temperature) or equivalent.


Engine hot state: At 80 –120° C

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-08 engine coolant temperature sensor connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-08 engine coolant temperature sensor connector.



- Disconnect connector, and measure at sensor side.
- Resistance between terminal No. 1 and No. 2.

OK:

Engine coolant temperature at -20° C: 14 –17 kΩ

Engine coolant temperature at 0° C: 5.1 –6.5 kΩ

Engine coolant temperature at 20° C: 2.1 –2.7 kΩ

Engine coolant temperature at 40° C: 0.9 –1.3 kΩ

Engine coolant temperature at 60° C: 0.48 –0.68 kΩ


Engine coolant temperature at 80° C: 0.26 –0.36 kΩ

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace engine coolant temperature sensor.

STEP 4. Perform resistance measurement at B-08 engine coolant temperature sensor connector.



- Disconnect connector and measure at harness side.
- Voltage between terminal No. 2 and earth.
OK: 2 Ω or less


Q: Is the check result normal?

YES : Go to Step 8 .


NO : Go to Step 5 .

STEP 5. Connector check: C-113 engine-A/T-ECU connector

Q: Is the check result normal?



STEP 8. Perform voltage measurement at B-08 engine coolant temperature sensor connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.


OK: 4.5 –4.9 V

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Go to Step 9 .

STEP 9. Perform voltage measurement at C-113 engine-A/T-ECU connector.





- Measure engine-A/T-ECU terminal voltage.
- Disconnect B-08 engine coolant temperature sensor connector.
- Ignition switch: ON
- Voltage between terminal No. 98 and earth.

OK: 4.5 –4.9 V

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 11 .


**STEP 10. Connector check: C-113
engine-A/T-ECU connector**

Q: Is the check result normal?

YES : Check and repair harness between B-08 (terminal No. 1) engine coolant temperature sensor connector and C-113 (terminal No. 98) engine-A/T-ECU connector.

- Check output line for open circuit.



NO : Repair or replace.

**STEP 11. Connector check: C-113
engine-A/T-ECU connector**

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair or replace.

**STEP 12. Check harness between B-08 (terminal
No. 1) engine coolant temperature sensor
connector and C-113 (terminal No. 98)
engine-A/T-ECU connector**


- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 13. Perform voltage measurement at B-08 engine coolant temperature sensor connector.



- Use special tool test harness (MB991709) to connect connector, and measure at pick-up harness.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK:

Engine coolant temperature at -20°C : 3.9–4.5 V

Engine coolant temperature at 0°C : 3.2–3.8 V

Engine coolant temperature at 20°C : 2.3–2.9 V

Engine coolant temperature at 40°C : 1.3–1.9 V

Engine coolant temperature at 60°C : 0.7–1.3 V


Engine coolant temperature at 80°C : 0.3–0.9 V

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 14 .

STEP 14. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair or replace.

STEP 15. Check harness between B-08 (terminal No. 1) engine coolant temperature sensor connector and C-113 (terminal No. 98) engine-A/T-ECU connector.



- Check output line for damage.


Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

Code No. P0122: Throttle Position Sensor (Main) Circuit Low Input

Throttle position sensor (main) circuit



Wire colour code
 B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
 R: Red P: Pink V: Violet PU: Purple

AK305550AE

OPERATION

- A power voltage of 5 V is applied to the electronic-controlled throttle valve (terminal No. 5) from the engine-A/T-ECU (terminal No. 106).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 105) from the electronic-controlled throttle valve (terminal No. 3).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 115) from the electronic-controlled throttle valve output terminal (terminal No. 4).

FUNCTION

- The throttle position sensor converts the throttle valve position into voltage and inputs it into the engine-A/T-ECU.

- The engine-A/T-ECU controls the throttle valve position.

TROUBLE JUDGMENT**Check Condition**

- Ignition switch is in "ON" position.

Judgment Criterion

- Throttle position sensor (main) output voltage is 0.35 V or less for 0.5 second.

PROBABLE CAUSES

- Failed throttle position sensor (main)
- Open/short circuit in throttle position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 79: Throttle position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform voltage measurement at B-06 electronic-controlled throttle valve connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 5 and earth.


OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-06 (terminal No. 5) electronic-controlled throttle valve connector and C-113 (terminal No. 106) engine-A/T-ECU connector.



- Check power supply line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.


STEP 6. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 79: Throttle position sensor (main)

Q: Is the check result normal?



YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Connector check: C-113 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between B-06 (terminal No. 5) electronic-controlled throttle valve connector and C-113 (terminal No. 106) engine-A/T-ECU connector.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check harness between B-06 (terminal No. 4) electronic-controlled throttle valve connector and C-113 (terminal No. 115) engine-A/T-ECU connector.



STEP 10. Replace the electronic-controlled throttle valve

- After replacing the electronic-controlled throttle valve, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

- Check output line for open/short circuit and damage.


Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

Code No. P0123: Throttle Position Sensor (Main) Circuit High Input

Throttle position sensor (main) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305550AE

OPERATION

- A power voltage of 5 V is applied to the electronic-controlled throttle valve (terminal No. 5) from the engine-A/T-ECU (terminal No. 106).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 105) from the electronic-controlled throttle valve (terminal No. 3).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 115) from the electronic-controlled throttle valve output terminal (terminal No. 4).

FUNCTION

- The throttle position sensor converts the throttle valve position into voltage and inputs it into the engine-A/T-ECU.

- The engine-A/T-ECU controls the throttle valve position.

TROUBLE JUDGMENT**Check Condition**

- Ignition switch is in "ON" position.

Judgment Criterion

- Throttle position sensor (main) output voltage is 4.8 V or more for 0.5 second.

PROBABLE CAUSES

- Failed throttle position sensor (main)
- Open/short circuit in throttle position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - Item 79: Throttle position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-06 electronic-controlled throttle valve connector.




- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 3 and earth.
 - OK: 2 Ω or less**

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-06 (terminal No. 3) electronic-controlled throttle valve connector and C-113 (terminal No. 105) engine-A/T-ECU connector.



- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 79: Throttle position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Replace the electronic-controlled throttle valve

- After replacing the electronic-controlled throttle valve, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P0125: Feedback System Monitor**OPERATION**

- Refer to Code No. P0201 No. 1 Injector System [P.13C-106](#).

Refer to Code No. P0202 No. 2 Injector System [P.13C-110](#).

Refer to Code No. P0203 No. 3 Injector System [P.13C-114](#).

Refer to Code No. P0204 No. 4 Injector System [P.13C-118](#).

- Refer to Code No. P0130 Cylinder 1, 4 Oxygen Sensor (Front) Circuit [P.13C-54](#).
- Refer to Code No. P0150 Cylinder 2, 3 Oxygen Sensor (Front) Circuit [P.13C-76](#).

FUNCTION

- The engine-A/T-ECU effects air-fuel ratio feedback control in accordance with the signals from the oxygen sensor (front).
- If the oxygen sensor (front) has deteriorated, corrections will be made by the oxygen sensor (rear).
- Diagnosis code P0125 becomes stored in memory if a failure is detected in the above air/fuel ratio feedback control system.

TROUBLE JUDGMENT**Check Conditions**

- The engine coolant temperature approximately 76° C or more.
- Within the range of air-fuel ratio feedback operation.
- Not in low speed operation.

Judgment Criterion

- The oxygen sensor output voltage is not deviated from 0.5 V for 30 seconds.

PROBABLE CAUSES

- Failed oxygen sensor (front)
- Harness damage in oxygen sensor (front) circuit or loose connector contact
- Failed oxygen sensor (rear)

NOTE: When the oxygen sensor (front) begins to deteriorate, the oxygen sensor output voltage will deviate from the voltage when the sensor was new (normally 0.5 volt at stoichiometric ratio). This deviation will be corrected by the oxygen sensor (rear). If the oxygen sensor (rear) responds poorly because it has deteriorated, it will improperly correct the oxygen sensor (front). Thus, even when closed loop control is being effected, the fluctuation of the oxygen sensor (front) output voltage decreases, without intersecting with 0.5 volt. As a result, there is a possibility of diagnosis code P0125 becoming registered.

- Failed fuel system
- Failed exhaust system
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. M.U.T.-III diagnosis code****Q: Is any other diagnosis code than P0170 or P0173 output?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2.M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 12: Air flow sensor
 - b. Item 21: Engine coolant temperature sensor
 - c. Item 59: Cylinder 1, 4 oxygen sensor (front)
 - d. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data valve (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Are the check results normal?

YES : Go to Step 4 .

NO : Replace engine-A/T-ECU.

STEP 4.Check for intake of air from intake hose and inlet manifold.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair.

STEP 5.Check for leakage of exhaust emission from exhaust manifold.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.



STEP 6.Check throttle body (throttle valve portion) for contamination.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 7. Connector check: B-22 cylinder 1, 4 oxygen sensor (front) connector, C-113 engine-A/T-ECU connector.



Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP8. Check cylinder 1, 4 oxygen sensor (front) itself.



- Check cylinder 1, 4 oxygen sensor (front) itself (Refer to [P.13C-342](#)).

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Replace cylinder 1, 4 oxygen sensor (front).

STEP 9. Check harness between B-22 (terminal No. 4) cylinder 1, 4 oxygen sensor (front) connector and C-113 (terminal No. 109) engine-A/T-ECU connector.





- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Connector check: B-19 cylinder 2, 3 oxygen sensor (front) connector, C-113 engine-A/T-ECU connector.



Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair or replace.

STEP 11. Check cylinder 2, 3 oxygen sensor (front) itself.



- Check cylinder 2, 3 oxygen sensor (front) itself (Refer to [P.13C-342](#)).

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Replace cylinder 2, 3 oxygen sensor (front).

STEP 12. Check harness between B-19 (terminal No. 4) cylinder 2, 3 oxygen sensor (front) connector and C-113 (terminal No. 108) engine-A/T-ECU connector.




- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Repair.

STEP 13. Connector check: Injector connector



- B-101 (No.1 injector connector)
- B-102 (No.2 injector connector)
- B-104 (No.3 injector connector)
- B-105 (No.4 injector connector)

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Repair or replace.

STEP 14. Check injector itself.



- Check Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Replace injector.

STEP 15. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector.





Q: Is the check result normal?

YES : Go to Step 16 .

NO : Repair or replace.

STEP 16. Check harness between B-15X engine control relay connector and injector connector.





- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-101 (terminal No. 1) No. 1 injector connector.
- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-102 (terminal No. 1) No. 2 injector connector.
- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-104 (terminal No. 1) No. 3 injector connector.
- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-105 (terminal No. 1) No. 4 injector connector.
 - Check power supply line for damage.

Q: Are the check results normal?

YES : Go to Step 17 .

NO : Repair.

STEP 17. Check harness between injector connector and C-110 engine-A/T-ECU connector.



STEP 18. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Repair.

NO : Replace engine-A/T-ECU.

- Check harness between B-101 (terminal No. 2) No. 1 injector connector and C-110 (terminal No. 1) engine-A/T-ECU connector.
 - Check harness between B-102 (terminal No. 2) No. 2 injector connector and C-110 (terminal No. 5) engine-A/T-ECU connector.
 - Check harness between B-104 (terminal No. 2) No. 3 injector connector and C-110 (terminal No. 14) engine-A/T-ECU connector.
 - Check harness between B-105 (terminal No. 2) No. 4 injector connector and C-110 (terminal No. 21) engine-A/T-ECU connector.
- Check output line for damage.


Q: Are the check results normal?

YES : Go to Step 18 .

NO : Repair.

Code No. P0130: Cylinder 1, 4 Oxygen Sensor (Front) System

Cylinder 1, 4 oxygen sensor (front) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK501532AB

OPERATION

- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 109) from the cylinder 1, 4 oxygen sensor (front) output terminal (terminal No. 4).
- The cylinder 1, 4 oxygen sensor (front) (terminal No. 2) is earthed with engine-A/T-ECU (terminal No. 96).

FUNCTION

- The cylinder 1, 4 oxygen sensor (front) converts the concentration of oxygen in the exhaust emission into a voltage and inputs the signal to the engine-A/T-ECU.
- When the air-fuel ratio is richer than the theoretical air-fuel ratio, the cylinder 1, 4 oxygen sensor (front) outputs a voltage of about 1 V. When it is leaner than the theoretical air-fuel ratio, it outputs a voltage of about 0 V.

- In response to the signal, the engine-A/T-ECU controls the fuel injection amount so that the air-fuel ratio can be equivalent to the theoretical air-fuel ratio.

TROUBLE JUDGMENT

Check Conditions

- Above 3 minutes later after the engine has started up.
- The engine coolant temperature is approx. 82° C or higher.
- The engine speed is 1200 r/min or more.
- The monitoring time is 5 seconds.

Judgment Criteria

- When the cylinder 1, 4 oxygen sensor (front) output voltage is 0.2 V or less and a power voltage of 5 V is applied to the cylinder 1, 4 oxygen sensor (front) in the engine-A/T-ECU, the sensor output voltage is 4.5V or more.
- To be monitored once per driving cycle.

Check Conditions

- The engine speed is 1200 –3000 r/min.
- The engine coolant temperature is approx. 60° C or higher.
- Volumetric efficiency is 20 –60 %.
- During the air-fuel ratio feedback control

Judgment Criterion

- When the cylinder 1, 4 oxygen sensor (front) output frequency is 6 or less for 10 seconds on the average.

PROBABLE CAUSES

- Failed cylinder 1, 4 oxygen sensor (front)
- Open/short circuit in cylinder 1, 4 oxygen sensor (front) heater circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - Item 11: Cylinder 1, 4 oxygen sensor (front)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-22 cylinder 1, 4 oxygen sensor (front) connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-22 cylinder 1, 4 oxygen sensor (front) connector.






- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.

OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .


NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector**Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Repair or replace.**STEP 5. Check harness between B-22 (terminal No. 2) cylinder 1, 4 oxygen sensor (front) connector and C-113 (terminal No. 96) engine-A/T-ECU connector.***NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.*

- Check earthing line for open circuit and damage.

Q: Is the check result normal?**YES :** . Go to Step 6 .**NO :** . Repair.**STEP 6. M.U.T.-III data list**

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 11: Cylinder 1, 4 oxygen sensor (front)

Q: Is the check result normal?**YES :** Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).**NO :** Replace engine-A/T-ECU.**STEP 7. Perform voltage measurement at B-22 cylinder 1, 4 oxygen sensor (front) connector.**



- Use special tool test harness (MB991316) to connect connector, and measure at pick-up harness.
- Engine: After warm-up
- Transmission: P range
- Voltage between terminal No. 4 and earth.

OK:**When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.****Q: Is the check result normal?****YES :** Go to Step 10 .**NO :** Go to Step 8 .**STEP 8. Check cylinder 1, 4 oxygen sensor (front) itself.**

- Check cylinder 1, 4 oxygen sensor (front) itself (Refer to [P.13C-342](#)).

Q: Is the check result normal?**YES :** Go to Step 9 .**NO :** Replace cylinder 1, 4 oxygen sensor (front).

STEP 9. Connector check: C-113 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Check and repair harness between B-22 (terminal No. 4) Cylinder 1, 4 oxygen sensor (front) connector and C-113 (terminal No. 109) engine-A/T-ECU connector.

- Check output line for damage.

NO : Repair or replace.

STEP 10. Perform voltage measurement at C-113 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Transmission: P range
- Engine: After warm-up
- Voltage between terminal No. 109 and earth.




OK:

When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Go to Step 11 .

**STEP 11. Connector check: C-113
engine-A/T-ECU connector****STEP 12. Connector check: C-113
engine-A/T-ECU connector****Q: Is the check result normal?****YES :** Go to Step 6 .**NO :** Repair or replace.**Q: Is the check result normal?**


YES : Check and repair harness between B-22 (terminal No. 4) oxygen sensor (front) connector and C-113 (terminal No. 109) engine-A/T-ECU connector.

- Check output line for open circuit.

NO : Repair or replace.

Code No. P0135: Cylinder 1, 4 Oxygen Sensor (Front) Heater System

Cylinder 1, 4 oxygen sensor (front) heater circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305552AD

OPERATION

- Power is supplied to the heater power terminal (terminal No. 1) of the Cylinder 1, 4 oxygen sensor (front) connector from the engine control relay (terminal No. 1).
- The heater (terminal No. 3) of the Cylinder 1, 4 oxygen sensor (front) connector is controlled by the power transistor in the engine-A/T-ECU (terminal No. 25).

FUNCTION

- The power supply to the cylinder 1, 4 oxygen sensor (front) heater is controlled by the ON/OFF control of the power transistor in the engine-A/T-ECU.
- Heating the cylinder 1, 4 oxygen sensor (front) heater enables the cylinder 1, 4 oxygen sensor (front) to provide good response even when the exhaust emission temperature is low.

TROUBLE JUDGMENT**Check Conditions**



- 60 seconds have elapsed since the previous monitoring started.
- Engine coolant temperature is 20° C or higher.
- While cylinder 1, 4 oxygen sensor (front) heater is on.
- Battery positive voltage is 11 –16 V.

Judgment Criterion


- Cylinder 1, 4 oxygen sensor (front) heater current has continued to be 0.16 A or lower, or 7.5 A or higher for 4 seconds.

PROBABLE CAUSES

- Failed cylinder 1, 4 oxygen sensor (front) heater
- Open/short circuit in cylinder 1, 4 oxygen sensor (front) circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Connector check: B-22 cylinder 1, 4 oxygen sensor (front) connector****Q: Is the check result normal?****YES** : Go to Step 2 .**NO** : Repair or replace.**STEP 2. Perform resistance measurement at B-22 cylinder 1, 4 oxygen sensor (front) connector.**



- Disconnect connector, and measure at sensor side.
- Resistance between terminal No. 1 and No. 3.

OK: 4.5 –8.0 Ω**Q: Is the check result normal?****YES** : Go to Step 3 .**NO** : Replace cylinder 1, 4 oxygen sensor (front).**STEP 3. Perform voltage measurement at B-22 cylinder 1, 4 oxygen sensor (front) connector.**

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage**Q: Is the check result normal?****YES** : Go to Step 5 .**NO** : Go to Step 4 .

STEP 4. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-22 (terminal No. 1) cylinder 1, 4 oxygen sensor (front) connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 5. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 25 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 6 .

STEP 6. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-22 (terminal No. 3) cylinder 1, 4 oxygen sensor (front) connector and C-110 (terminal No. 25) engine-A/T-ECU connector.




- Check earthing line for open/short circuit.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check harness between B-22 (terminal No. 1) cylinder 1, 4 oxygen sensor (front) connector and B-15X (terminal No. 1) engine control relay connector.



NOTE: Before checking harness check intermediate connector C-116, and repair if necessary.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Check harness between B-22 (terminal No. 3) cylinder 1, 4 oxygen sensor (front) connector and C-110 (terminal No. 25) engine-A/T-ECU connector.



- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0136: Cylinder 1, 4 Oxygen Sensor (Rear) System

Cylinder 1, 4 oxygen sensor (rear) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK501533AB

OPERATION

- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 117) from the cylinder 1, 4 oxygen sensor (rear) output terminal (terminal No. 4).
- The cylinder 1, 4 oxygen sensor (rear) (terminal No. 2) is earthed with engine-A/T-ECU (terminal No. 96).

FUNCTION

- The cylinder 1, 4 oxygen sensor (rear) converts the concentration of oxygen in the exhaust emission into a voltage and inputs the signal to the engine-A/T-ECU.

- When the air-fuel ratio is richer than the theoretical air-fuel ratio, the cylinder 1, 4 oxygen sensor (rear) outputs a voltage of about 1 V. When it is leaner than the theoretical air-fuel ratio, it outputs a voltage of about 0 V.
- Based on this signal, the engine-A/T-ECU corrects the deviation in the signal that is output by the cylinder 1, 4 oxygen sensor (rear).

TROUBLE JUDGMENT

Check Conditions

- Above 3 minutes later after the engine has started up.
- The engine coolant temperature is approx. 82° C or higher.
- The engine speed is 1200 r/min or more.
- The monitoring time is 5 seconds.

Judgment Criteria

- When the cylinder 1, 4 oxygen sensor (rear) output voltage is 0.2V or less and a power voltage of 5 V is applied to the cylinder 1, 4 oxygen sensor (rear) in the engine-A/T-ECU, the sensor output voltage is 4.5 V or more.
- To be monitored once per driving cycle.

Check Conditions

- 2 seconds later after lack of circuit continuity is detected.
- When the front oxygen sensor is normally operated.

Judgment Criterion

- When the air-fuel ratio is rich, the cylinder 1, 4 oxygen sensor (front) output voltage is 0.5 V or more.
- The cylinder 1, 4 oxygen sensor (rear) output voltage is less than 0.1 V.
- The maximum and maximum of the cylinder 1, 4 oxygen sensor (rear) output is 0.078 V or less.

PROBABLE CAUSES

- Failed cylinder 1, 4 oxygen sensor (rear)
- Open/short circuit in cylinder 1, 4 oxygen sensor (rear) circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 59: Cylinder 1, 4 oxygen sensor (rear)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-23 cylinder 1, 4 oxygen sensor (rear) connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-23 cylinder 1, 4 oxygen sensor (rear) connector.




- Disconnect connector, and measure at harness side.
 - Resistance between terminal No. 2 and earth.
- OK: 2 Ω or less**

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-23 (terminal No. 2) cylinder 1, 4 oxygen sensor (rear) connector and C-113 (terminal No. 96) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.



- Check earthing line for open circuit.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 59: Cylinder 1, 4 oxygen sensor (rear)


Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Perform voltage measurement at B-23 cylinder 1, 4 oxygen sensor (rear) connector.



STEP 10. Perform voltage measurement at C-113 engine-A/T-ECU connector.

- Measure engine-A/T-ECU terminal voltage.
- Transmission: P range
- Engine: After warm-up
- Voltage between terminal No. 117 and earth.



OK:

When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Go to Step 11 .

STEP 11. Connector check: C-113 engine-A/T-ECU connector


Q: Is the check result normal?

YES : Check and repair harness between B-23 (terminal No. 4) cylinder 1, 4 oxygen sensor (rear) connector and C-113 (terminal No. 117) engine-A/T-ECU connector.

- Check output line for open circuit.

NO : Repair or replace.

STEP 12. Connector check: C-113
engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

Cylinder 1,4 oxygen sensor (rear) heater circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305554AC

OPERATION

- Power is supplied to the heater power terminal (terminal No. 1) of the cylinder 1, 4 oxygen sensor (rear) connector from the engine control relay (terminal No. 1).
- The heater (terminal No. 3) of the cylinder 1, 4 oxygen sensor (rear) connector is controlled by the power transistor in the engine-A/T-ECU (terminal No. 24).

FUNCTION

- The power supply to the cylinder 1, 4 oxygen sensor (rear) heater is controlled by the ON/OFF control of the power transistor in the engine-A/T-ECU.
- Heating the cylinder 1, 4 oxygen sensor (rear) heater enables the cylinder 1, 4 oxygen sensor (rear) to provide good response even when the exhaust emission temperature is low.

TROUBLE JUDGMENT

Check Conditions

- 60 seconds have elapsed since the previous monitoring started.
- Engine coolant temperature is 20° C or higher.
- While cylinder 1, 4 oxygen sensor (rear) heater is on.
- Battery positive voltage is 11 –16 V.

Judgment Criterion


- Cylinder 1, 4 oxygen sensor (rear) heater currents have continued to be 0.16 A or lower, or 5.0 A or higher for 4 seconds.

PROBABLE CAUSES

- Failed cylinder 1, 4 oxygen sensor (rear) heater
- Open/short circuit in cylinder 1, 4 oxygen sensor (rear) heater circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-23 cylinder 1, 4 oxygen sensor (rear) connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at B-23 cylinder 1, 4 oxygen sensor (rear) connector.



- Disconnect connector, and measure at sensor side.
- Resistance between terminal No. 1 and No. 3.


OK: 11 –18 Ω

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace cylinder 1, 4 oxygen sensor (rear).

STEP 3. Perform voltage measurement at B-23 cylinder 1, 4 oxygen sensor (rear) connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Go to Step 4 .

STEP 4. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-23 (terminal No. 1) cylinder 1, 4 oxygen sensor (rear) connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 5. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 24 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 6 .

STEP 6. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-23 (terminal No. 3) cylinder 1, 4 oxygen sensor (rear) connector and C-110 (terminal No. 24) engine-A/T-ECU connector.






- Check earthing line for open/short circuit.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?****YES :** Go to Step 9 .**NO :** Repair or replace.**STEP 9. Check harness between B-23 (terminal No. 1) cylinder 1, 4 oxygen sensor (rear) connector and B-15X (terminal No. 1) engine control relay connector.****NOTE:** Before checking harness intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?**YES :** Go to Step 10 .**NO :** Repair.

STEP 10. Check harness between B-23 (terminal No. 3) cylinder 1, 4 oxygen sensor (rear) connector and C-110 (terminal No. 24) engine-A/T-ECU connector.



- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0150: Cylinder 2, 3 Oxygen Sensor (Front) System

Cylinder 2, 3 oxygen sensor (front) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK501534AB

OPERATION

- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 108) from the cylinder 2, 3 oxygen sensor (front) output terminal (terminal No. 4).
- The front cylinder 2, 3 oxygen sensor (front) (terminal No. 2) is earthed with engine-A/T-ECU (terminal No. 96).

FUNCTION

- The cylinder 2, 3 oxygen sensor (front) converts the concentration of oxygen in the exhaust emission into a voltage and inputs the signal to the engine-A/T-ECU.

- When the air-fuel ratio is richer than the theoretical air-fuel ratio, the cylinder 2, 3 oxygen sensor (front) outputs a voltage of about 1 V. When it is leaner than the theoretical air-fuel ratio, it outputs a voltage of about 0 V.
- In response to the signal, the engine-A/T-ECU controls the fuel injection amount so that the air-fuel ratio can be equivalent to the theoretical air-fuel ratio.

TROUBLE JUDGMENT

Check Conditions

- Above 3 minutes later after the engine has started up.
- The engine coolant temperature is approx. 82° C or higher.
- The engine speed is 1200 r/min or more.
- The monitoring time is 5 seconds.

Judgment Criteria

- When the cylinder 2, 3 oxygen sensor (front) output voltage is 0.2 V or less and a power voltage of 5 V is applied to the cylinder 2, 3 oxygen sensor (front) in the engine-A/T-ECU, the sensor output voltage is 4.5 V or more.
- To be monitored once per driving cycle.

Check Conditions

- The engine speed is 1200 –3000 r/min.
- The engine coolant temperature is approx. 60° C or higher.
- Volumetric efficiency is 20 –60 %.
- During the air-fuel ratio feedback control.

Judgment Criterion

- When the cylinder 2, 3 oxygen sensor (front) output frequency is 6 or less for 10 seconds on the average

PROBABLE CAUSES

- Failed cylinder 2, 3 oxygen sensor (front)
- Open/short circuit in cylinder 2, 3 oxygen sensor (front) circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 39: Cylinder 2, 3 oxygen sensor (front)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-19 cylinder 2, 3 oxygen sensor (front) connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-19 cylinder 2, 3 oxygen sensor (front) connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-19 (terminal No. 2) cylinder 2, 3 oxygen sensor (front) connector and C-113 (terminal No. 96) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.



- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 39: Cylinder 2, 3 oxygen sensor (front)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Perform voltage measurement at B-19 cylinder 2, 3 oxygen sensor (front) connector.



- Use special tool test harness (MB991316) to connect connector, and measure at pick-up harness.
- Engine: After warm-up
- Transmission: P range
- Voltage between terminal No. 4 and earth.

OK:

When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 8 .

STEP 8. Check cylinder 2, 3 oxygen sensor (front) itself



- Check cylinder 2, 3 oxygen sensor (front) itself (Refer to [P.13C-342](#)).

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Replace cylinder 2, 3 oxygen sensor (front).

STEP 9. Connector check: C-113 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Check and repair harness between B-19 (terminal No. 4) cylinder 2, 3 oxygen sensor (front) connector and C-113 (terminal No. 108) engine-A/T-ECU connector.

- Check output line for damage.

NO : Repair or replace.

STEP 10. Perform voltage measurement at C-113 engine-A/T-ECU connector.

- Measure engine-A/T-ECU terminal voltage.
- Transmission: P range
- Engine: After warm-up
- Voltage between terminal No. 108 and earth.



OK:

When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Go to Step 11 .

STEP 11. Connector check: C-113 engine-A/T-ECU connector


Q: Is the check result normal?

YES : Check and repair harness between B-19 (terminal No. 4) cylinder 2, 3 oxygen sensor (front) connector and C-113 (terminal No. 108) engine-A/T-ECU connector.

- Check output line for open circuit.

NO : Repair or replace.

STEP 12. Connector check: C-113
engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

Code No. P0155: Cylinder 2, 3 Oxygen Sensor (Front) Heater System

Cylinder 2, 3 oxygen sensor (front) heater circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305556AF

OPERATION

- Power is supplied to the heater power terminal (terminal No. 1) of the cylinder 2, 3 oxygen sensor (front) connector from the engine control relay (terminal No. 1).
- The heater (terminal No. 3) of the cylinder 2, 3 oxygen sensor (front) connector is controlled by the power transistor in the engine-A/T-ECU (terminal No. 10).

FUNCTION

- The power supply to the cylinder 2, 3 oxygen sensor (front) heater is controlled by the ON/OFF control of the power transistor in the engine-A/T-ECU.
- Heating the cylinder 2, 3 oxygen sensor (front) heater enables the cylinder 2, 3 oxygen sensor (front) to provide good response even when the exhaust emission temperature is low.

TROUBLE JUDGMENT

Check Conditions

- 60 seconds have elapsed since the previous monitoring started.
- Engine coolant temperature is 20° C or higher.
- While cylinder 2, 3 oxygen sensor (front) heater is on.
- Battery positive voltage is 11 –16 V.

Judgment Criterion


- Cylinder 2, 3 oxygen sensor (front) heater currents has continued to be 0.16 A or lower, or 7.5 A or higher for 4 seconds.

PROBABLE CAUSES

- Failed cylinder oxygen sensor heater
- Open/short circuit in cylinder 2, 3 oxygen sensor (front) heater circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-19 cylinder 2, 3 oxygen sensor (front) connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at B-19 cylinder 2, 3 oxygen sensor (front) connector.



- Disconnect connector, and measure at sensor side.
- Resistance between terminal No. 1 and No. 3.


OK: 4.5 –8.0 Ω

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace cylinder 2, 3 oxygen sensor (front).

STEP 3. Perform voltage measurement at B-19 cylinder 2, 3 oxygen sensor (front) connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Go to Step 4 .

STEP 4. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-19 (terminal No. 1) cylinder 2, 3 oxygen sensor (front) connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 5. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 10 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 6 .

STEP 6. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-19 (terminal No. 3) cylinder 2, 3 oxygen sensor (front) connector and C-110 (terminal No. 10) engine-A/T-ECU connector.






- Check earthing line for open/short circuit.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?****YES :** Go to Step 9 .**NO :** Repair or replace.**STEP 9. Check harness between B-19 (terminal No. 1) cylinder 2, 3 oxygen sensor (front) connector and B-15X (terminal No. 1) engine control relay connector.****NOTE:** Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?**YES :** Go to Step 10 .**NO :** Repair.

STEP 10. Check harness between B-19 (terminal No. 3) cylinder 2, 3 oxygen sensor (front) connector and C-110 (terminal No. 10) engine-A/T-ECU connector.



- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0156: Cylinder 2, 3 Oxygen Sensor (Rear) System

Cylinder 2, 3 oxygen sensor (rear) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK501535AB

OPERATION

- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 116) from the cylinder 2, 3 oxygen sensor (rear) output terminal (terminal No. 4).
- The cylinder 2, 3 oxygen sensor (rear) (terminal No. 2) is earthed with engine-A/T-ECU (terminal No. 96).

FUNCTION

- The cylinder 2, 3 oxygen sensor (rear) converts the concentration of oxygen in the exhaust emission into a voltage and inputs the signal to the engine-A/T-ECU.

- When the air-fuel ratio is richer than the theoretical air-fuel ratio, the cylinder 2, 3 oxygen sensor (rear) outputs a voltage of about 1 V. When it is leaner than the theoretical air-fuel ratio, it outputs a voltage of about 0 V.
- Based on this signal, the engine-A/T-ECU corrects the deviation in the signal that is output by the cylinder 2, 3 oxygen sensor (front).

TROUBLE JUDGMENT

Check Conditions

- Above 3 minutes later after the engine has started up.
- The engine coolant temperature is approx. 82° C or higher.
- The engine speed is 1200 r/min or more.
- The monitoring time is 5 seconds.

Judgment Criteria

- When the cylinder 2, 3 oxygen sensor (rear) output voltage is 0.2 V or less and a power voltage of 5 V is applied to the cylinder 2, 3 oxygen sensor (rear) in the engine-A/T-ECU, the sensor output voltage is 4.5 V or more.
- To be monitored once per driving cycle.

Check Conditions

- 2 seconds later after lack of circuit continuity is detected.
- When the cylinder 2, 3 oxygen sensor (rear) is normally operated.

Judgment Criteria

- When the air-fuel ratio is rich, the cylinder 2, 3 oxygen sensor (rear) output voltage is 0.5 V or more.
- The cylinder 2, 3 oxygen sensor (rear) output voltage is less than 0.1 V.
- The maximum and maximum of the cylinder 2, 3 oxygen sensor (rear) output is 0.078 V or less.

PROBABLE CAUSES

- Failed cylinder 2, 3 oxygen sensor (rear)
- Open/short circuit in cylinder 2, 3 oxygen sensor (rear) circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-18 cylinder 2, 3 oxygen sensor (rear) connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-18 cylinder 2, 3 oxygen sensor (rear) connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-18 (terminal No. 2) cylinder 2, 3 oxygen sensor (rear) connector and C-113 (terminal No. 96) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.



- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Perform voltage measurement at B-18 cylinder 2, 3 oxygen sensor (rear) connector.



- Use special tool test harness (MD998464) to connect connector, and measure at pick-up harness.
- Transmission: P range
- Engine: After warm-up
- Voltage between terminal No. 4 and earth.

OK:

When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 8 .

STEP 8. Check cylinder 2, 3 oxygen sensor (rear) itself



- Check cylinder 2, 3 oxygen sensor (rear) itself (Refer to [P.13C-342](#)).

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Replace cylinder 2, 3 oxygen sensor (rear).

STEP 9. Connector check: C-113 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Check and repair harness between B-18 (terminal No. 4) cylinder 2, 3 oxygen sensor (rear) connector and C-113 (terminal No. 116) engine-A/T-ECU connector.

- Check output line for damage.

NO : Repair or replace.

STEP 10. Perform voltage measurement at C-113 engine-A/T-ECU connector.

- Measure engine-A/T-ECU terminal voltage.
- Transmission: P range
- Engine: After warm-up
- Voltage between terminal No. 116 and earth.



OK:

When the engine is 2,500 r/min, the output voltage should repeat 0 to 0.8 V alternately.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Go to Step 11 .

STEP 11. Connector check: C-113 engine-A/T-ECU connector


Q: Is the check result normal?

YES : Check and repair harness between B-18 (terminal No. 4) cylinder 2, 3 oxygen sensor (rear) connector and C-113 (terminal No. 116) engine-A/T-ECU connector.

- Check output line for open circuit.

NO : Repair or replace.

STEP 12. Connector check: C-113
engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

Code No. P0161: Cylinder 2, 3 Oxygen Sensor (Rear) Heater System

Cylinder 2, 3 oxygen sensor (rear) heater circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305558AC

OPERATION

- Power is supplied to the heater power terminal (terminal No. 1) of the cylinder 2, 3 oxygen sensor (rear) connector from the engine control relay (terminal No. 1).
- The heater (terminal No. 3) of the cylinder 2, 3 oxygen sensor (rear) connector is controlled by the power transistor in the engine-A/T-ECU (terminal No. 18).

FUNCTION

- The power supply to the cylinder 2, 3 oxygen sensor (rear) heater is controlled by the ON/OFF control of the power transistor in the engine-A/T-ECU.
- Heating the cylinder 2, 3 oxygen sensor (rear) heater enables the cylinder 2, 3 oxygen sensor (rear) to provide good response even when the exhaust emission temperature is low.

TROUBLE JUDGMENT

Check Conditions

- 60 seconds have elapsed since the previous monitoring started.
- Engine coolant temperature is 20° C or higher.
- While cylinder 2, 3 oxygen sensor (rear) heater is on.
- Battery positive voltage is 11 –16 V.

Judgment Criterion


- Cylinder 2, 3 oxygen sensor (rear) heater currents have continued to be 0.16 A or lower, or 5.0 A or higher for 4 seconds.

PROBABLE CAUSES

- Failed cylinder 2, 3 oxygen sensor (rear) heater
- Open/short circuit in cylinder 2, 3 oxygen sensor (rear) heater circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-18 cylinder 2, 3 oxygen sensor (rear) connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at B-18 cylinder 2, 3 oxygen sensor (rear) connector.




- Disconnect connector, and measure at sensor side.
- Resistance between terminal No. 1 and No. 3.

OK: 11 –18 Ω



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace cylinder 2, 3 oxygen sensor (rear).

STEP 3. Perform voltage measurement at B-18 cylinder 2, 3 oxygen sensor (rear) connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.


OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Go to Step 4 .**STEP 4. Connector check: B-15X engine control relay connector****Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-18 (terminal No. 1) cylinder 2, 3 oxygen sensor (rear) connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 5. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 18 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 6 .

STEP 6. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-18 (terminal No. 3) cylinder 2, 3 oxygen sensor (rear) connector and C-110 (terminal No. 18) engine-A/T-ECU connector.






- Check earthing line for open/short circuit.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?****YES :** Go to Step 9 .**NO :** Repair or replace.**STEP 9. Check harness between B-18 (terminal No. 1) cylinder 2, 3 oxygen sensor (rear) connector and B-15X (terminal No. 1) engine control relay connector.****NOTE:** Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?**YES :** Go to Step 10 .**NO :** Repair.

STEP 10. Check harness between B-18 (terminal No. 3) cylinder 2, 3 oxygen sensor (rear) connector and C-110 (terminal No. 18) engine-A/T-ECU connector.



- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0170: Abnormal Fuel System (Cylinder 1, 4)

OPERATION

- Refer to Code No. P0201: No. 1 Injector System [P.13C-106](#).
- Refer to Code No. P0204: No. 4 Injector System [P.13C-118](#).

FUNCTION

- If the fuel system goes out of order, the fuel correction value will become larger.
- The engine-A/T-ECU checks whether the fuel trim value is within a specified range.

TROUBLE JUDGMENT**Check Condition**

- In learning the air-fuel ratio

Judgment Criterion

- Long-term fuel trim has continued to be +12.5 % or higher for 10 seconds.

or

- Long-term fuel trim has continued to be -12.5 % or lower for 10 seconds.

PROBABLE CAUSES

- Failed intake air temperature sensor
- Failed air flow sensor
- Failed purge control solenoid valve
- Failed injector
- Air drawn in from gaps in gasket, seals, etc.
- Failed engine coolant temperature sensor
- Failed barometric pressure sensor
- Exhaust leak
- Incorrect fuel pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Is any other diagnosis code than P0170 output?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 12: Air flow sensor
 - b. Item 13: Intake air temperature sensor
 - c. Item 21: Engine coolant temperature sensor

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace engine-A/T-ECU.

STEP 4. Check throttle body (throttle valve portion) for contamination.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 5. Check for intake of air from intake hose and inlet manifold.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.


STEP 6. Check for leakage of exhaust emission from exhaust manifold.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Connector Check: Injector connector



- B-101 (No. 1 injector connector).
- B-105 (No. 4 injector connector).

Q: Are the check results normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check No.1 and No.4 injector itself.



- Check No.1 and No.4 Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Replace injector.



STEP 9. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector



Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair or replace.



STEP 10. Check harness between B-15X engine control relay connector and injector connector.

- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-101 (terminal No. 1) No. 1 injector connector.
- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-105 (terminal No. 1) No. 4 injector connector.
 - Check power supply line for damage.

Q: Are the check results normal?

YES : Go to Step 11 .

NO : Repair or replace.

STEP 11. Check harness between injector connector and C-110 engine-A/T-ECU connector.

- Check harness between B-101 (terminal No. 2) No. 1 injector connector and C-110 (terminal No. 1) engine-A/T-ECU connector.
- Check harness between B-105 (terminal No. 2) No. 4 injector connector and C-110 (terminal No. 21) engine-A/T-ECU connector.
 - Check power supply line for damage.

Q: Are the check results normal?

YES : Go to Step 12 .

NO : Repair.

STEP 12. Check purge control solenoid valve itself.

- Check purge control solenoid valve itself (Refer to GROUP 17 –Emission Control System – Evaporative Emission Control System–Purge Control Solenoid Valve [P.17-42](#)).

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Replace purge control solenoid valve.

STEP 13. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Repair.

Code No. P0173: Abnormal Fuel System (cylinder 2, 3)

OPERATION

- Refer to Code No. P0202 No. 2 Injector System [P.13C-110](#).
- Refer to Code No. P0203 No. 3 Injector System [P.13C-114](#).

FUNCTION

- If the fuel system goes out of order, the fuel correction value will become larger.
- The engine-A/T-ECU checks whether the fuel trim value is within a specified range.

TROUBLE JUDGMENT

Check Condition

- In learning the air-fuel ratio

Judgment Criterion

- Long-term fuel trim has continued to be +12.5 % or higher for 10 seconds.

or

- Long-term fuel trim has continued to be -12.5 % or lower for 10 seconds.

PROBABLE CAUSES

- Failed intake air temperature sensor
- Failed air flow sensor
- Failed purge control solenoid valve
- Failed injector
- Air drawn in from gaps in gasket, seals, etc.
- Failed engine coolant temperature sensor
- Failed barometric pressure sensor
- Exhaust leak
- Incorrect fuel pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Is any other diagnosis code than P0173 output?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 12: Air flow sensor
 - b. Item 13: Intake air temperature sensor
 - c. Item 21: Engine coolant temperature sensor

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace engine-A/T-ECU.

STEP 4. Check throttle body (throttle valve portion) for contamination.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 5. Check for intake of air from intake hose and inlet manifold.

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Repair.

STEP 6. Check for leakage of exhaust emission from exhaust manifold.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Connector Check: Injector connector

- B-102 (No. 2 injector connector).
- B-104 (No. 3 injector connector).

Q: Are the check results normal?

YES : Go to Step 8 .

NO : Repair or replace.



STEP 8. Check No.2 and No.3 injector itself.

- Check No.2 and No.3 Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Replace injector.



STEP 9. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair or replace.

STEP 10. Check harness between B-15X engine control relay connector and injector connector.





- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-102 (terminal No. 1) No. 2 injector connector.
- Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check harness between B-15X (terminal No. 1) engine control relay connector and B-104 (terminal No. 1) No. 3 injector connector.
 - Check power supply line for damage.

Q: Are the check results normal?

YES : Go to Step 11 .
NO : Repair or replace.

STEP 11. Check harness between injector connector and C-110 engine-A/T-ECU connector.



- Check harness between B-102 (terminal No. 2) No. 2 injector connector and C-110 (terminal No. 5) engine-A/T-ECU connector.
- Check harness between B-104 (terminal No. 2) No. 3 injector connector and C-110 (terminal No. 14) engine-A/T-ECU connector.

Q: Are the check results normal?

YES : Go to Step 12 .
NO : Repair.

STEP 12. Check purge control solenoid valve itself.

- Check purge control solenoid valve itself (Refer to GROUP 17 –Emission Control System – Evaporative Emission Control System –Purge Control Solenoid Valve [P.17-42](#)).

Q: Is the check result normal?

YES : Go to Step 13 .
NO : Replace purge control solenoid valve.


STEP 13. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.
NO : Repair.

Code No. P0201: No. 1 Injector System



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the injector (terminal No. 1) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU (terminal No. 1) makes the power transistor in the unit be in ON position, and that makes currents go on the injector (terminal No. 2).

FUNCTION

- The engine-A/T-ECU controls the power supply interval of the injector.
- The fuel injection amount of the injector depends on the power supply interval.

TROUBLE JUDGMENT

Check Condition

- While engine is running.

Judgment Criterion

- Injector coil surge voltage (battery positive voltage + 2 V) has not been detected for 2 seconds.

PROBABLE CAUSES

- Failed No. 1 injector
- Open/short circuit in injector circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III actuator test

- Item 01: No. 1 injector


OK: Idling state varies.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-101 No. 1 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check No. 1 injector itself.


- Check No. 1 Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace No. 1 injector.

STEP 4. Perform voltage measurement at B-101 No. 1 injector connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-15X (terminal No. 1) engine control relay connector and B-101 (terminal No. 1) No. 1 injector connector.



- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 6. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-15X (terminal No. 1) engine control relay connector and B-101 (terminal No. 1) No. 1 injector connector.


NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 8 .



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check harness between B-101 (terminal No. 2) No. 1 injector connector and C-110 (terminal No. 1) engine-A/T-ECU connector.




- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Perform signal wave pattern measurement at C-110 engine-A/T-ECU connector (Using an oscilloscope).



- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 1 and earth.


OK: Waveforms should be display on Inspection procedure using an oscilloscope (Refer to P.13C-329).

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

NO : Replace engine-A/T-ECU.

Code No. P0202: No. 2 Injector System



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the injector (terminal No. 1) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU connector (terminal No. 5) makes the power transistor in the unit be in ON position, and that makes currents go on the injector (terminal No. 2).

FUNCTION

- The engine-A/T-ECU controls the power supply interval of the injector.
- The fuel injection amount of the injector depends on the power supply interval.

TROUBLE JUDGMENT

Check Condition

- While engine is running.

Judgment Criterion

- Injector coil surge voltage (battery positive voltage + 2 V) has not been detected for 2 seconds.

PROBABLE CAUSES

- Failed No. 2 injector
- Open/short circuit in No. 2 injector circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III actuator test

- Item 02: No. 2 injector


OK: Idling state varies.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-102 No. 2 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check No. 2 injector itself.


- Check No. 2 Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace No. 2 injector.

STEP 4. Perform voltage measurement at B-102 No. 2 injector connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-15X (terminal No. 1) engine control relay connector and B-102 (terminal No. 1) No. 2 injector connector.



- Check power supply line for open/short circuit and damage.

NO : Repair or replace.

STEP 6. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-15X (terminal No. 1) engine control relay connector and B-102 (terminal No. 1) No. 2 injector connector.


NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 8 .



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check harness between B-102 (terminal No. 2) No. 2 injector connector and C-110 (terminal No. 5) engine-A/T-ECU connector.




- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Perform signal wave pattern measurement at C-110 engine-A/T-ECU connector (Using an oscilloscope).



- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 5 and earth.


OK: Waveform should be display on Inspection procedure using an oscilloscope (Refer to P.13C-329).

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

NO : Replace engine-A/T-ECU.

Code No. P0203: No. 3 Injector System



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the injector (terminal No. 1) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU (terminal No. 14) makes the power transistor in the unit be in ON position, and that makes currents go on the injector (terminal No. 2).

FUNCTION

- The engine-A/T-ECU controls the power supply interval of the injector.
- The fuel injection amount of the injector depends on the power supply interval.

TROUBLE JUDGMENT

Check Condition

- While engine is running.

Judgment Criterion

- Injector coil surge voltage (battery positive voltage + 2 V) has not been detected for 2 seconds.

PROBABLE CAUSES

- Failed No. 3 injector
- Open/short circuit in No. 3 injector circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III actuator test

- Item 03: No. 3 injector


OK: Idling state varies.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-104 No. 3 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check No. 3 injector itself.


- Check No. 3 Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace No. 3 injector.

STEP 4. Perform voltage measurement at B-104 No. 3 injector connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-15X (terminal No. 1) engine control relay connector and B-104 (terminal No. 1) No. 3 injector connector.



- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 6. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-15X (terminal No. 1) engine control relay connector and B-104 (terminal No. 1) No. 3 injector connector.


NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 8 .



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check harness between B-104 (terminal No. 2) No. 3 injector connector and C-110 (terminal No. 14) engine-A/T-ECU connector.




- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Perform signal wave pattern measurement at C-110 engine-A/T-ECU connector (Using on oscilloscope).



- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 14 and earth.


OK: Waveform should be display on Inspection procedure using an oscilloscope (Refer to P.13C-329).

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

NO : Replace engine-A/T-ECU.

Code No. P0204: No. 4 Injector System



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the injector (terminal No. 1) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU (terminal No. 21) makes the power transistor in the unit be in ON position, and that makes currents go on the injector (terminal No. 2).

FUNCTION

- The engine-A/T-ECU connector controls the power supply interval of the injector.
- The fuel injection amount of the injector depends on the power supply interval.

TROUBLE JUDGMENT

Check Condition

- While engine is running.

Judgment Criterion

- Injector coil surge voltage (battery positive voltage + 2 V) has not been detected for 2 seconds.

PROBABLE CAUSES

- Failed No. 4 injector
- Open/short circuit in No. 4 injector circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III actuator test

- Item 04: No. 4 injector


OK: Idling state varies.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-105 No. 4 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check No. 4 injector itself.


- Check No. 4 Injector (Refer to [P.13C-344](#)) itself.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace No. 4 injector.

STEP 4. Perform voltage measurement at B-105 No. 4 injector connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-15X (terminal No. 1) engine control relay connector and B-105 (terminal No. 1) No. 4 injector connector.



- Check power supply line for open/short circuit and damage.

NO : Repair or replace.

STEP 6. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Go to Step 7.

NO : Repair or replace.

STEP 7. Check harness between B-15X (terminal No. 1) engine control relay connector and B-105 (terminal No. 1) No. 4 injector connector.


NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 8 .



NO : Repair.

STEP 8. Connector check: C-110 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check harness between B-105 (terminal No. 2) No. 4 injector connector and C-110 (terminal No. 21) engine-A/T-ECU connector.




- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Perform signal wave pattern measurement at C-110 engine-A/T-ECU connector (Using an oscilloscope).



- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 21 and earth.

OK: Waveform should be display on Inspection procedure using an oscilloscope (Refer to P.13C-329).


Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

NO : Replace engine-A/T-ECU.

Code No. P0222: Throttle Position Sensor (Sub) Circuit Low Input

Throttle position sensor (sub) circuit



Wire colour code
 B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
 R: Red P: Pink V: Violet PU: Purple

AK305560 AE

OPERATION

- A power voltage of 5 V is applied to the electronic-controlled throttle valve (terminal No. 5) from the engine-A/T-ECU (terminal No. 106).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 105) from the electronic-controlled throttle valve (terminal No. 3).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 113) from the electronic-controlled throttle valve output terminal (terminal No. 6).

FUNCTION

- The throttle position sensor converts the throttle valve position into voltage and inputs it into the engine-A/T-ECU.

- The engine-A/T-ECU controls the throttle valve position.

TROUBLE JUDGMENT**Check Condition**

- Ignition switch is in ON position.

Judgment Criterion

- Throttle position sensor (sub) output voltage is 2.25 V or less for 0.5 second.

PROBABLE CAUSES

- Failed throttle position sensor (sub)
- Open/short circuit in throttle position sensor (sub) circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform voltage measurement at B-06 electronic-controlled throttle valve connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 5 and earth.


OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-06 (terminal No. 5) electronic-controlled throttle valve connector and C-113 (terminal No. 106) engine-A/T-ECU connector.



- Check power supply line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.


STEP 6. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 79: Throttle position sensor (main)

Q: Is the check result normal?



YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Connector check: C-113 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between B-06 (terminal No. 5) electronic-controlled throttle valve connector and C-113 (terminal No. 106) engine-A/T-ECU connector.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check harness between B-06 (terminal No. 6) electronic-controlled throttle valve connector and C-113 (terminal No. 113) engine-A/T-ECU connector.



STEP 10. Replace the electronic-controlled throttle valve

- After replacing the electronic-controlled throttle valve, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

- Check output line for open/short circuit and damage.


Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

Code No. P0223: Throttle Position Sensor (Sub) Circuit High Input

Throttle position sensor (sub) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305560 AE

OPERATION

- A power voltage of 5 V is applied to the electronic-controlled throttle valve (terminal No. 5) from the engine-A/T-ECU (terminal No. 106).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 105) from the electronic-controlled throttle valve (terminal No. 3).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 113) from the electronic-controlled throttle valve output terminal (terminal No. 6).

FUNCTION

- The throttle position sensor converts the throttle valve position into voltage and inputs it into the engine-A/T-ECU.

- The engine-A/T-ECU controls the throttle valve position.

TROUBLE JUDGMENT

Check Condition

- Ignition switch is in "ON" position.

Judgment Criterion

- Throttle position sensor (sub) output voltage is 4.8 V or more for 0.5 second.

PROBABLE CAUSES

- Failed throttle position sensor (sub)
- Open/short circuit in throttle position sensor (sub) circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - Item 14: Throttle position sensor (sub)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at B-06 electronic-controlled throttle valve connector.




- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 3 and earth.
OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-06 (terminal No. 3) electronic-controlled throttle valve connector and C-113 (terminal No. 105) engine-A/T-ECU connector.



- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Replace the electronic-controlled throttle valve

- After replacing the electronic-controlled throttle valve, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P0300: Random/Multiple Cylinder Misfire Detected**OPERATION**

- Refer to Code No. P0201: No. 1 injector system [P.13C-106](#).
- Refer to Code No. P0202: No. 2 injector system [P.13C-110](#).
- Refer to Code No. P0203: No. 3 injector system [P.13C-114](#).
- Refer to Code No. P0204: No. 4 injector system [P.13C-118](#).

FUNCTION

- If a misfire occurs while the engine is running, the engine speed changes for an instant.
- The engine-A/T-ECU checks for such changes in engine speed.

TROUBLE JUDGMENT**Check Conditions**

- Engine speed is 500 –6,500 r/min.
- Engine coolant temperature is -10°C or higher.
- Barometric pressure is 76 kPa or higher.
- Volumetric efficiency is between 30% and 55 %.
- Adaptive learning is complete for the vane which generates a crankshaft position signal.
- While the engine is running, excluding gear shifting, deceleration, sudden acceleration/deceleration and A/C compressor switching.
- The throttle deviation is -0.06 V/10 ms to +0.06 V/10 ms.

Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection).

- Misfire has occurred more frequently than the limit during the last 200 revolutions (when the catalyst temperature has been 950°C or higher).

Or

- Misfire has occurred 15 times or more in the last 1,000 revolutions (that has been equivalent to approximately 1.5 times the emission standard).

PROBABLE CAUSES

- Ignition system related part(s) failed
- Failed crank angle sensor
- Incorrect air-fuel ratio
- Low compression pressure
- Failed engine coolant temperature sensor
- Skipping of timing belt teeth.
- EGR system and EGR valve failed
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1.M.U.T.-III data list**

- Item 22: Crank angle sensor

OK: Keep the engine speed constant to make the pulse width of output waveform constant.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check crank angle sensor system (Refer to Code No. P0335 [P.13C-143](#)).

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 21: Engine coolant temperature sensor
 - b. Item 81: Long-term fuel compensation
 - c. Item 82: Short-term fuel compensation

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data valve (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).


STEP 3. Check ignition coil spark.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 4. Connector check: Injector connector



- a. B-101 (No. 1 injector connector)
- b. B-102 (No. 2 injector connector)
- c. B-104 (No. 3 injector connector)
- d. B-105 (No. 4 injector connector)

Q: Are the check results normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check injector itself.

- Check Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Replace injector.

STEP 6. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#))

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Check for intake of air from intake hose and inlet manifold.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check for skipped timing belt teeth.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Exhaust Gas Recirculation (EGR) System –EGR Valve (Stepper Motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 10.

NO : Replace EGR valve (stepper motor)

STEP 10. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0301: No. 1 Cylinder Misfire Detected

OPERATION

- Refer to Code No. P0201: No. 1 Injector System [P.13C-106](#).

FUNCTION

- If a misfire occurs while the engine is running, the engine speed changes for an instant.
- The engine-A/T-ECU checks for such changes in engine speed.

TROUBLE JUDGMENT

Check Conditions

- Engine speed is 500 –6,500 r/min.
- Engine coolant temperature is -10° C or higher.
- Barometric pressure is 76 kPa or higher.
- Volumetric efficiency is between 30% and 55 %.
- Adaptive learning is complete for the vane which generates a crankshaft position signal.
- While the engine is running, excluding gear shifting, deceleration, sudden acceleration/deceleration and A/C compressor switching.

- The throttle deviation is -0.06 V/10 ms to $+0.06$ V/10 ms.

Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection).

- Misfire has occurred more frequently than the limit during the last 200 revolutions (when the catalyst temperature has been 950°C or higher).
- or
- Misfire has occurred 15 times or more in the last 1,000 revolutions (that has been equivalent to approximately 1.5 times the emission standard).

PROBABLE CAUSES

- Ignition system related part(s) failed
- Low compression pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE


STEP 1. Check ignition coil spark.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check ignition circuit system (Refer to Inspection procedure 25 [P.13C-303](#))

STEP 2. Connector check: B-101 No. 1 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check No. 1 injector itself.



- Check Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace No. 1 injector.

STEP 4. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-15X (terminal No. 1) engine control relay connector and B-101 (terminal No. 1) No. 1 injector connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. Check harness between B-101 (terminal No. 2) No. 1 injector connector and C-110 (terminal No. 1) engine-A/T-ECU connector



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Go to Step 8

NO : Repair.

STEP 8. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0302: No. 2 Cylinder Misfire Detected**OPERATION**

- Refer to Code No. P0202 No. 2 Injector System [P.13C-110](#).

FUNCTION

- If a misfire occurs while the engine is running, the engine speed changes for an instant.
- The engine-A/T-ECU checks for such changes in engine speed.

TROUBLE JUDGMENT**Check Conditions**

- Engine speed is 500 –6,500 r/min.
- Engine coolant temperature is -10°C or higher.
- Barometric pressure is 76 kPa or higher.
- Volumetric efficiency is between 30% and 55 %.
- Adaptive learning is complete for the vane which generates a crankshaft position signal.
- While the engine is running, excluding gear shifting, deceleration, sudden acceleration/deceleration and A/C compressor switching.
- The throttle deviation is -0.06 V/10 ms to +0.06 V/10 ms.

Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection).


- Misfire has occurred more frequently than the limit during the last 200 revolutions (when the catalyst temperature has been 950°C or higher).

or

- Misfire has occurred 15 times or more in the last 1,000 revolutions (that has been equivalent to approximately 1.5 times the emission standard).

PROBABLE CAUSES



- Ignition system related part(s) failed
- Low compression pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Check ignition coil spark.****Q: Is the check result normal?****YES :** Go to Step 2 .**NO :** Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).**STEP 2. Check connector: B-102 No. 2 injector connector****Q: Is the check result normal?****YES :** Go to Step 3 .**NO :** Repair or replace.**STEP 3. Check No. 2 injector itself.**

- Check Injector itself (Refer to [P.13C-344](#)).



Q: Is the check result normal?**YES :** Go to Step 4 .**NO :** Replace No. 2 injector.

STEP 4. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector



Q: Is the check result normal?
YES : Go to Step 5 .
NO : Repair or replace.



STEP 5. Check harness between B-15X (terminal No. 1) engine control relay connector and B-102 (terminal No. 1) No. 2 injector connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?
YES : Go to Step 6 .
NO : Repair.

STEP 6. Check harness between B-102 (terminal No. 2) No. 2 injector connector and C-110 (terminal No. 5) engine-A/T-ECU connector

- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#))

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check the trouble symptoms.**Q: Does trouble symptom persist?**

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0303: No. 3 Cylinder Misfire Detected**OPERATION**

- Refer to Code No. P0203 No. 3 Injector System [P.13C-114](#).

FUNCTION

- If a misfire occurs while the engine is running, the engine speed changes for an instant.
- The engine-A/T-ECU checks for such changes in engine speed.

TROUBLE JUDGMENT**Check Conditions**

- Engine speed is 500 –6,500 r/min.
- Engine coolant temperature is -10° C or higher.
- Barometric pressure is 76 kPa or higher.
- Volumetric efficiency is between 30% and 55 %.

- Adaptive learning is complete for the vane which generates a crankshaft position signal.
- While the engine is running, excluding gear shifting, deceleration, sudden acceleration/deceleration and A/C compressor switching.
- The throttle deviation is -0.06 V/10 ms to +0.06 V/10 ms.

Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection).

- Misfire has occurred more frequently than the limit during the last 200 revolutions (when the catalyst temperature has been 950° C or higher).

or

- Misfire has occurred 15 times or more in the last 1,000 revolutions (that has been equivalent to approximately 1.5 times the emission standard).

PROBABLE CAUSES

- Ignition system related part(s) failed
- Low compression pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE


STEP 1. Check ignition coil spark.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 2. Connector check: B-104 No. 3 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check No. 3 injector itself.



- Check Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace No. 3 injector.

STEP 4. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between B-15X (terminal No. 1) engine control relay connector and B-104 (terminal No. 1) No. 3 injector connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. Check harness between B-104 (terminal No. 2) No. 3 injector connector and C-110 (terminal No. 14) engine-A/T-ECU connector



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#))

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0304: No. 4 Cylinder Misfire Detected

OPERATION

- Refer to Code No. P0204 No. 4 Injector System [P.13C-118](#).

FUNCTION

- If a misfire occurs while the engine is running, the engine speed changes for an instant.
- The engine-A/T-ECU checks for such changes in engine speed.

TROUBLE JUDGMENT

Check Conditions

- Engine speed is 500 –6,500 r/min.
- Engine coolant temperature is -10°C or higher.
- Barometric pressure is 76 kPa or higher.
- Volumetric efficiency is between 30% and 55 %.
- Adaptive learning is complete for the vane which generates a crankshaft position signal.
- While the engine is running, excluding gear shifting, deceleration, sudden acceleration/deceleration and A/C compressor switching.
- The throttle deviation is -0.06 V/10 ms to +0.06 V/10 ms.

Judgment Criteria (change in the angular acceleration of the crankshaft is used for misfire detection).

- Misfire has occurred more frequently than the limit during the last 200 revolutions (when the catalyst temperature has been 950°C or higher).

or

- Misfire has occurred 15 times or more in the last 1,000 revolutions (that has been equivalent to approximately 1.5 times the emission standard).

PROBABLE CAUSES

- Ignition system related part(s) failed
- Low compression pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE


STEP 1. Check the ignition coil spark.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check ignition Circuit System (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 2. Connector check: B-105 No. 4 injector connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.





STEP 3. Check No. 4 injector itself.

- Check Injector itself (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 4 .



NO : Replace No. 4 injector.

STEP 4. Connector check: B-15X engine control relay connector and C-110 engine-A/T-ECU connector**Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Repair or replace.**STEP 5. Check harness between B-15X (terminal No. 1) engine control relay connector and B-105 (terminal No. 1) No. 4 injector connector.****NOTE:** Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?**YES :** Go to Step 6 .**NO :** Repair.

STEP 6. Check harness between B-105 (terminal No. 2) No. 4 injector connector and C-110 (terminal No. 21) engine-A/T-ECU connector.



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair.

STEP 7. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#))

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0325: Detonation Sensor System

Detonation sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305600AC

OPERATION

- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 89) from the detonation sensor (terminal No. 1).

FUNCTION

- The detonation sensor detects the vibration of the cylinder block caused by detonation waves, and inputs a signal to the engine-A/T-ECU.
- In response to the signal, the engine-A/T-ECU provides controls to retard the ignition timing when the detonation occurs.

TROUBLE JUDGMENT**Check Conditions**

- After 2 seconds have passed since the engine starting sequence was completed.
- Engine speed is 2,500 r/min or higher.

Judgment Criterion


- Change of detonation sensor output voltage (detonation sensor peak voltage in each 1/2 turn of the crankshaft) has not been 0.06 V or more in the last consecutive 200 periods.

PROBABLE CAUSES

- Failed detonation sensor
- Open/short circuit in detonation sensor circuit or loose connector contact
- Failed engine-A/T-ECU


DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-24 detonation sensor connector



- Q: Is the check result normal?**
YES : Go to Step 2 .
NO : Repair or replace.


STEP 2. Perform resistance measurement at B-24 detonation sensor connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.
OK: 2 Ω or less



- Q: Is the check result normal?**
YES : Go to Step 3 .
NO : Check and repair harness between B-24 (terminal No. 2) detonation sensor connector and body earth.
- Check earthing line for open circuit and damage.

STEP 3. Connector check: C-112 engine-A/T-ECU connector



- Q: Is the check result normal?**
YES : Go to Step 4 .
NO : Repair or replace.

STEP 4. Check harness between B-24 (terminal No. 1) detonation sensor connector and C-112 (terminal No. 89) engine-A/T-ECU connector.



- Check output line for open/short circuit and damage.

- Q: Is the check result normal?**
YES : Go to Step 5 .
NO : Repair.

STEP 5. Check the trouble symptoms.**Q: Does trouble symptom persist?****YES :** Go to Step 6 .**NO :** Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).


STEP 6. Replace detonation sensor.

- After replacing the detonation sensor, re-check the trouble symptoms.

Q: Does trouble symptom persist?**YES :** Replace engine-A/T-ECU.**NO :** Check end.

Code No. P0335: Crank Angle Sensor System

Crank angle sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the crank angle sensor (terminal No. 1) from the engine control relay (terminal No. 1) and is earthed to the engine-A/T-ECU (terminal No. 88) from the crank angle sensor (terminal No. 3).
- A power voltage of 5 V is applied to the crank angle sensor output terminal (terminal No. 2) from the engine-A/T-ECU (terminal No. 70).

FUNCTION

- The crank angle sensor detects the crank angle (position) and inputs a pulse signal to the engine-A/T-ECU.
- In response to the signal, the engine-A/T-ECU controls the injector, etc.

TROUBLE JUDGMENT**Check Condition**

- While engine is cranking.

Judgment Criterion

- Crank angle sensor output voltage has not been changed (no pulse signal has been input) for 2 seconds.

PROBABLE CAUSES

- Failed crank angle sensor
- Open/short circuit in crank angle sensor circuit or loose connector contact
- Failed engine-A/T-ECU


DIAGNOSIS PROCEDURE**STEP 1. M.U.T.-III data list**

- Refer to Data List Reference Table [P.13C-313](#).
 - Item 22: Crank angle sensor

Q: Is the check result normal?


YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-121 crank angle sensor intermediate connector**Q: Is the check result normal?**

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform voltage measurement at B-121 crank angle sensor intermediate connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 2 and earth.



OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Go to Step 4 .

STEP 4. Perform voltage measurement at C-112 engine-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Disconnect B-121 crank angle sensor intermediate connector.
- Ignition switch: ON
- Voltage between terminal No. 70 and earth.



OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Go to Step 6 .

STEP 5. Connector check: C-112 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Check and repair harness between B-121 (terminal No. 2) crank angle sensor intermediate connector and C-112 (terminal No. 70) engine-A/T-ECU connector.

- Check output line for open circuit.

NO : Repair or replace.

STEP 6. Connector check: C-112 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Check harness between B-121 (terminal No. 2) crank angle sensor intermediate connector and C-112 (terminal No. 70) engine-A/T-ECU connector.



- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 22: Crank angle sensor

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 9. Perform voltage measurement at B-121 crank angle sensor intermediate connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Go to Step 10 .

STEP 10. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-121 (terminal No. 1) crank angle sensor intermediate connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 11. Perform resistance measurement at B-121 crank angle sensor intermediate connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 3 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Go to Step 12 .

STEP 12. Connector check: C-112 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 13 .

NO : Repair or replace.

STEP 13. Check harness between B-121 (terminal No. 3) crank angle sensor intermediate connector and C-112 (terminal No. 88) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.


- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 14. Perform output wave pattern measurement at B-121 crank angle sensor intermediate connector (Using an oscilloscope).



- Use special tool test harness (MB991658) to connect connector, and measure at pick-up harness.
- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 2 and earth.


OK: Waveforms should be displayed on Inspection procedure using an oscilloscope (Refer to P.13C-329), its maximum value should be 4.8 V or more, and its minimum value should be 0.6 V or less with no noise in waveform.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 15 .

STEP 15. Connector check: B-15X engine control relay connector





Q: Is the check result normal?

YES : Go to Step 16 .

NO : Repair or replace.

STEP 16. Check harness between B-121 (terminal No. 1) crank angle sensor intermediate connector and B-15X (terminal No. 1) engine control relay connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.


- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 17 .

NO : Repair.

STEP 17. Connector check: C-112 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 18 .

NO : Repair or replace.

STEP 18. Check harness between B-121 (terminal No. 2) crank angle sensor intermediate connector and C-112 (terminal No. 70) engine-A/T-ECU connector.





- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 19 .

NO : Repair.

STEP 19. Check harness between B-121 (terminal No. 3) crank angle sensor intermediate connector and C-112 (terminal No. 88) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.


- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 20 .

NO : Repair.

STEP 20. Connector check: B-121-1 crank angle sensor connector





Q: Is the check result normal?

YES : Go to Step 21 .

NO : Repair or replace.

STEP 21. Check harness between B-121 crank angle sensor intermediate connector and B-121-1 crank angle sensor connector.



- Check power supply line open/short circuit and damage.
- Check output line for open/short circuit and damage.
- Check earthing line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 22 .

NO : Replace the timing belt cover.

STEP 22. Check the crankshaft sensing blade.

Q: Is the check result normal?

YES : Go to Step 23 .

NO : Replace the crankshaft sensing blade.

STEP 23: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 22: Crank angle sensor


Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace crank angle sensor.

Code No. P0340: Camshaft Position Sensor System

Camshaft position sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the camshaft position sensor (terminal No. 3) from the engine control relay (terminal No. 1) and is earthed to the engine-A/T-ECU (terminal No. 88) from the camshaft position sensor (terminal No. 1).
- A power voltage of 5 V is applied to the camshaft position sensor output terminal (terminal No. 2) from the engine-A/T-ECU (terminal No. 71).

FUNCTION

- The camshaft position sensor detects the top dead center on the compression stroke of the No. 1 cylinder and inputs a pulse signal to the engine-A/T-ECU.

TROUBLE JUDGMENT**Check Condition**


- Engine speed is 50 r/min or higher.

Judgment Criterion

- Camshaft position sensor output voltage has not been changed (no pulse signal is has been input) for 2 seconds.

PROBABLE CAUSES


- Failed camshaft position sensor
- Open/short circuit in camshaft position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Connector check: B-114 camshaft position sensor connector**

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform voltage measurement at B-114 camshaft position sensor connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Go to Step 3 .

STEP 3. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-114 (terminal No. 3) camshaft position sensor connector and B-15X (terminal No. 1) engine control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 4. Perform voltage measurement at B-114 camshaft position sensor connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 2 and earth.

OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 5 .

STEP 5. Perform voltage measurement at C-112 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Disconnect B-114 camshaft position sensor connector.
- Ignition switch: ON
- Voltage between terminal No. 71 and earth.

OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Go to Step 7 .

STEP 6. Connector check: C-112 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Check and repair harness between B-114 (terminal No. 2) camshaft position sensor connector and C-112 (terminal No. 71) engine-A/T-ECU connector.

- Check output line for open circuit.



NO : Repair or replace.

STEP 7. Connector check: C-112 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between B-114 (terminal No. 2) camshaft position sensor connector and C-112 (terminal No. 71) engine-A/T-ECU connector.



- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.


STEP 9. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 10. Perform resistance measurement at B-114 camshaft position sensor connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 1 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Go to Step 11 .

STEP 11. Connector check: C-112 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair or replace.

STEP 12. Check harness between B-114 (terminal No. 1) camshaft position sensor connector and C-112 (terminal No. 88) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.


- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 13. Perform output wave pattern measurement at B-114 camshaft position sensor connector (Using an oscilloscope).



- Use special tool test harness (MB991709) to connect connector, and measure at pick-up harness.
- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 2 and earth.


OK: Waveforms should be displayed on Inspection procedure using an oscilloscope (Refer to [P.13C-329](#)), its maximum value should be 4.8 V or more, and its minimum value should be 0.6 V or less with no noise in waveform.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Go to Step 14 .

STEP 14. Connector check: B-15X engine control relay connector.





Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair or replace.

STEP 15. Check harness between B-114 (terminal No. 3) camshaft position sensor connector and B-15X (terminal No. 1) engine control relay connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.


- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Repair.

STEP 16. Connector check: C-112 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 17 .

NO : Repair or replace.

STEP 17. Check harness between B-114 (terminal No. 2) camshaft position sensor connector and C-112 (terminal No. 71) engine-A/T-ECU connector.





- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 18 .

NO : Repair.

STEP 18. Check harness between B-114 (terminal No. 1) camshaft position sensor connector and C-112 (terminal No. 88) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 19 .

NO : Repair.

STEP 19. Check camshaft position sensing cylinder.

Q: Is the check result normal?

YES : Go to Step 20 .

NO : Replace camshaft position sensing cylinder.

STEP 20. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace camshaft position sensor.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0403: Exhaust Gas Recirculation Control System

EGR valve circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the EGR valve (terminal No. 2 and No. 5) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU (terminal No. 3, No. 12, No. 19 and No. 26) makes the power transistor in the unit be in "ON", and that makes currents go on the EGR valve (terminal No. 1, No. 3, No. 4 and No. 6).

FUNCTION

- Based on the signal from engine-A/T-ECU, the EGR valve (stepper motor) controls the EGR rate.

TROUBLE JUDGMENT**Check Condition**


- Battery positive voltage is 10.3 V or higher.

Judgment Criterion


- The EGR valve motor coil surge voltage (battery positive voltage +2 V) is not detected for 3 seconds.

PROBABLE CAUSES

- Failed EGR valve
- Open/short circuit in EGR valve circuit or loose connector contact
- Failed engine-A/T-ECU




DIAGNOSIS PROCEDURE**STEP 1. Connector check: B-103 EGR valve connector****Q: Is the check result normal?****YES :** Go to Step 2 .**NO :** Repair or replace.**STEP 2. Check EGR valve itself.**

- Check EGR control solenoid valve itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (stepper motor) Check P.17-44.

Q: Is the check result normal?**YES :** Go to Step 3 .**NO :** Replace EGR valve (stepper motor).**STEP 3. Perform voltage measurement at B-103 EGR valve connector.**

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 2, No. 5 and earth.



OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Go to Step 4 .

STEP 6. Connector check: C-110 engine-A/T-ECU connector**STEP 7. Connector check: C-110 engine-A/T-ECU connector****Q: Is the check result normal?****YES :** Go to Step 8 .**NO :** Repair or replace.**Q: Is the check result normal?****YES :** Check and repair harness between B-103 EGR valve and C-110 engine-A/T-ECU connector



- Check harness between B-103 (terminal No. 1) EGR valve connector and C-110 (terminal No. 3) engine-A/T-ECU connector
 - Check harness between B-103 (terminal No. 3) EGR valve connector and C-110 (terminal No. 12) engine-A/T-ECU connector
 - Check harness between B-103 (terminal No. 4) EGR valve connector and C-110 (terminal No. 19) engine-A/T-ECU connector
 - Check harness between B-103 (terminal No. 6) EGR valve connector and C-110 (terminal No. 26) engine-A/T-ECU connector
- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 8. Check harness between B-103 EGR valve connector and C-110 engine-A/T-ECU connector.



STEP 9. Check harness between B-103 (terminal No. 2, No. 5) EGR valve connector and B-15X (terminal No. 1) engine control relay connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Repair.

- Check harness between B-103 (terminal No. 1) EGR valve connector and C-110 (terminal No. 3) engine-A/T-ECU connector
 - Check harness between B-103 (terminal No. 3) EGR valve connector and C-110 (terminal No. 12) engine-A/T-ECU connector
 - Check harness between B-103 (terminal No. 4) EGR valve connector and C-110 (terminal No. 19) engine-A/T-ECU connector
 - Check harness between B-103 (terminal No. 6) EGR valve connector and C-110 (terminal No. 26) engine-A/T-ECU connector
- Check output line for damage.

Q: Are the check results normal?

YES : Go to Step 9 .

NO : Repair.

Code No. P0421: Warm Up Catalyst Malfunction (cylinder 1, 4)

FUNCTION

- The signal from the cylinder 1, 4 oxygen sensor (rear) differs from the cylinder 1, 4 oxygen sensor (front). That is because the catalytic converter purifies exhaust gas. When the catalytic converter has deteriorated, the signal from the cylinder 1, 4 oxygen sensor (front) becomes similar to the cylinder 1, 4 oxygen sensor (rear).
- The engine-A/T-ECU compares the output of the cylinder 1, 4 oxygen sensor signals (front and rear).

TROUBLE JUDGMENT**Check Conditions**

- Engine speed is 3,000 r/min or lower.
- The accelerator pedal is open.
- Air flow sensor output is 8 gm/s or higher.
- 3 seconds or more elapsed after the above mentioned conditions were satisfied.
- Intake air temperature is -10° C or higher after the engine is started.
- Barometric pressure is 76 kPa or higher.
- Under the closed loop air/fuel ratio control.
- Vehicle speed is 1.5 km/h or higher.
- For 10 seconds per cycle, the engine-A/T-ECU monitors 7 cycles of this condition during the drive cycle.
- Short-term fuel trim is between -25 % or higher and +25 % or lower.
- The cumulative air flow sensor output is 2,931 g or higher.

Judgment Criterion

- The cylinder 1, 4 oxygen sensor (rear) signal frequency divided by cylinder 1, 4 oxygen sensor (front) signal frequency is 0.8 or more.

PROBABLE CAUSES

- Catalytic converter deteriorated
- Failed cylinder 1, 4 oxygen sensor (front)
- Failed cylinder 1, 4 oxygen sensor (rear)
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check for leakage of exhaust emission from exhaust manifold.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair.

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 11: Cylinder 1, 4 oxygen sensor (front)
 - b. Item 59: Cylinder 1, 4 oxygen sensor (rear)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. M.U.T.-III data list

- Item 11: Cylinder 1, 4 oxygen sensor (front)
OK: 0 –0.4 and 0.6 –1.0 volt should alternate 15 times or more within 10 seconds (engine speed at 2,000 r/min).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace the cylinder 1, 4 oxygen sensor (front).

STEP 4. Replace the cylinder 1, 4 oxygen sensor (rear).

- After replacing the cylinder 1, 4 oxygen sensor (rear), re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Go to Step 5 .

STEP 5. Replace the catalytic converter (cylinder 1, 4).

- After replacing the catalytic converter (cylinder 1, 4), re-check the trouble symptoms.

Q: Is the check result normal?

YES : Replacing engine-A/T-ECU.

NO : Check end.

Code No. P0431: Warm Up Catalyst Malfunction (Cylinder 2, 3)

FUNCTION

- The signal from the cylinder 2, 3 oxygen sensor (rear) differs from the cylinder 2, 3 oxygen sensor (front). That is because the catalytic converter purifies exhaust gas. When the catalytic converter has deteriorated, the signal from the cylinder 2, 3 oxygen sensor (front) becomes similar to the cylinder 2, 3 oxygen sensor (rear).
- The engine-A/T-ECU compares the output of the cylinder 2, 3 oxygen sensor signals (front and rear).

TROUBLE JUDGMENT

Check Conditions

- Engine speed is 3,000 r/min or lower.
- The accelerator pedal is open.
- Air flow sensor output is 8 gm/s or higher.
- 3 seconds or more elapsed after the above mentioned conditions were satisfied.
- Intake air temperature is -10° C or higher after the engine is started.
- Barometric pressure is 76 kPa or higher.
- Under the closed loop air/fuel ratio control.
- Vehicle speed is 1.5 km/h or higher.
- For 10 seconds per cycle, the engine-A/T-ECU monitors 7 cycles of this condition during the drive cycle.
- Short-term fuel trim is between -25 % or higher and +25 % or lower.
- The cumulative air flow sensor output is 2,931 g or higher.

Judgment Criterion

- The cylinder 2, 3 oxygen sensor (rear) signal frequency divided by cylinder 2, 3 oxygen sensor (front) signal frequency is 0.8 or more.

PROBABLE CAUSES

- Catalytic converter deteriorated
- Failed cylinder 2, 3 oxygen sensor (front)
- Failed cylinder 2, 3 oxygen sensor (rear)
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check for leakage of exhaust emission from exhaust manifold.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair.

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 39: Cylinder 2, 3 oxygen sensor (front)
 - b. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. M.U.T.-III data list

- Item 39: Cylinder 2, 3 oxygen sensor (front)
OK: 0 –0.4 and 0.6 –1.0 volt should alternate 15 times or more within 10 seconds (engine speed at 2,000 r/min).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace the cylinder 2, 3 oxygen sensor (front).

STEP 4. Replace the cylinder 2, 3 oxygen sensor (rear).

- After replacing the cylinder 2, 3 oxygen sensor (rear), re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Go to Step 5 .

STEP 5. Replace the catalytic converter (cylinder 2, 3).

- After replacing the catalytic converter (cylinder 2, 3), re-check the trouble symptoms.


Q: Is the check result normal?

YES : Replacing engine-A/T-ECU.

NO : Check end.

Code No. P0443: Purge Control Solenoid Valve System

Purge control solenoid valve circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305564AD

OPERATION

- Power is supplied to the purge control solenoid valve (terminal No. 2) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU (terminal No. 23) makes the power transistor in the unit be in ON position, and that makes currents go on the purge control solenoid valve (terminal No. 1).

FUNCTION

- In response to a signal from the engine-A/T-ECU, the purge control solenoid valve controls the flow rate of the purge air to be introduced into the surge tank.

TROUBLE JUDGMENT

Check Conditions

- Ignition switch is in ON position.
- Battery positive voltage is 10 V or higher.

Judgment Criterion

- The surge voltage (system voltage +2 V) of solenoid coil is not detected when the purge control solenoid valve is turned in OFF position from ON.

PROBABLE CAUSES

- Failed purge control solenoid valve
- Open/short circuit in purge control solenoid value circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III actuator test

- Item 08: Purge control solenoid valve


OK: Operating sound can be heard and the valve vibrates

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: B-01 purge control solenoid valve connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3: Perform resistance measurement at B-01 purge control solenoid valve connector.



- Disconnect connector, and measure at solenoid valve side.
- Resistance between terminal No. 1 and No. 2.


OK: 30 –34 Ω (at 20° C)

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace purge control solenoid valve.

STEP 4. Perform voltage measurement at B-01 purge control solenoid valve connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 2 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .


NO : Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-01 (terminal No. 2) purge control solenoid valve connector and B-15X (terminal No. 1) engine control relay connector.

- Check power line for open/short circuit.

NO : Repair or replace.

STEP 6. Perform voltage measurement at C-110 engine-A/T-ECU connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 23 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 7 .

STEP 7. Connector check: C-110 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Check and repair harness between B-01 (terminal No. 1) purge control solenoid valve connector and C-110 (terminal No. 23) engine-A/T-ECU connector.

- Check output line for open/short circuit.

NO : Repair or replace.

STEP 8. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check harness between B-01 (terminal No. 1) purge control solenoid valve connector and C-110 (terminal No. 23) engine-A/T-ECU connector.





- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Check harness between B-01 (terminal No. 2) purge control solenoid valve connector and B-15X (terminal No. 1) engine control relay connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power line for damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. M.U.T.-III actuator test

- Item 08: purge control solenoid valve

OK: Operating sound can be heard and the valve vibrates

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

Code No. P0500: Vehicle Speed Signal System

FUNCTION

- Receives the signal from the secondary speed sensor used for the A/T control and converts it to the vehicle speed signal, and then inputs it to the engine control system and the speedometer.

TROUBLE JUDGMENT

Check Conditions

- After 2 seconds pass from when the engine has completed the starting.
- The engine rpm is 2500 –4000 r/min.
- Under the high load operation.

Judgment Criterion

- The sensor output voltage does not vary for 4 seconds. (The pulse signal is not input.)

PROBABLE CAUSES

- Open circuit, short or damage in the secondary speed sensor circuits or connection failure of the connector
- Failed secondary speed sensor
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III other system diagnosis codes

Q: Is the diagnosis code output for A/T system?

YES : A/T system check (Refer to GROUP 23-DIAGNOSIS CODE CLASSIFIED TABLE [P.23A-17](#).)

NO : Go to STEP 2.

STEP 2. M.U.T.-III diagnosis code

- Reconfirmation of the diagnosis code.

Q: Is the diagnosis code output?

YES : Replacement of Engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0505: Idle Speed Control (ISC) System

FUNCTION

- The amount of air taken in during idling is regulated by the opening and closing of the throttle valve.
- The engine-A/T-ECU checks the difference between the actual engine speed and the target engine speed.

TROUBLE JUDGMENT**Check Conditions**

- The vehicle speed has reached 1.5 km/h or more at least once.
- During the closed-loop idle speed control.

Judgment Criterion

- The actual idle speed is higher than the target idle speed by 300 r/min or more for 10 seconds.

Check Conditions

- The vehicle speed has reached 1.5 km/h or more at least once.
- During the closed-loop idle speed control.
- The highest ambient temperature at the last drive is 45° C or less.
- The engine coolant temperature is approximately 77° C or higher.
- The battery voltage is 10 V or more.
- The intake air temperature is -10° C or higher.

Judgment Criterion

- The actual idle speed is higher than the target idle speed by 200 r/min or more for 10 seconds.

Check Conditions

- During the closed-loop idle speed control
- The engine coolant temperature is approximately 77° C or higher.
- The battery voltage is 10 V or more.
- The power steering switch is in OFF position.
- The charging efficiency is 40 % or less.

- The intake air temperature is -10° C or higher.

Judgment Criterion

- The actual idle speed is lower than the target idle speed by 100 r/min or more for 10 seconds.

PROBABLE CAUSES

- Throttle valve area is dirty.
- Intake system vacuum leak.
- Failed engine-A/T-ECU

STEP 1: M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#).)

NO : Go to Step 2 .

STEP 2: Check throttle body (throttle valve portion) for contamination.**Q: Is the check result normal?**

YES : Go to Step 3 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 3. Check air intake from intake hose and inlet manifold.**Q: Is the check result normal?**

YES : Go to Step 4 .

NO : Repair.


STEP 4. Check the trouble symptoms.**Q: Does trouble symptom persist?**

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0513: Immobilizer Malfunction

Immobilizer-ECU circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305566AC

OPERATION

- The signals are sent and received between engine-A/T-ECU (terminal No. 65) and immobilizer-ECU (terminal No. 7).

FUNCTION

- Engine-A/T-ECU sends or receives the control signals to or from immobilizer-ECU to certify the ignition key.

NOTE:

- If the registered ignition keys are close each other when starting the engine, radio interference may cause this code to be displayed.
- This code may be displayed when registering the key encrypted code.

TROUBLE JUDGMENT**Check Condition**

- Ignition switch is in "ON" position.

Judgment Criterion



- When the communication error between engine-A/T-ECU and the immobilizer-ECU continues for 2 seconds or more.

PROBABLE CAUSES

- Open/short circuit in immobilizer system circuit or loose connector contact
- Failed immobilizer-ECU
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: C-308 immobilizer-ECU connector and C-112 engine-A/T-ECU connector.





Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Check harness between C-308 (terminal No. 7) immobilizer-ECU connector and C-112 (terminal No. 65) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-17, and repair if necessary.

- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair.

STEP 3. Check the trouble symptoms.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 4. After replacing the immobilizer-ECU, re-check the trouble symptoms.


Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Check end.

Code No. P0551: Power Steering Fluid Pressure Sensor System

Power steering fluid pressure sensor circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305567 AC

CONDITION

- A power voltage of 5 V is applied to power steering fluid pressure sensor (terminal No. 3) from the engine-A/T-ECU (terminal No. 97).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 96) from the power steering fluid pressure sensor (terminal No. 1).

- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 84) from power steering fluid pressure sensor output terminal (terminal No. 2).

FUNCTION

- Detect the power steering oil pump load caused by the steering and input it into engine-A/T-ECU. Engine-A/T-ECU determines the power steering oil pump load through power steering fluid pressure sensor to perform the idle up control depending on the load.

TROUBLE JUDGMENT

Check Condition

- All the time after the microcomputer start.

Judgment Criteria

- Power steering fluid pressure sensor output voltage has continued to be 4.8 V or more for 5 seconds.
- or
- Power steering fluid pressure sensor output voltage has continued to be 0.2 V or less for 5 seconds.

PROBABLE CAUSES

- Failed power steering fluid pressure sensor
- Failed power steering
- Open/short circuit in power steering fluid pressure sensor circuit or loose contact.
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#)
 - Item B4: Power steering fluid pressure sensor

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#))

NO : Go to Step 2 .


STEP 2. Check for stationary steering effort (Refer to [P.37-11](#)).

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair.

STEP 3. Connector check: B-20 power steering fluid pressure sensor connector




Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

STEP 4. Perform voltage measurement at B-20 power steering fluid pressure sensor connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.


OK: 4.9 –5.1V

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 5 .

STEP 5. Perform voltage measurement at C-113 engine-A/T-ECU connector.





- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No.97 and earth.

OK: 4.9 –5.1V

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Go to Step 7


STEP 6. Connector check: C-113 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Check intermediate connector B-17, and repair if necessary. If intermediate connector is normal, check and repair harness between B-20 (terminal No. 3) power steering pressure sensor connector and C-113 (terminal No. 97) engine-A/T-ECU connector.

- Check power supply line for damage.



NO : Repair or replace.

STEP 7. Connector check: C-113 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between B-20 (terminal No. 3) power steering fluid pressure sensor connector and C-113 (terminal No. 97) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.

- Check power supply line for short circuit.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#)
 - Item B4: Power steering fluid pressure sensor

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 10. Perform resistance measurement at B-20 power steering fluid pressure sensor




- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 1 and earth.
OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Go to Step 11.

STEP 11. Connector check: C-113 engine-A/T-ECU connector



Q: Is the check result normal?



YES : Go to Step 12 .

NO : Repair or replace.

STEP 12. Check harness between B-20 (terminal No. 1) power steering fluid pressure sensor connector and C-113 (terminal No. 96) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector B-17 and C-116, and repair if necessary.


- Check earthing line for open circuit and damage.



Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 13. Perform voltage measurement at C-112 engine-A/T-ECU connector.

- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 84 and earth.


OK: 1V or less (Steering wheel: Not operated)

Voltage rises (Steering wheel: Operated)

Q: Is the check result normal?

YES : Go to Step 17 .



NO : Go to Step 14 .

STEP 14. Connector check: C-112 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair or replace.

STEP 15. Check harness between B-20 (terminal No. 2) (terminal No. 1) power steering fluid pressure sensor connector and C-112 (terminal No. 84) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.



- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Repair.

STEP 16. Check harness between B-20 (terminal No. 3) power steering fluid pressure sensor connector and C-113 (terminal No. 97) engine-A/T-ECU connector.




NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

- YES :** Replace power steering pressure sensor.
NO : Repair.

STEP 17. Connector check: C-112 engine-A/T-ECU connector



Q: Is the check result normal?

- YES :** Go to Step 9 .
NO : Repair or replace.

Code No. P0603: EEP ROM Malfunction

FUNCTION

- To check whether the information such as the idle learned value and so on is stored in the memory of engine-A/T-ECU.

TROUBLE JUDGMENT

Check Condition

- Ignition switch is in ON position

Judgement Criterion

- The latest learned data that was flashed while the ignition switch was in OFF position are not stored correctly

PROBABLE CAUSE

- Failed the engine-A/T-ECU

DIAGNOSIS

STEP 1. Reconfirmation of diagnosis codes.

Q: Is the check result normal?

- YES :** Replace engine-A/T-ECU.
NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0606: Engine-A/T-ECU Main Processor Malfunction**FUNCTION**

- System LSI checks the engine-A/T-ECU for abnormal conditions.

TROUBLE JUDGMENT**Check Condition**


- Ignition switch is ON position.

Judgement Criterion

- No surveillance pulse signals is input for 0.5 second.

PROBABLE CAUSE

- Failed engine-A/T-ECU

DIAGNOSIS**STEP 1. Check the trouble symptoms.****Q: Does trouble symptom persist?****YES** : Replace engine-A/T-ECU.**NO** : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).**Code No. P0622: Alternator FR Terminal System****Alternator circuit**

Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- The energized state of the alternator field coil is inputted from the alternator (terminal No. 4) to the engine-A/T-ECU (terminal No. 86).

FUNCTION

- A signal of the power supply duty ratio for the alternator field coil is inputted to the engine-A/T-ECU.
- In response to the signal, the engine-A/T-ECU detects the alternator output current and controls the idling speed according to the output current (electric load).

TROUBLE JUDGMENT

Check Condition

- Engine speed is 50 r/min or higher.

Judgment Criterion


- Input voltage from the alternator FR terminal is system voltage for 20 seconds.

PROBABLE CAUSES

- Failed alternator
- Open/short circuit in alternator FR terminal circuit or loose connector
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-119 alternator connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform voltage measurement at B-119 alternator connector.






- Disconnect connector, and measure at male connector side.
- Ignition switch: ON
- Voltage between terminal No. 4 and earth.

OK: System voltage

Q: Is the check result normal?


YES : Go to Step 6 .

NO : Go to Step 3 .

STEP 3. Connector check: C-112 engine-A/T-ECU connector.**Q: Is the check result normal?****YES :** Go to Step 4 .**NO :** Repair or replace.**STEP 4. Check harness between B-119 (terminal No. 4) alternator connector and C-112 (terminal No. 86) engine-A/T-ECU connector.**

NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.

- Check output line for open/short circuit.



Q: Is the check result normal?**YES :** Go to Step 5 .**NO :** Repair.**STEP 5. Check the trouble symptoms.****Q: Does trouble symptom persist?****YES :** Replace engine-A/T-ECU.**NO :** Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).**STEP 6. Perform voltage measurement at C-112 engine-A/T-ECU connector.**

- Measure engine-A/T-ECU terminal voltage.
- Engine: Idle after warm-up
- Transmission: P range
- Radiator fan: Inactive
- Voltage between terminal No. 86 and earth.

OK: Switching the headlamps to ON from OFF causes the voltage to fall.

Q: Is the check result normal?**YES :** Go to Step 7 .**NO :** Go to Step 5 .

STEP 7. Check harness between B-119 (terminal No. 4) alternator connector and C-112 (terminal No. 86) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.

- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check trouble symptom.

Q: Same symptoms regenerated?

YES : Replace alternator.

NO : Intermittent malfunction (Refer to Group 00

–How to Use troubleshooting/Inspection

Service Points [P.00-5](#)).

Code No. P0638: Throttle Valve Control Servo Circuit Range/Performance Problem**OPERATION**

- Refer to P0657 –Throttle valve control servo circuit [P.13C-191](#).
- Refer to P2101 –Throttle valve control servo circuit [P.13C-208](#).

FUNCTION

- Engine-A/T-ECU checks the electronic controlled throttle system for abnormal conditions.

TROUBLE JUDGMENT**Check Conditions**

- Battery positive voltage is 8.3 V or higher.
- Throttle position sensor (main) output voltage is 0.35 –4.8 V.
- Drop of throttle position sensor (main) output voltage per 100 milliseconds is 0.04 V or more.

Judgement Criterion

- Throttle position sensor (main) output voltage has continued to be above 0.5 V higher than the target throttle position sensor (main) voltage for 0.5 second.

Check Conditions

- Battery positive voltage is 8.3 V or higher.
- Throttle position sensor (main) output voltage is 0.35 –4.8 V.

Judgement Criterion

- Difference between throttle position sensor (main) output voltage and target throttle position sensor (main) voltage is 1 V or higher for 4 seconds.

PROBALE CAUSES

- Failed throttle valve return spring.
- Failed throttle valve operation.
- Failed throttle valve control servo.
- Open/short circuit in throttle valve control servo connector contact.
- Failed engine-A/T-ECU.


DIAGNOSIS**STEP 1. M.U.T.-III data list**

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 9A: Throttle position sensor (main) mid opening learning value

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Replace throttle body assembly.

STEP 2. Connector check: B-12X throttle valve control servo relay connector**Q: Is the check result normal?**

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check throttle valve control servo relay itself.


- Check throttle valve control servo relay (Refer to [P.13C-345](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair.

STEP 4. Perform voltage measurement at B-12X throttle valve control servo relay connector.



- Remove relay, and measure at relay box side.
- Voltage between terminal No. 4 and earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 5 .

NO : Check and repair harness between B-12X (terminal No. 4) throttle valve control servo relay connector and battery.

- Check power supply line for open/short circuit.

STEP 5. Perform voltage measurement at B-12X throttle valve control servo relay connector.



- Remove relay, and measure at relay box side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 6 .

STEP 6. Connector check: B-15X engine control relay connector





Q: Is the check result normal?

YES : Check and repair harness between B-15X (terminal No. 1) engine control relay connector and B-12X (terminal No. 3) throttle valve control servo relay connector.

- Check power supply line for open/short circuit.


NO : Repair or replace.

STEP 7. Perform voltage measurement at C-110 engine-A/T-ECU connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 15 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 8 .**NO :** Check and repair harness between B-12X (terminal No. 2) throttle valve control servo relay connector and C-110 (terminal No. 15) engine-A/T-ECU connector.



- Check earthing line for open/short circuit.

STEP 8. Perform voltage measurement at C-114 engine-A/T-ECU connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 132 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 11 .**NO :** Go to Step 9 .

STEP 9. Check harness between B-12X (terminal No. 1) throttle valve control servo relay connector and C-114 (terminal No. 132) engine-A/T-ECU connector.






- Check output line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Check harness between B-15X (terminal No. 1) engine control relay connector and B-12X (terminal No. 3) throttle valve control servo relay connector.




- Check output line for damage.

Q: Is the check result normal?



YES : Check and repair harness between B-12X (terminal No. 2) throttle valve control servo relay connector and C-110 (terminal No. 15) engine-A/T-ECU connector.

- Check earthing line for open/short circuit.



NO : Repair.

STEP 11. Connector check: C-114 and C-110 engine-A/T-ECU connector**Q: Is the check result normal?****YES :** Go to Step 12 .**NO :** Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).**STEP 12. Check the throttle valve control servo itself.**

- Check the throttle valve control servo control motor itself (Refer to [P.13C-345](#))

Q: Is the check result normal?**YES :** Go to Step 13 .**NO :** Replace electronic-controlled throttle valve.**STEP 13. Connector check: B-06 electronic-controlled throttle valve connector and C-114 engine-A/T-ECU connector****Q: Is the check result normal?****YES :** Go to Step 14 .**NO :** Repair or replace.

STEP 14. Check harness between B-06 (terminal No. 1) electronic-controlled throttle valve connector and C-114 (terminal No. 133) engine-A/T-ECU connector.





- Check output line for short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair.

STEP 15. Check harness between B-06 (terminal No. 2) electronic-controlled throttle valve connector and C-114 (terminal No. 141) engine-A/T-ECU connector.



- Check output line for short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Repair.

STEP 16. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0642: Throttle Position Sensor Power Supply

FUNCTION

- Engine-A/T-ECU checks the throttle position sensor power voltage for abnormal conditions.

TROUBLE JUDGMENT**Check Condition**

- Battery positive voltage is 6.3 V or higher.

Judgement Criterion

- Throttle position sensor power voltage is 4.1 V or less for 0.5 second.

PROBALE CAUSE


- Failed engine-A/T-ECU

DIAGNOSIS

STEP 1. Check the trouble symptoms.**Q: Does trouble symptom persist?****YES** : Replace engine-A/T-ECU.**NO** : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P0657: Throttle Valve Control Servo Relay Circuit Malfunction

Throttle valve control servo relay circuit



AK305568AD

OPERATION

- Battery voltage is applied to the throttle valve control servo relay terminal (terminal No. 4).
- Battery voltage is applied to the throttle valve control servo relay terminal (terminal No. 3) from the engine control relay (terminal No. 1).
- Engine-A/T-ECU (terminal No. 15) applies current to the throttle valve control servo relay coil by turning ON the power transistor in the unit in order to turn the relay ON.
- When the throttle valve control servo relay turns ON, battery voltage is supplied by the throttle valve control servo relay (terminal No. 1) to the engine-A/T-ECU (terminal No. 132).

FUNCTION

- When the ignition switch ON signal is input into the engine-A/T-ECU, the engine-A/T-ECU turns ON the Throttle valve control servo.

TROUBLE JUDGMENT**Check Condition**


- Ignition switch is in ON position.

Judgement Criterion

- The power line voltage of the electronic controlled throttle system is 4.0 V or less for 1 second.

PROBABLE CAUSES

- Failed throttle valve return spring
- Open/short circuit in throttle valve control servo circuit or loose connector contact.
- Failed engine-A/T-ECU

DIAGNOSIS**STEP 1. Connector check: B-12X throttle valve control servo relay connector****Q: Is the check result normal?**

YES : Go to Step 2 .

NO : Repair or replace.


STEP 2. Check throttle valve control servo relay itself.

- Check throttle valve control servo relay itself (Refer to P.13C-340).

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair.

STEP 3. Perform voltage measurement at B-12X throttle valve control servo relay connector.


- Remove relay, and measure at relay box side.
- Voltage between terminal No. 4 and earth.

OK: System voltage**Q: Is the check result normal?**

YES : Go to Step 4 .

NO : Check and repair harness between B-12X (terminal No. 4) throttle valve control servo relay connector and battery.

- Check power supply line for open/short circuit.

STEP 4. Perform voltage measurement at B-12X throttle valve control servo relay connector.



- Remove relay, and measure at relay box side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.

OK: System voltage**Q: Is the check result normal?**

YES : Go to Step 6 .

NO : Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector





Q: Is the check result normal?

YES : Check and repair harness between B-15X (terminal No. 1) engine control relay connector and B-12X (terminal No. 3) throttle valve control servo relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 6. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 15 and earth.

OK: System voltage


Q: Is the check result normal?

YES : Check and repair harness between B-12X (terminal No. 2) throttle valve control servo relay connector and C-110 (terminal No. 15) engine-A/T-ECU connector.

- Check earthing line for open/short circuit.

NO : Go to Step 7 .

STEP 7. Perform voltage measurement at C-114 engine-A/T-ECU connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 132 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 8 .

STEP 8. Check harness between B-12X (terminal No. 1) throttle valve control servo relay connector and C-114 (terminal No. 132) engine-A/T-ECU connector.






- Check output line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check harness between B-15X (terminal No. 1) engine control relay connector and B-12X (terminal No. 3) throttle valve control servo relay connector.



- Check output line for damage.


Q: Is the check result normal?

YES : Check and repair harness between B-12X (terminal No. 2) throttle valve control servo relay connector and C-110 (terminal No. 15) engine-A/T-ECU connector.

- Check earthing line for open/short circuit.

NO : Repair.

STEP 10. Connector check: C-114 and C-110 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair or replace.

STEP 11. Check and repair harness between B-12X (terminal No. 4) throttle valve control servo relay connector and battery.





- Check power supply line for damage.

Q: Is the harness connector in good condition?

YES : Go to Step 12 .

NO : Repair.

STEP 12. Check and repair harness between B-12X (terminal No. 1) throttle valve control servo relay connector and C-114 (terminal No. 132) engine-A/T-ECU connector.



- Check power supply line for damage.

Q: Is the harness connector in good condition?

YES : Go to Step 13 .

NO : Repair.

STEP 13. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P1021: Oil Control Valve Circuit

Oil control valve circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- Power is supplied to the oil control valve (terminal No. 1) from the engine control relay (terminal No. 1).
- The engine-A/T-ECU (terminal No. 95) makes the power transistor in the unit be in ON position, and that makes currents go on the oil control valve (terminal No. 2).

FUNCTION

- The oil control valve switches the cams to operate the MIVEC in the low-speed or high-speed mode in accordance with the signals from the engine-A/T-ECU.

TROUBLE JUDGMENT**Check Conditions**



- Ignition switch is "ON" position
- Battery positive voltage is higher than 10 V.
- MIVEC operating in the low-speed mode.

Judgment Criterion


- The engine-A/T-ECU terminal voltage of oil control valve circuit is less than 1.5 V for 2 seconds.

PROBABLE CAUSES

- Failed purge oil control valve
- Open/short circuit in oil control valve circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Connector check: B-07 oil control valve connector****Q: Is the check result normal?****YES :** Go to Step 2 .**NO :** Repair or replace.**STEP 2: Perform resistance measurement at B-07 oil control valve connector.**



- Disconnect connector, and measure at control valve side.
- Resistance between terminal No. 1 and No. 2.

OK: 6.9 –7.9 Ω (at 20° C)**Q: Is the check result normal?****YES :** Go to Step 3 .**NO :** Replace oil control valve.**STEP 3. Perform voltage measurement at B-07 oil control valve connector.**

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Go to Step 4 .

STEP 4. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connector C-116, and repair if necessary. If intermediate connector is normal, check and repair harness between B-07 (terminal No. 1) oil control valve connector and B-15X (terminal No. 1) engine control relay connector.

- Check power line for open/short circuit.

NO : Repair or replace.

STEP 5. Perform voltage measurement at C-113 engine-A/T-ECU connector.





- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 95 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 7 .


NO : Go to Step 6 .

STEP 6. Connector check: C-113 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Check and repair harness between B-07 (terminal No. 2) oil control valve connector and C-113 (terminal No. 95) engine-A/T-ECU connector.



- Check output line for open/short circuit.

NO : Repair or replace.

STEP 7. Connector check: C-113 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between B-07 (terminal No. 2) oil control valve connector and C-113 (terminal No. 95) engine-A/T-ECU connector.



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check harness between B-07 (terminal No. 1) oil control valve connector and B-15X (terminal No. 1) engine control relay connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P1602: Communication Malfunction (between Engine-A/T-ECU Main Processor and System LSI)

FUNCTION

- Engine-A/T-ECU checks the communication status for abnormal conditions.

TROUBLE JUDGMENT

Check Condition

- Ignition switch is ON position.

Judgement Criterion

- Engine-A/T-ECU detects an error in communication with the throttle actuator control module for 0.07 second.

PROBALE CAUSE

- Failed engine-A/T-ECU

DIAGNOSIS


STEP 1. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P1603: Battery Backup Circuit Malfunction



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305569AD

OPERATION

- Power is directly supplied to the engine-A/T-ECU (terminal No. 58) from the battery.

FUNCTION

- The engine-A/T-ECU checks the open circuit of battery backup line.

TROUBLE JUDGMENT**Check Conditions**

- After engine starting sequence is completed.

- Battery positive voltage is 10 V or higher.

Judgment Criterion

- Battery backup line voltage is 6 V or lower for 2 seconds.

PROBABLE CAUSES

- Open/short circuit in battery backup line circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code


- Temporarily place the ignition switch in "LOCK" (OFF) position, and 10 seconds after that, place it in "ON" position again.

Q: Is the diagnosis code P1603 set?

YES : Go to Step 2 .

NO : Intermittent malfunction (Refer to GROUP 00 –How to use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 2. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 58 and earth.

OK: System voltage

Q: Is the check result normal?


YES : Go to Step 3 .

NO : Check intermediate connector A-16, and repair if necessary. If intermediate connector is normal, check and repair harness between battery and C-111 (terminal No. 58) engine-A/T-ECU connector.

- Check power supply line for open/short circuit.

STEP 3. Check harness between battery and C-111 (terminal No. 58) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector A-16, and repair if necessary.




- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

STEP 4. Connector check: C-111 engine-A/T-ECU connector.



Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P2100: Throttle Valve Control Servo Circuit (open)

Throttle valve control servo circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305570AD

OPERATION

- Controls the current that is applied from the engine-A/T-ECU (terminals No. 133, No. 141) to the electronic-controlled throttle valve (terminals No. 1, No. 2).

FUNCTION

- Engine-A/T-ECU varies the direction and the amperage of the current that is applied to the throttle valve control servo in order to control the opening of the throttle valve.

TROUBLE JUDGMENT**Check Condition**

- Battery positive voltage is 8.3 V or higher.

Judgement Criterion


- Throttle actuator control motor current is 0.1 A or less for 0.72 second.

PROBABLE CAUSES

- Failed throttle valve control servo.
- Open/short circuit in throttle valve control servo circuit or lose connector contact.
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at B-06 electronic-controlled throttle valve connector.




- Disconnect connector, and measure at electronic-controlled throttle valve side.
- Resistance between terminal No. 1 and No. 2.
OK: 0.3 –100 k Ω (at 20 °C)

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace throttle body assembly.

STEP 3. Connector check: C-114 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

STEP 4. Perform resistance measurement at C-114 engine-A/T-ECU connector.




- Disconnect connector and measure at harness side.
- Resistance between terminal No. 144, No. 145 and earth.

OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .



NO : Go to Step 5 .

STEP 5. Connector check: C-115 earth connector

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.



STEP 6. Check harness between C-114 engine-A/T-ECU and C-115 earth connector.

- Check harness between C-114 (terminal No. 144) engine-A/T-ECU and C-115 (terminal No.3) earth connector.
- Check harness between C-114 (terminal No. 145) engine-A/T-ECU and C-115 (terminal No.4) earth connector.

Q: Are the check results normal?

YES : Go to Step 7 .

NO : Repair

STEP 7. Check harness between B-06 (terminal No. 1) electronic-controlled throttle valve connector and C-114 (terminal No. 133) engine-A/T-ECU connector.



- Check output line for short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check harness between B-06 (terminal No. 2) electronic-controlled throttle valve connector and C-114 (terminal No. 141) engine-A/T-ECU connector.



- Check output line for short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check the trouble symptoms.


Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P2101: Throttle Valve Control Servo Magneto Malfunction

Throttle valve control servo circuit



AK305730AD

OPERATION

- Controls the current that is applied from the engine-A/T-ECU (terminals No. 133, No. 141) to the electronic-controlled throttle valve (terminals No. 1, No. 2).

FUNCTION

- Engine-A/T-ECU check whether the throttle valve control servo magneto failed.

TROUBLE JUDGMENT**Check Condition**

- Battery positive voltage is 8.3 V or higher.

Judgement Criterion


- The coil temperature of the throttle actuator control motor is 180° C or higher for 0.8 second.

PROBABLE CAUSES

- Failed throttle valve control servo.
- Open/short circuit in throttle valve control servo circuit or lose connector contact.
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at B-06 electronic-controlled throttle valve connector.



- Disconnect connector, and measure at electronic-controlled throttle valve side.
- Resistance between terminal No. 1 and No. 2.


OK: 0.3 –100 k Ω (at 20 °C)

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace throttle body assembly.

STEP 3. Connector check: C-114 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

STEP 4. Check harness between B-06 (terminal No. 1) electronic-controlled throttle valve connector and C-114 (terminal No. 133) engine-A/T-ECU connector.





- Check output line for short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair.

STEP 5. Check harness between B-06 (terminal No. 2) electronic-controlled throttle valve connector and C-114 (terminal No. 141) engine-A/T-ECU connector.



- Check output line for short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. Check the trouble symptoms.


Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P2102: Throttle Valve Control Servo Circuit (Shorted Low)

Throttle valve control servo circuit



AK305730AD

OPERATION

- Controls the current that is applied from the engine-A/T-ECU (terminals No. 133, No. 141) to the electronic-controlled throttle valve (terminals No. 1, No. 2).

FUNCTION

- Engine-A/T-ECU varies the direction and the amperage of the current that is applied to the throttle valve control servo in order to control the opening of the throttle valve.

TROUBLE JUDGMENT

Check Condition

- Battery positive voltage is 8.3 V or higher.


Judgement Criterion

- Throttle valve control servo current is 12 A or higher for 0.8 second.

PROBABLE CAUSES

- Failed throttle valve control servo.
- Short circuit in throttle valve control servo circuit or lose connector contact.
- Failed engine-A/T-ECU


DIAGNOSIS PROCEDURE

**STEP 1. Connector check: B-06
electronic-controlled throttle valve connector**

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

**STEP 2. Perform resistance measurement at B-06
electronic-controlled throttle valve connector.**


- Disconnect connector, and measure at electronic-controlled throttle valve side.
- Resistance between terminal No. 1 and No. 2.

OK: 0.3 –100 Ω (at 20 °C)

Q: Is the check result normal?

YES : Go to Step 3 .



NO : Replace throttle body assembly.

**STEP 3. Connector check: C-114 engine-A/T-ECU
connector**

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

**STEP 4. Check harness between B-06 (terminal
No. 1) electronic-controlled throttle valve
connector and C-114 (terminal No. 133)
engine-A/T-ECU connector.**



- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair.

STEP 5. Check harness between B-06 (terminal No. 2) electronic-controlled throttle valve connector and C-114 (terminal No. 141) engine-A/T-ECU connector.



- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. Check the trouble symptoms.


Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P2103: Throttle Valve Control Servo Circuit (Shorted High)

Throttle valve control servo circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305730AD

OPERATION

- Controls the current that is applied from the engine-A/T-ECU (terminals No. 133, No. 141) to the electronic-controlled throttle valve (terminals No. 1, No. 2).

FUNCTION

- Engine-A/T-ECU varies the direction and the amperage of the current that is applied to the throttle valve control servo in order to control the opening of the throttle valve.

TROUBLE JUDGMENT**Check Condition**

- Battery positive voltage is 8.3 V or higher.

Judgement Criterion


- Throttle actuator control motor current is 8 A or higher for 0.8 second.

PROBABLE CAUSES

- Failed throttle valve control servo.
- Short circuit in throttle valve control servo circuit or loose connector contact.
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: B-06 electronic-controlled throttle valve connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at B-06 electronic-controlled throttle valve connector.



- Disconnect connector, and measure at electronic-controlled throttle valve side.
- Resistance between terminal No. 1 and No. 2.


OK: 0.3 –100 Ω (at 20 °C)

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace the throttle body assembly.

STEP 3. Connector check: C-114 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

STEP 4. Check harness between B-06 (terminal No. 1) electronic-controlled throttle valve connector and C-114 (terminal No. 133) engine-A/T-ECU connector.





- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair.

STEP 5. Check harness between B-06 (terminal No. 2) electronic-controlled throttle valve connector and C-114 (terminal No. 141) engine-A/T-ECU connector.



- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. Check the trouble symptoms.


Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Code No. P2122: Accelerator Pedal Position Sensor (Main) Circuit Low Input

Accelerator pedal position sensor (main) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305571AD

OPERATION

- A power voltage of 5 V is applied to the accelerator pedal position sensor (terminal No. 1) from the engine-A/T-ECU (terminal No. 92).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 91) from the accelerator pedal position sensor (terminal No. 2).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 114) from the accelerator pedal position sensor output terminal (terminal No. 3).

FUNCTION

- The accelerator pedal position sensor (main) outputs voltage which corresponds to the accelerator pedal depression.
- The engine-A/T-ECU checks whether the voltage is within a specified range.

TROUBLE JUDGMENT

Check Condition

- Ignition switch is in ON position.

Judgment Criterion

- Accelerator pedal position sensor (main) output voltage is 0.2 volt or less for 0.3 second.

PROBABLE CAUSES

- Failed accelerator pedal position sensor
- Open/short circuit in accelerator pedal position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - Item 78: Accelerator pedal position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: C-102 accelerator pedal position sensor connector




Q: Is the check result normal?

YES : Go to Step 3.

NO : Repair or replace.

STEP 3. Perform voltage measurement at C-102 accelerator pedal position sensor connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.


OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between C-102 (terminal No. 1) accelerator pedal position sensor connector and C-113 (terminal No. 92) engine-A/T-ECU connector.

- Check power supply line for open/short circuit.



Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 78: Accelerator pedal position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between C-102 (terminal No. 1) accelerator pedal position sensor connector and C-113 (terminal No. 92) engine-A/T-ECU connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check harness between C-102 (terminal No. 3) accelerator pedal position sensor connector and C-113 (terminal No. 114) engine-A/T-ECU connector.



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Replace the accelerator pedal assembly

- After replacing the accelerator pedal assembly, re-check the trouble symptoms.


Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P2123: Accelerator Pedal Position Sensor (Main) Circuit High Input

Accelerator pedal position sensor (main) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305571AD

OPERATION

- A power voltage of 5 V is applied to the accelerator pedal position sensor (terminal No. 1) from the engine-A/T-ECU (terminal No. 92).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 91) from the accelerator pedal position sensor (terminal No. 2).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 114) from the accelerator pedal position sensor output terminal (terminal No. 3).

FUNCTION

- The accelerator pedal position sensor (main) outputs voltage which corresponds to the accelerator pedal depression.
- The engine-A/T-ECU checks whether the voltage is within a specified range.

TROUBLE JUDGMENT

Check Conditions

- Ignition switch is in ON position.
- Accelerator pedal position sensor (sub) output voltage is 0.2 - 2.5 V.

Judgment Criterion

- Accelerator pedal position sensor (main) output voltage is 4.5 V or higher for is 1 second.

PROBABLE CAUSES

- Failed accelerator pedal position sensor
- Open/short circuit in accelerator pedal position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - Item 78: Accelerator pedal position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: C-102 accelerator pedal position sensor connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at C-102 accelerator pedal position sensor connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between C-102 (terminal No. 2) accelerator pedal position sensor connector and C-113 (terminal No. 91) engine-A/T-ECU connector.



- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 78: Accelerator pedal position sensor (main)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Replace the accelerator pedal assembly

- After replacing the accelerator pedal assembly, re-check the trouble symptoms.


Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P2127: Accelerator Pedal Position Sensor (Sub) Circuit Low Input

Accelerator pedal position sensor (sub) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305572AE

OPERATION

- A power voltage of 5 V is applied to the accelerator pedal position sensor (terminal No. 4) from the engine-A/T-ECU (terminal No. 97).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 107) from the accelerator pedal position sensor output terminal (terminal No. 6).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 96) from the accelerator pedal position sensor (terminal No. 5).

FUNCTION

- The accelerator pedal position sensor (sub) outputs voltage which corresponds to the accelerator pedal depression.
- The engine-A/T-ECU checks whether the voltage is within a specified range.

TROUBLE JUDGMENT**Check Condition**

- Ignition switch is in ON position

Judgment Criterion

- Accelerator pedal position sensor (sub) output voltage is 0.2 volt or less for 1 second.

PROBABLE CAUSES

- Failed accelerator pedal position sensor
- Open/short circuit in accelerator pedal position sensor circuit or loose connector contact
- Failed engine-A/T-ECU


DIAGNOSIS PROCEDURE**STEP 1. M.U.T.-III data list**

- Refer to Data List Reference Table [P.13C-313](#).
 - Item 77: Accelerator pedal position sensor (sub)

Q: Is the check result normal?


YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: C-102 accelerator pedal position sensor connector**Q: Is the check result normal?**

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform voltage measurement at C-102 accelerator pedal position sensor connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 4 and earth.


OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between C-102 (terminal No. 4) accelerator pedal position sensor connector and C-113 (terminal No. 97) engine-A/T-ECU connector.



- Check power supply line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 77: Accelerator pedal position sensor (sub)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between C-102 (terminal No. 4) accelerator pedal position sensor connector and C-113 (terminal No. 97) engine-A/T-ECU connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair.

STEP 9. Check harness between C-102 (terminal No. 6) accelerator pedal position sensor connector and C-113 (terminal No. 107) engine-A/T-ECU connector.



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 10.

NO : Repair.

STEP 10. Replace the accelerator pedal assembly

- After replacing the accelerator pedal assembly, re-check the trouble symptoms.


Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P2128: Accelerator Pedal Position Sensor (Sub) Circuit High Input

Accelerator pedal position sensor (sub) circuit



AK305572AE

OPERATION

- A power voltage of 5 V is applied to the accelerator pedal position sensor (terminal No. 4) from the engine-A/T-ECU (terminal No. 97).
- The power voltage is earthed to the engine-A/T-ECU (terminal No. 96) from the accelerator pedal position sensor (terminal No. 5).
- The sensor signal is inputted to the engine-A/T-ECU (terminal No. 107) from the accelerator pedal position sensor output terminal (terminal No. 6).

FUNCTION

- The accelerator pedal position sensor (sub) outputs voltage which corresponds to the accelerator pedal depression.
- The engine-A/T-ECU checks whether the voltage is within a specified range.

TROUBLE JUDGMENT

Check Conditions

- Ignition switch is in ON position.
- Accelerator pedal position sensor (main) output voltage is 0.2 –2.5 V.

Judgment Criterion

- Accelerator pedal position sensor (main) output voltage is 4.5 V or higher for 1 second.

PROBABLE CAUSES

- Failed accelerator pedal position sensor
- Open/short circuit in accelerator pedal position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - Item 77: Accelerator pedal position sensor (sub)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Go to Step 2 .

STEP 2. Connector check: C-102 accelerator pedal position sensor connector




Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform resistance measurement at C-102 accelerator pedal position sensor connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 5 and earth.


OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Go to Step 4 .

STEP 4. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair or replace.

STEP 5. Check harness between C-102 (terminal No. 5) accelerator pedal position sensor connector and C-113 (terminal No. 96) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.

- Check earthing line for open circuit and damage.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair.

STEP 6. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 77: Accelerator pedal position sensor (sub)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 7. Replace the accelerator pedal assembly

- After replacing the accelerator pedal assembly, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P2135: Throttle Position Sensor (Main and Sub) Range/Performance Problem

OPERATION

- Refer to Code No. P0122: Throttle Position Sensor (main) Circuit Low Input [P.13C-42](#).
- Refer to Code No. P0222: Throttle Position Sensor (sub) Circuit Low Input [P.13C-122](#).

FUNCTION

- Engine-A/T-ECU checks the throttle position sensor output signal characteristics for abnormal conditions.

TROUBLE JUDGMENT

Check Conditions

- Ignition switch is in ON position.
- Throttle position sensor (main) output voltage is 0.35–2.5 V.
- Throttle position sensor (sub) output voltage is 2.25–4.8 V

Judgment Criterion

- Using the formula given below, the voltage of 0.3 V or higher is obtained for 0.5 second: $V^* - V^{**} - 2V$

V^* : throttle position sensor (main) output voltage



V^{**} : throttle position sensor (sub) output voltage.

PROBABLE CAUSES

- Failed throttle position sensor
- Open/short circuit in throttle position sensor circuit or loose connector contact

DIAGNOSIS PROCEDURE

STEP 1. Connector check: C-113 engine-A/T-ECU connector and B-06 electronic-controlled throttle valve connector





Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Check harness between B-06 (terminal No. 4) electronic-controlled throttle valve connector and C-113 (terminal No. 115) engine-A/T-ECU connector.





- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair.

STEP 3. Check harness between B-06 (terminal No. 6) electronic-controlled throttle valve connector and C-113 (terminal No. 113) engine-A/T-ECU connector.



- Check output line for short circuit.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair.

STEP 4. Replace throttle body assembly.

- After throttle body assembly is replaced, re-check for trouble symptom.

Q: Does trouble system persist?

YES : Replace engine-A/T-ECU.

NO : Check end.

Code No. P2138: Accelerator Pedal Position Sensor (Main and Sub) Range/Performance Problem

OPERATION

- Refer to Code No. P2122: Accelerator Pedal Position Sensor (main) Circuit Low Input [P.13C-217](#).
- Refer to Code No. P2127: Accelerator Pedal Position Sensor (sub) Circuit Low Input [P.13C-223](#).

FUNCTION

- Engine-A/T-ECU checks the accelerator pedal position sensor output signal characteristics for abnormal conditions.

TROUBLE JUDGMENT

Check Conditions

- Ignition switch is in ON position
- Accelerator pedal position sensor (main) output voltage is 0.2 –4.5 V.
- Accelerator pedal position sensor (sub) output voltage is 0.2 –4.5 V.

Judgment Criteria


- Accelerator pedal position sensor (sub) output voltage minus accelerator pedal position sensor (main) output voltage is 1 volt or higher for 1 second.
- Accelerator pedal position sensor (main) output voltage minus accelerator pedal position sensor (sub) output voltage is 1 volt or higher for 0.2 seconds.

PROBABLE CAUSES

- Failed accelerator pedal position sensor
- Open/short circuit in accelerator pedal position sensor circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: C-102 accelerator pedal position connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Perform resistance measurement at C-102 accelerator pedal position sensor connector.




- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.

OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 6 .



NO : Go to Step 3 .

STEP 3. Connector check: C-113 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair or replace.

STEP 4. Check harness between C-102 (terminal No. 2) accelerator pedal position sensor connector and C-113 (terminal No. 91) engine-A/T-ECU connector.

- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 5 .


NO : Repair.

STEP 5. Check the trouble symptoms

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 6. Perform resistance measurement at C-102 accelerator pedal position sensor connector.


- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 5 and earth.

OK: 2 Ω or less

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Go to Step 7 .



STEP 7. Connector check: C-113 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Check harness between C-102 (terminal No. 5) accelerator pedal position sensor connector and C-113 (terminal No. 96) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector C-116, and repair if necessary.


- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair.

STEP 9. Connector check: C-113 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair or replace.

STEP 10. Check harness between C-102 (terminal No. 1) accelerator pedal position sensor connector and C-113 (terminal No. 92) engine-A/T-ECU connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Check harness between C-102 (terminal No. 4) accelerator pedal position sensor connector and C-113 (terminal No. 97) engine-A/T-ECU connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair.

STEP 12. Check harness between C-102 (terminal No. 3) accelerator pedal position sensor connector and C-113 (terminal No. 114) engine-A/T-ECU connector.





- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 13.

NO : Repair.

STEP 13. Check harness between C-102 (terminal No. 6) accelerator pedal position sensor connector and C-113 (terminal No. 107) engine-A/T-ECU connector.



- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Repair.

STEP 14. Replace the accelerator pedal assembly

- After replacing the accelerator pedal assembly, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Check end.

NO : Replace engine-A/T-ECU.

Code No. P2173: Abnormal Intake Air Amount

FUNCTION

- Engine-A/T-ECU decides the allowable intake air amount in accordance with the engine speed and the target opening angle of throttle valve.
- Engine-A/T-ECU checks whether the actual intake air amount is more than the allowable intake air amount.

TROUBLE JUDGMENT

Check Condition

- While engine is running.

Judgment Criterion

- The actual intake air amount is more than the allowable intake air amount for 1.5 seconds.

PROBABLE CAUSES

- Failed air flow sensor.
- Throttle valve faulty operation.
- Failed throttle position sensor
- Failed engine-A/T-ECU

DIAGNOSIS

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. Replace the air flow sensor.

- After replacing the air flow sensor, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Check end.

STEP 3. Replace the throttle body assembly.

- After replacing the throttle body assembly, re-check the trouble symptoms.

Q: Is the check result normal?

YES : Replacing engine-A/T-ECU.

NO : Check end.

Code No. U1073: Bus Off**⚠ CAUTION**

If diagnosis code U1073 is output from engine-A/T-ECU surely perform CAN busline diagnosis.

⚠ CAUTION

Replace ECU after certainly confirming that the communication circuits are normal.

TROUBLE JUDGMENT**Check Condition**

- All the time

Judgment Criterion

- When the buss off error is detected.

COMMENT ON TROUBLE SYMPTOM

- The failure is possibly caused by malfunction of the harness and connector in CAN busline or by malfunction in engine-A/T-ECU.

PROBABLE CAUSE

- Failed engine-A/T-ECU

DIAGNOSIS**STEP 1. M.U.T.-III CAN bus diagnostics**

- Using M.U.T.-III, perform CAN busline diagnosis.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Correct CAN busline (Refer to 54F – Troubleshooting –Can Bus Diagnostics Table [P.54F-13](#)), and then go to Step 3 .

STEP 2. M.U.T.-III diagnosis code

Reconfirm whether the diagnosis codes are output from Engine-A/T-ECU.

1. Erase the diagnosis codes being output.
2. Ignition switch: "LOCK" (OFF) to ON
3. Confirm whether the diagnosis codes are output.

Q: Are the diagnosis codes output?

YES : Replace engine-A/T-ECU. Then go to Step 3 .

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 3. M.U.T.-III diagnosis code

Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.

1. Erase the diagnosis codes being output.
2. Ignition switch: "LOCK" (OFF) to ON
3. Confirm whether the diagnosis codes are output.

Q: Are the diagnosis codes output?

YES : Go to Step 1 .

NO : Check end.

Code No. U1102: ABS-ECU time-out

⚠ CAUTION

If Diagnosis Code U1102 is output from engine-A/T-ECU surely perform CAN busline diagnosis.

⚠ CAUTION

Replace ECU after certainly confirming that the communication circuits are normal.

TROUBLE JUDGMENT

Check Conditions

- While the cranking switch is in OFF position, or when 3 seconds pass after the cranking switch is in OFF from ON.
- The battery voltage is 10V or more.

Judgment Criterion

- The signals cannot be received from ABS-ECU through CAN busline.

COMMENT ON TROUBLE SYMPTOM

Current malfunction

- The failure is possibly caused by malfunction of the harness and connector in CAN busline between engine-A/T-ECU and ABS-ECU, by malfunction in the power supply system of ABS-ECU, in ABS-ECU itself, in engine-A/T-ECU.

Past malfunction

- Focus on diagnosing malfunction of the harness and connector in CAN busline between engine-A/T-ECU and ABS-ECU as well as malfunction in the power supply system of ABS-ECU (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

NOTE: In case of Past trouble, M.U.T.-III CAN bus diagnosis cannot detect the failure even if there is malfunction in CAN bus, so that check CAN busline in the same way as Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5). The diagnosis codes being output to each ECU with CAN communication can narrow down the most suspected area. (Refer to GROUP 54F –Explanation About The M.U.T.-III Can Bus Diagnostics P.54F-7).

PROBABLE CAUSES

- Failed of the harness and the connector
- Failed engine-A/T-ECU
- Failed ABS-ECU

DIAGNOSIS

STEP 1. M.U.T.-III CAN bus diagnostics

- Using M.U.T.-III, perform CAN busline diagnosis.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Correct CAN busline (Refer to GROUP54F –Troubleshooting –Can Bus Diagnostic Table P.54F-13), and then go to Step 6 .

STEP 2. M.U.T.-III other system diagnosis codes

- Confirm whether the diagnosis codes are output from ABS-ECU.

Q: Is the diagnosis code output?

YES : Perform the troubleshooting of ABS (Refer to GROUP 35B –Troubleshooting –Check Chart For Diagnosis Codes P.35B-6).

NO : Go to Step 3 .

STEP 3. M.U.T.-III other system diagnosis codes

- Confirm whether Diagnosis Code U1102: ABS-ECU time-out is output from the following ECU having CAN communication with ABS-ECU
 - a. EPS-ECU
 - b. Combination meter-ECU

Q: Is the diagnosis code output?

YES : Go to Step 4 .

NO : Go to Step 5 .

STEP 4. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - a. Erase the diagnosis codes being output.
 - b. Ignition switch: "LOCK" (OFF) to ON
 - c. Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Replace ABS-ECU. Then go to Step 6 .

NO : Intermittent malfunction in CAN busline between engine-A/T-ECU and ABS-ECU (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

STEP 5. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - a. Erase the diagnosis codes being output.
 - b. Ignition switch: "LOCK" (OFF) to ON
 - c. Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Replace engine-A/T-ECU. Then go to Step 6 .

NO : Intermittent malfunction in CAN busline between engine-A/T-ECU and ABS-ECU (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 6. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - a. Erase the diagnosis codes being output.
 - b. Ignition switch: "LOCK" (OFF) to ON
 - c. Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Go to step 1 .

NO : Check end.

Code No. U1108: Combination meter timeout**⚠ CAUTION**

If Diagnosis Code U1108 is output from engine-A/T-ECU surely perform CAN busline diagnosis.

⚠ CAUTION

Replace ECU after certainly confirming that the communication circuits are normal.

TROUBLE JUDGMENT**Check Conditions**

- While the cranking switch is in OFF position, or when 3 seconds pass after the cranking switch is in OFF from ON.
- The battery voltage is 10V or more.

Judgment Criterion

- The signals cannot be received from combination meter through CAN busline.

COMMENT ON TROUBLE SYMPTOM**Current malfunction**

- The failure is possibly caused by malfunction of the harness and connector in CAN busline between engine-A/T-ECU and combination meter or between engine-A/T-ECU and combination meter, by malfunction in the power supply system of combination meter, in combination meter itself, in engine-A/T-ECU.

Past malfunction

- Focus on diagnosing malfunction of the harness and connector in CAN busline between engine-A/T-ECU and combination meter as well as malfunction in the power supply system of combination meter. Refer to past trouble (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)) for the diagnosis procedure.

NOTE: In case of Past trouble, M.U.T.-III CAN bus diagnosis cannot detect the failure even if there is malfunction in CAN bus, so that check CAN busline in the same way as Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)). The diagnosis codes being output to each ECU with CAN communication can narrow down the most suspected area (Refer to GROUP 54F –Explanation About The M.U.T.-III Can Bus Diagnostics [P.54F-7](#)).

PROBABLE CAUSES

- Failed of the harness and the connector
- Failed combination meter
- Failed engine-A/T-ECU

DIAGNOSIS

STEP 1. M.U.T.-III CAN bus diagnostics

- Using M.U.T.-III, perform CAN busline diagnosis.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Correct CAN busline (Refer to Group 54F – Troubleshooting –Can Bus Diagnostics Table [P.54F-13](#)), and then go to Step 6 .

STEP 2. M.U.T.-III other system diagnosis codes.

- Confirm whether the diagnosis codes are output from combination meter.

Q: Is the diagnosis code output?

YES : Perform the troubleshooting of combination meter (Refer to GROUP 54A –combination meter –Check Chart For Diagnosis Code codes [P.54A-55](#)).

NO : Go to Step 3 .

STEP 3. M.U.T.-III other system diagnosis codes

- Confirm whether Diagnosis Code U1108: combination meter time-out is output from the following ECU having CAN communication with combination meter
 - ETACS-ECU

Q: Is the diagnosis code output?

YES : . Go step 5.

NO : . Go step 4 .

STEP 4. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - Erase the diagnosis codes being output.
 - Ignition switch: "LOCK" (OFF) to ON
 - Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : . Replace combination meter. Then go to Step 6 .

NO : Temporary malfunction in CAN busline between engine-A/T-ECU and combination meter (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 5. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - Erase the diagnosis codes being output.
 - Ignition switch: "LOCK" (OFF) to ON
 - Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Replace engine-A/T-ECU. Then go to Step 6 .

NO : Temporary malfunction in CAN busline between engine-A/T-ECU and combination meter (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#))

STEP 6. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - Erase the diagnosis codes being output.
 - Ignition switch: "LOCK" (OFF) to ON
 - Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Go to step 1 .

NO : The check is completed.

Code No. U1110: A/C-ECU timeout

⚠ CAUTION

If Diagnosis Code U1110 is output from engine-A/T-ECU surely perform CAN busline diagnosis.

⚠ CAUTION

Replace ECU after certainly confirming that the communication circuits are normal.

TROUBLE JUDGMENT**Check Conditions**

- While the cranking switch is in OFF position, or when 3 seconds pass after the cranking switch is in OFF from ON.
- The battery voltage is 10V or more.

Judgment Criterion

- The signals cannot be received from A/C-ECU through CAN busline.

COMMENT ON TROUBLE SYMPTOM**Current malfunction**

- The failure is possibly caused by malfunction of the harness and connector in CAN busline between engine-A/T-ECU and A/C-ECU, by malfunction in the power supply system of A/C-ECU, in A/C-ECU itself, in engine-A/T-ECU.

Past malfunction

- Focus on diagnosing malfunction of the harness and connector in CAN busline between engine-A/T-ECU and A/C-ECU as well as malfunction in the power supply system of A/C-ECU. Refer to past trouble (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5) for the diagnosis procedure.

NOTE: In case of Past trouble, M.U.T.-III CAN bus diagnosis cannot detect the failure even if there is malfunction in CAN bus, so that check CAN busline in the same way as Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5). The diagnosis codes being output to each ECU with CAN communication can narrow down the most suspected area (Refer to GROUP 54F –Explanation About The M.U.T.-III Can Bus Diagnostics P.54F-7).

PROBABLE CAUSES

- Failed of the harness and the connector
- Failed A/C-ECU
- Failed engine-A/T-ECU

DIAGNOSIS**STEP 1. M.U.T.-III CAN bus diagnostics**

- Using M.U.T.-III, perform CAN busline diagnosis.

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Correct CAN busline (Refer to Group 54F – Troubleshooting –Can Bus Diagnostic Table P.54F-13), and then go to Step 6 .

STEP 2. M.U.T.-III other system diagnosis codes

- Confirm whether the diagnosis codes are output from A/C-ECU.

Q: Is the diagnosis code output?

YES : Perform the troubleshooting of A/C-ECU (Refer to GROUP 55 –Troubleshooting– Check Chart for Diagnosis Codes P.55-8).

NO : Go step 3 .

STEP 3. M.U.T.-III other system diagnosis codes

- Confirm whether Diagnosis Code U1110 A/C-ECU time-out is output from the following ECU having CAN communication with A/C ECU.
 - a. ETACS-ECU

Q: Is the diagnosis code output?

YES : Go to Step 4 .

NO : Go to Step 5 .

STEP 4. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - a. Erase the diagnosis codes being output.
 - b. Ignition switch: "LOCK" (OFF) to ON
 - c. Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Replace A/C-ECU. Then go to Step 6 .

NO : Intermittent malfunction in CAN busline between engine-A/T-ECU and A/C-ECU (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

STEP 5. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - a. Erase the diagnosis codes being output.
 - b. Ignition switch: "LOCK" (OFF) to ON
 - c. Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Replace engine-A/T-ECU. Then go to Step 6 .

NO : Intermittent malfunction in CAN busline between engine-A/T-ECU and A/C-ECU (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 6. M.U.T.-III diagnosis code

- Reconfirm whether the diagnosis codes are output from engine-A/T-ECU.
 - a. Erase the diagnosis codes being output.
 - b. Ignition switch: "LOCK" (OFF) to ON
 - c. Confirm whether the diagnosis codes are output.

Q: Is the diagnosis code output?

YES : Go to Step 1 .

NO : check end.

INSPECTION CHART FOR TROUBLE SYMPTOMS

M1131151501611

Items	Trouble symptom		Inspection procedure No.
Communication with M.U.T.-III is impossible	Communication with engine-A/T-ECU only is not possible		1
Engine warning lamp	The engine warning lamp does not illuminate right after the ignition switch is turned the "ON" position		2
	The engine warning lamp remains illuminating and never goes out		3
Starting	Starting impossible (No initial combustion)	The starter is impossible to operate.	4
	Starting impossible (Starter operative but no initial combustion)	The starter is operative and cranks the engine, but none of initial combustion is in the cylinders and the engine is not started.	5
	Starting impossible (Initial combustion but no complete combustion)	The initial combustion occurs, but the engine stalls soon due to the incomplete combustion.	6
	Improper starting (Long time to start)	It is long cranking to start the engine.	
Improper idling	Unstable idling (Rough idling, hunting)	The engine speed is not constant and changeable during the idling. Usually, the judgment can be based on the movement of the tachometer pointer, also on the vibration transmitted to the steering wheel, shift lever, vehicle body and so on.	7
	Improper idling speed	The proper idling speed is not satisfied.	
	Engine stalled during idling (Die out)	The engine stalls during the idling in no relation to the vehicle movement.	
Engine stalls	The engine stalls when starting the car (Pass out)	The engine stalls during the operation, or when the accelerator pedal is depressed from the idling.	8
	The engine stalls when decelerating	The engine stalls at the deceleration.	9

Items	Trouble symptom		Inspection procedure No.
Driving	Engine does not revolve up	The engine speed is not higher when the accelerator pedal is depressed.	10
	Hesitation, sag	The response of vehicle speed (engine speed) is delayed when the accelerator pedal is depressed, or the vehicle speed (engine speed) is temporarily dropped during the acceleration. These phenomena are called "hesitation" and the serious hesitation is called "sag".	11
	Poor acceleration	The engine cannot obtain the acceleration corresponding to the degree of throttle opening although the engine is smooth at the constant speed.	11
	Stumble	The engine speed increase is delayed when the accelerator pedal is initially depressed at the starting.	
	Surge	The vehicle body is repeated to vibrate jollity in the forward and backward directions at the constant speed or acceleration.	
	The feeling of impact or vibration when accelerating	The large impact feeling occurs at the acceleration.	12
	The feeling of impact or vibration when decelerating	The large impact feeling occurs at the deceleration.	13
	Knocking	Sharp sound like a hammer striking on the cylinder walls during the driving can be heard and wrongly affects the driving.	14
	Ignition timing offset	The basic ignition timing is deviated from the datum value.	15
Stopping	Run on (Dieseling)	The engine continues to run after the ignition switch is in "LOCK (OFF)" position.	16
Exhaust gas	Odor, white smoke, black smoke, high-concentration CO/HC during idling	The exhaust gas is extremely rank odor, white smoke or black smoke. The concentration of CO & HC is high during the idling.	17

Items	Trouble symptom		Inspection procedure No.
Charging performance	Battery rundown	The battery is soon rundown or the charging ability of battery is small.	18
Cooling performance	Overheating	The temperature of engine cooling water is extremely high.	19
	Abnormal rotation of fan Motor	The fan motor is abnormally rotated when the ignition switch is in "ON" position in no relation to the engine cooling water temperature.	20


PROBLEM SYMPTOMS TABLE

Inspection procedure No.	Trouble symptom	Reference page
1	Communication with engine-A/T-ECU only is not possible	P.13A-189
2	The engine warning lamp does not illuminate right after the ignition switch is turned the "ON" position	P.13C-248
3	The engine warning lamp remains illuminating and never goes out	P.13C-248
4	Starting impossible (No initial combustion)	P.13C-249
5	Starting impossible (Starter operative but no initial combustion)	P.13C-254
6	Starting impossible (Initial combustion but no complete combustion)	P.13C-256
	Starting impossible (Long time to start)	
7	Unstable idling (Rough idling, hunting)	P.13C-258
	Improper idling speed (Too high or too low)	
	Engine stalls during idling (Die out)	
8	The engine stalls when starting the car (pass out)	P.13C-261
9	The engine stalls when decelerating	P.13C-262
10	Engine does not revolve up	P.13C-263
11	Hesitation, sag	P.13C-263
	Poor acceleration	
	Stumble	
	Surge	
12	The feeling of impact or vibration when accelerating	P.13C-265
13	The feeling of impact or vibration when decelerating	P.13C-265
14	Knocking	P.13C-266
15	Ignition timing offset	P.13C-266
16	Run on (Dieseling)	P.13C-268
17	Odor, white smoke, black smoke, high-concentration CO/HC during idling	P.13C-268
18	Battery rundown	P.13C-270
19	Overheating	P.13C-273
20	Abnormal rotation of fan motor	P.13C-274
21	Engine-A/T-ECU power supply, engine control relay, ignition switch-IG1 system	P.13A-232
22	Fuel pump system	P.13C-283
23	Fan control relay system	P.13C-291
24	A/C compressor relay system	P.13C-297
25	Ignition circuit system	P.13C-303
26	Stop lamp switch circuit	P.13C-310

SYMPTOM PROCEDURES

Inspection Procedure 1: Communication with Engine-A/T-ECU is Not Possible.

Diagnosis connector circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK305574 AD

OPERATION

- There is data communication between diagnosis connector output terminal (terminal No. 7) and engine-A/T-ECU (terminal No. 74).

COMMENT ON TROUBLE SYMPTOM

- The failure possibly occurs when engine-A/T-ECU detects malfunction, or is caused by malfunction of open or short in the combination meter circuit.

PROBABLE CAUSES

- Open/short circuit in engine-A/T-ECU power circuit

- Between engine-A/T-ECU and diagnosis connector for short circuit
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE


STEP 1: Check start - up.

Q: Is engine started

YES : Go to Step 2 .

NO : Check engine-A/T-ECU power supply, engine control relay and ignition switch IG1 system (Refer to Inspection Procedure 21 [P.13A-232](#)).

STEP 2: Connector check: C-112 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3: Check harness between C-126 (terminal No. 7) diagnosis connector and C-112 (terminal No. 74) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connectors C-17, and repair if necessary.

- Check communication line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Repair.

STEP 4: Check the trouble symptom.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Inspection Procedure 2: The Engine Warning Lamp Does Not Illuminate Right after the Ignition Switch is Turned the "ON" Position

COMMENTS ON TROUBLE SYMPTOM

- The combination meter illuminates engine warning lamp for 5 seconds just after the ignition switch is in "ON" position.
- If engine warning lamp does not illuminate just after the ignition switch is in "ON" position, the failure is possibly caused by malfunction of engine warning lamp, open or short in the combination meter circuits and so on.

PROBABLE CAUSES

- Failed engine warning lamp
- Open/short circuit in combination meter

DIAGNOSIS PROCEDURE

STEP 1: M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2: Check the trouble symptoms.

Q: Does trouble system persist?

YES : Replace combination meter assembly.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Inspection Procedure 3: The Engine Warning Lamp Remains Illuminating and Never Goes Out

COMMENT ON TROUBLE SYMPTOM

- Engine-A/T-ECU has detected failed sensor or failed actuator. Or failure is possibly caused by short circuit or other faults.

PROBABLE CAUSE

- Short circuit in combination meter

DIAGNOSIS PROCEDURE

STEP 1: M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#).)

NO : Go to Step 2 .

STEP 2: Check the trouble symptoms.


Q: Does trouble symptom persist?

YES : Replace combination meter assembly.

NO : Intermittent malfunction (Refer to GROUP00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Inspection Procedure 4: Starting Impossible (No Initial Combustion)

Starting impossible (no initial combustion)



AK305576AC

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed starter itself or failed related circuit.

PROBABLE CAUSES

- Failed battery

- Failed inhibitor switch
- Failed starter motor
- Open/short circuit in starter associated circuit or loose connector contact

DIAGNOSIS PROCEDURE

STEP 1: Check battery voltage.

- Measure battery voltage at cranking.

OK: 8 V or higher

Q: Is the check result normal?

YES : Go to Step 2.

NO : Check battery (Refer to GROUP 54A – Battery-On-vehicle Service –Battery Test P.54A-6).

STEP 2: M.U.T.-III data list

- Refer to Data List Reference Table P.13C-313
 - Item 18: Cranking signal

OK:


ON (Ignition switch: ST)

OFF (Ignition switch: ON)

Q: Is the check result normal?

YES : Go to Step 11.


NO : Go to Step 3.

STEP 3: Connector check: C-111 engine-A/T-ECU connector

Q: Is the check result normal?

YES : Go to Step 4.

NO : Repair or replace.

STEP 4: Perform voltage measurement at C-111 engine-A/T-ECU connector.


- Disconnect connector, and measure at the harness side.
- Ignition switch: ST
- Voltage between terminal No. 51 and earth.

OK: System voltage

Q: Is the check result normal?

YES : Go to Step 10.

NO : Go to Step 5.


STEP 5: Connector check: B-111 inhibitor switch connector

Q: Is the check result normal?

YES : Go to Step 6.

NO : Repair or replace.

STEP 6: Perform voltage measurement at B-111 inhibitor switch connector



- Disconnect connector, and measure at the harness side.
- Ignition switch: ST
- Voltage between terminal No. 10 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 9.

NO : Go to Step 7.

STEP 7: Connector check: C-307 ignition switch connector





Q: Is the check result normal?

YES : Go to Step 8.

NO : Repair or replace.

STEP 8: Check ignition switch





- Check ignition switch (Refer to GROUP 54A – Ignition switch –Inspection [P.54A-49](#)).

Q: Is the check result normal?

YES : Check intermediate connector C-18 and repair if necessary. If intermediate connector is normal, check and repair harness between B-111 (terminal No. 10) inhibitor switch connector and C-307 (terminal No. 5) ignition switch connector.

- Check power supply line for open/short circuit.

NO : Replace ignition switch.

STEP 9: Check inhibitor switch.



- Check ignition switch (Refer to GROUP 23A – On-vehicle Service –A/T Control Component Check –Inhibitor Switch Check [P.23A-147](#)).

Q: Is the check result normal?

YES : Check intermediate connectors B-17, and repair if necessary. If intermediate connector is normal, check and repair harness between B-111 (terminal No. 9) inhibitor switch connector and C-111 (terminal No. 51) engine-A/T-ECU connector.

- Check power supply line for open/short circuit.


NO : Replace ignition switch.

STEP 10: Connector check: B-111 inhibitor switch connector and B-116 starter connector**Q: Is the check result normal?**

YES : Check intermediate connector B-17, and repair if necessary. If intermediate connector is normal, check and repair harness between B-111 (terminal No. 9) inhibitor switch connector and B-116 (terminal No. 1) starter connector.

- Check output line for short circuit.


NO : Repair or replace.

STEP 11: Connector check: B-116 starter connector**Q: Is the check result normal?**

YES : Go to Step 12.

NO : Repair or replace.

STEP 12: Perform voltage measurement at B-116 starter connector.



- Disconnect connector, and measure at the harness side.
- Ignition switch: ST
- Voltage between terminal No. 1 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 14.

NO : Go to Step 13.

STEP 13: Connector check: B-111 inhibitor switch connector




Q: Is the check result normal?

YES : Check intermediate connector B-17, and repair if necessary. If intermediate connector is normal, check and repair harness between B-111 (terminal No. 9) inhibitor switch connector and B-116 (terminal No. 1) starter connector.

- Check output line for open circuit and damage.

NO : Repair or replace.

STEP 14: Connector check: B-115 starter connector




Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair or replace.

STEP 15: Perform voltage measurement at B-115 starter connector.



- Disconnect connector, and measure at the harness side.
- Voltage between terminal No. 1 and earth.

OK: System voltage



Q: Is the check result normal?

YES : Go to Step 16.

NO : Check and repair harness between B-115 (terminal No. 1) starter connector and battery.

- Check power supply line for open/short circuit.

STEP 16: Check harness between B-111 (terminal No. 9) inhibitor switch connector and B-116 (terminal No. 1) starter connector.



NOTE: Before checking harness, check intermediate connector B-17 and repair if necessary.


- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 17.

NO : Repair.

STEP 17: Check harness between B-115 (terminal No. 1) starter connector and battery.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Replace starter.

NO : Repair.

Inspection Procedure 5: Starting Impossible (Starter Operative but No Initial Combustion)

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed ignition circuit, failed fuel feed or other faults.

PROBABLE CAUSES

- Failed battery
- Timing belt broken
- Failed idle speed control
- Throttle valve fouled around
- Failed ignition system
- Failed fuel system
- Failed immobilizer system
- Failed inhibitor switch
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1: Check battery voltage.

- Measure battery voltage at cranking.

OK: 8 V or higher

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check battery (Refer to GROUP 54 –Battery –On-vehicle Service –Battery Test [P.54A-6](#)).

STEP 2: With M.U.T.-III of communication.

- Confirm the communication available M.U.T. -III and engine-A/T-ECU

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Check engine-A/T-ECU power supply, engine control relay and ignition switch IG1 system (Refer to Inspection Procedure 21 [P.13A-232](#)).

STEP 3: M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis codes (Refer to [P.13C-21](#))

NO : Go to Step 4 .

STEP 4: M.U.T.-III actuator test

- Item 07: Fuel pump

OK: Operating sound of fuel pump can be heard.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Check fuel pump system (Refer to Inspection Procedure 22 [P.13C-283](#))

STEP 5. Check timing belt for breakage.

- Engine: Cranking

OK: Camshaft rotates.

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Replace timing belt.

STEP 6. Check throttle body (throttle valve) contamination.

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 7: M.U.T.-III data list

- Item 18: Cranking signal

OK:

ON (Ignition switch: ST)



OFF (Ignition switch: ON)

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Go to Step 8 .

STEP 8: Connector check: C-111 engine-A/T-ECU connector



Q: Is the check result normal?

YES : Check intermediate connector B-17, and repair if necessary. If intermediate connector is normal, check and repair harness between B-111 (terminal No. 9) inhibitor switch connector and C-111 (terminal No. 51) engine-A/T-ECU connector.

- Check output line for open/short circuit.

NO : Repair or replace.

STEP 9: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 22: Crank angle sensor

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Check crank angle sensor system (Refer to Code No. P0335 [P.13C-143](#)).

STEP 10: Check injector for operating sound.

- Check injector for operating sound (Refer to [P.13C-344](#)).

Q: Can operating sound be heard?**YES** : Go to Step 11 .**NO** : Check the injector system of the defective cylinder.(Refer to Code No. P0201: No. 1 injector system [P.13C-106](#).)(Refer to Code No. P0202: No. 2 injector system [P.13C-110](#).)(Refer to Code No. P0203: No. 3 injector system [P.13C-114](#).)(Refer to Code No. P0204: No. 4 injector system [P.13C-118](#).)**STEP 12: Fuel pressure measurement.**

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?**YES** : Go to Step 13 .**NO** : Repair.**STEP 13: Replace engine-A/T-ECU**

- After replacing the engine-A/T-ECU, re-check the trouble symptoms.

Q: Does trouble symptom persist?**YES** : Check for foreign matters (water, kerosene, etc.) in fuel and replace if necessary.**NO** : Check end.**STEP 11: Check ignition coil spark.****Q: Is the check result normal?****YES** : Go to Step 12 .**NO** : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#))**Inspection Procedure 6: Starting Impossible (Initial Combustion But No Complete Combustion), Improper Starting (Long Time to Start)****COMMENT ON TROUBLE SYMPTOM**

- Failure is possibly caused by poor ignition, incorrect air-fuel ratio at cranking, improper fuel pressure or other faults.

PROBABLE CAUSES

- Failed battery
- Failed ignition system
- Failed fuel system
- Air-fuel ratio control
- Failed throttle valve control system
- Failed intake system
- Failed exhaust gas cleaning system
- Throttle valve fouled around
- Timing belt not in place
- Compression pressure improper
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1: Check battery condition.****Q: Have the battery terminal been disconnected?****YES** : After warm-up engine, idle for about 10 minutes.**NO** : Go to Step 2 .**STEP 2: Check battery voltage.**

- Measure battery voltage at cranking.

OK: 8 V or higher**Q: Is the check result normal?****YES** : Go to Step 3 .**NO** : Check battery (Refer to GROUP 54 –Battery –On-vehicle Service –Battery Test [P.54A-6](#)).**STEP 3: M.U.T.-III diagnosis code****Q: Diagnosis code set?****YES** : Inspection chart for diagnosis codes (Refer to [P.13C-21](#))**NO** : Go to Step 4 .

STEP 4: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 12: Air flow sensor
 - b. Item 13: Intake air temperature sensor
 - c. Item 21: Engine coolant temperature sensor

Q: Are the check results normal?

YES : Go to Step 5 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 5: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Replace engine-A/T-ECU.

STEP 6: Check throttle body (throttle valve) contamination.**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 7: M.U.T.-III actuator test

- Item 07: Fuel pump
 - OK:** Operating sound of fuel pump can be heard.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Check fuel pump system (Refer to Inspection Procedure 22 [P.13C-283](#)).

STEP 8: Check air intake from intake hose and inlet manifold.**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Repair.

STEP 9: Check injector for operating sound.

- Check injector for operating sound at engine cranking (Refer to [P.13C-344](#)).

Q: Can operating sound be heard?

YES : Go to Step 10 .

NO : Check the injector system of the defective cylinder.

(Refer to Code No. P0201: No.1 Injector System [P.13C-106](#).)

(Refer to Code No. P0202: No.2 Injector System [P.13C-110](#).)

(Refer to Code No. P0203: No.3 Injector System [P.13C-114](#).)

(Refer to Code No. P0204: No.4 Injector System [P.13C-118](#).)

STEP 10: Check timing marks of timing belt.**Q: Is the check result normal?**

YES : Go to Step 11 .

NO : Align timing marks.

STEP 11: Check ignition coil spark.**Q: Is the check result normal?**

YES : Go to Step 12 .

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 12: Check spray condition of injector.

- Check each injector for spray condition (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Replace injector.

STEP 13: Check compression pressure.

- Check compression pressure (Refer to GROUP 11A –On-vehicle Service –Compression Pressure Check [P.11A-14](#)).

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Repair.

STEP 14: Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (stepper motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Replace EGR valve (stepper motor).

STEP 15: Replace engine-A/T-ECU.

- After replacing the engine-A/T-ECU, re-check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Check for foreign matters (water, kerosene, etc.) in fuel and replace if necessary.

NO : Check end.

Inspection Procedure 7: Unstable Idling (Rough Idling, Hunting), Improper Idling Speed (Too High or too Low), Engine Stalls during Idling (Die Out)

COMMENT ON TROUBLE SYMPTOM

- Probable causes can be widely found in ignition system, air-fuel ratio control system, idle air control fuel system, etc. A sudden engine stall is possibly caused by poor connector contact.

PROBABLE CAUSES

- Failed ignition system
- Failed fuel system
- Failed throttle valve control system
- Failed intake/exhaust system
- Failed emission gas cleaning system
- Air drawn in from gaps in gasket, seal, etc.
- Throttle valve body fouled
- Timing belt out of place
- Compression pressure improper
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1: Check battery condition.**Q: Has the battery terminal been disconnected?**

YES : After warm-up engine, idle for about 10 minutes.

NO : Go to Step 2 .

STEP 2: M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 3 .

STEP 3: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 12: Air flow sensor
 - b. Item 13: Intake air temperature sensor
 - c. Item 14: Throttle position sensor (sub)
 - d. Item 21: Engine coolant temperature sensor
 - e. Item 29: Inhibitor switch
 - f. Item 77: Accelerator pedal position sensor (sub)
 - g. Item 78: Accelerator pedal position sensor (main)
 - h. Item 79: Throttle position sensor (main)
 - i. Item B4: Power steering fluid pressure sensor

Q: Are the check results normal?

YES : Go to Step 4 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 4: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Is the check results normal?

YES : Go to Step 5 .

NO : Replace engine-A/T-ECU.

STEP 5: Check air intake from intake hose and inlet manifold.**Q: Is the check result normal?**

YES : Go to Step 6 .

NO : Repair.

STEP 6: Check timing marks of timing belt.**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Align timing marks.

STEP 7: Check throttle body (throttle valve) contamination.

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Clean throttle body (throttle valve portion)
(Refer to [P.13C-335](#)).

STEP 8. M.U.T.-III data list


- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 11: Cylinder 1, 4 oxygen sensor (front)
 - b. Item 39: Cylinder 2, 3 oxygen sensor (front)
 - c. Item 59: Cylinder 1, 4 oxygen sensor (rear)
 - d. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Are the check results normal?

YES : Go to Step 9 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 9. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Engine: Idling after warm-up
- Transmission: P range
- Radiator fan: Not operating
- Voltage between terminal No. 45 and earth.



OK: Switching the headlamps to ON from OFF causes the voltage to increase.

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Go to Step 10 .

STEP 10. Connector check: C-111 engine-A/T-ECU connector and B-119 alternator connector





Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair or replace.

STEP 11. Check harness between C-111 (terminal No. 45) engine-A/T-ECU connector and B-119 (terminal No. 1) alternator connector.



NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.

- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair.

STEP 12. Replace alternator

- After alternator is replaced, re-check for trouble symptom.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Check end.

STEP 13. Check spark plug

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Replace spark plug.

STEP 14. Check ignition coil spark.

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 15. Check purge control solenoid valve itself.

- Check purge control solenoid valve itself (Refer to GROUP 17 –Emission Control System – Evaporative Emission Control System–Purge Control Solenoid Valve Check [P.17-42](#))

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Replace purge control solenoid valve.

STEP 16. Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (Stepper Motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 17 .

NO : Replace EGR valve (stepper motor).

STEP 17. Check injector for spray condition.

- Check each injector for spray condition (Refer to [P.13C-344](#)).

Q: Is the check result normal?

YES : Go to Step 18 .

NO : Replace injector.

STEP 18. Check compression pressure.

- Check compression pressure (Refer to GROUP 11A –On-vehicle Service –Compression Pressure Check [P.11A-14](#)).

Q: Is the check result normal?

YES : Go to Step 19 .

NO : Repair.

STEP 19. Replace engine-A/T-ECU.

- After engine-A/T-ECU is replaced, re-check for trouble symptom.

Q: Does trouble system persist?

YES : Check for foreign matters (water, kerosene, etc.) in fuel and replace if necessary.

NO : Check end.

Inspection Procedure 8: The Engine Stalls when Starting the Car (Pass Out)

COMMENT ON TROUBLE SYMPTOM

- Engine stall on starting is possibly caused by mis-fire due to failed spark plug, improper air-fuel ratio at accelerator pedal depression or other faults.

PROBABLE CAUSES

- Failed ignition system
- Failed intake system
- Failed emission gas cleaning system
- Air drawn in from gaps in gasket, seals, etc.
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)
 - b. Item 77: Accelerator pedal position sensor (sub)
 - c. Item 78: Accelerator pedal position sensor (main)
 - d. Item 79: Throttle position sensor (main)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (Stepper Motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace EGR valve (stepper motor).

STEP 4. Check air intake from intake hose and inlet manifold.

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Repair.

STEP 5. Check ignition coil spark.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

Inspection Procedure 9: The Engine Stalls when Decelerating

COMMENT ON TROUBLE SYMPTOM

- Engine stall on deceleration is possibly caused by insufficient air intake, improper air-fuel ratio due to failed exhaust gas recirculation system or other faults.

PROBABLE CAUSES

- Failed throttle valve control system
- Failed ignition system
- Failed emission control system
- Throttle valve fouled
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)
 - b. Item 77: Accelerator pedal position sensor (sub)
 - c. Item 78: Accelerator pedal position sensor (main)
 - d. Item 79: Throttle position sensor (main)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (Stepper Motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace EGR valve (stepper motor).

STEP 4. Check throttle body (throttle valve portion) for contamination.**Q: Is the check result normal?**

YES : Go to Step 5 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 5. Check ignition coil spark.**Q: Is the check result normal?**

YES : Replace engine-A/T-ECU.

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

Inspection Procedure 10: Engine Does Not Revolv Up

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed fuel system, throttle valve opening control system ignition system or other faults.

PROBABLE CAUSES

- Failed ignition system
- Failed fuel system
- Failed throttle valve opening control system
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)
 - b. Item 77: Accelerator pedal position sensor (sub)
 - c. Item 78: Accelerator pedal position sensor (main)
 - d. Item 79: Throttle position sensor (main)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. Check ignition coil spark.

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 4. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Repair.

Inspection Procedure 11: Hesitation, Sag, Poor Acceleration, Stumble, Surge

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed ignition system, improper air-fuel ratio, throttle valve opening control system improper compression pressure or other faults.

PROBABLE CAUSES

- Failed air-fuel ratio control system
- Failed ignition system
- Failed fuel system
- Failed intake and exhaust system

- Failed emission control system
- Failed throttle valve opening control system
- Throttle valve fouled
- Improper compression pressure
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. Check injector for operating sound.

- Check injector for operating sound (Refer to [P.13C-344](#)).

Q: Can operating sound be heard?

YES : Go to Step 3 .

NO : Check the injector system of the defective cylinder.

(Refer to Code No. P0201: No. 1 Injector System [P.13C-106](#)).

(Refer to Code No. P0202: No. 2 Injector System [P.13C-110](#)).

(Refer to Code No. P0203: No. 3 Injector System [P.13C-114](#)).

(Refer to Code No. P0204: No. 4 Injector System [P.13C-118](#)).

STEP 3. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 13: Intake air temperature sensor
 - b. Item 14: Throttle position sensor (sub)
 - c. Item 21: Engine coolant temperature sensor
 - d. Item 77: Accelerator pedal position sensor (sub)
 - e. Item 78: Accelerator pedal position sensor (main)
 - f. Item 79: Throttle position sensor (main)

Q: Are the check results normal?

YES : Go to Step 4 .

NO : Perform the diagnosis code classified check Procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 4: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Replace engine-A/T-ECU.

STEP 5. Check purge control solenoid valve itself.

- Check purge control solenoid valve itself (Refer to GROUP 17 –Emission Control System – Evaporative Emission Control System–Purge Control Solenoid Valve Check [P.17-42](#)).

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Replace purge control solenoid valve.

STEP 6. Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (Stepper Motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 7 .

NO : Replace EGR valve (stepper motor).

STEP 7. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 11: Cylinder 1, 4 oxygen sensor (front)
 - b. Item 39: Cylinder 2, 3 oxygen sensor (front)
 - c. Item 59: Cylinder 1, 4 oxygen sensor (rear)
 - d. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Are the check results normal?

YES : Go to Step 8 .

NO : Perform the diagnosis code classified check Procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 8. Check ignition coil spark.**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

STEP 9. Check throttle body (throttle valve portion) for contamination.**Q: Is the check result normal?**

YES : Go to Step 10 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 10. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. Check compression pressure.

- Check compression pressure (Refer to GROUP 11A –On-vehicle Service –Compression Pressure Check [P.11A-14](#)).

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Repair.

Inspection Procedure 12: The Feeling of Impact or Vibration when Accelerating

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed ignition leak with rise in spark plug-required voltage at acceleration, throttle valve opening control system.

PROBABLE CAUSES

- Failed ignition system
- Failed throttle valve opening control system
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)
 - b. Item 77: Accelerator pedal position sensor (sub)
 - c. Item 78: Accelerator pedal position sensor (main)
 - d. Item 79: Throttle position sensor (main)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. Check ignition coil spark.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

Inspection Procedure 13: The Feeling of Impact or Vibration when Decelerating

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by insufficient air intake due to failed idle speed control system.

PROBABLE CAUSES

- Failed idle speed control system
- Throttle valve body fouled
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 14: Throttle position sensor (sub)
 - b. Item 77: Accelerator pedal position sensor (sub)
 - c. Item 78: Accelerator pedal position sensor (main)
 - d. Item 79: Throttle position sensor (main)

Q: Are the check results normal?

YES : Go to Step 3 .

NO : Perform the diagnosis code classified check Procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 3. Check throttle body (throttle valve) contamination.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

Inspection Procedure 14: Knocking

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed detonation control, improper thermal value of spark plug or other faults.

PROBABLE CAUSES

- Defective detonation sensor
- Failed detonation control system
- Failed ignition system
- Defective spark plug
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. Check ignition coil spark.**Q: Is the check result normal?**

YES : Check detonation sensor system (Refer to Code No. P0325 [P.13C-140](#)).

NO : Check ignition circuit system (Refer to Inspection Procedure 25 [P.13C-303](#)).

Inspection Procedure 15: Ignition Timing Offset

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed crank angle sensor, failed camshaft position sensor, improper installed timing belt or other faults.

PROBABLE CAUSES

- Failed crank angle sensor
- Failed camshaft position sensor
- Improperly installed timing belt
- Failed engine-A/T-ECU



DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code**Q: Diagnosis code set?**

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. Perform output wave pattern measurement of crank angle sensor and camshaft position sensor (Using an oscilloscope).



Crank Angle Sensor

- Use special tool test harness (MB991658) to connect B-121 crank angle sensor intermediate connector, and measure at pick-up harness.
- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 2 and earth.

Camshaft Position Sensor

- Use special tool test harness (MB991709) to connect B-114 camshaft position sensor connector, and measure at pick-up harness.
- Engine: Idling
- Transmission: P range
- Voltage between terminal No. 2 and earth.

OK: Output waveform timings of both sensors are the same as the check procedure (Refer to P.13C-329) using an oscilloscope.

Q: Is the check result normal?

- YES :** Go to Step 3 .
NO : Go to Step 4 .

STEP 3. Check the trouble symptoms.

Q: Does trouble symptom persist?

- YES :** Replace engine-A/T-ECU.
NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

STEP 4. Check crank angle sensor and camshaft position sensor mounted conditions.

Q: Is the check result normal?

- YES :** Go to Step 5 .
NO : Repair.

STEP 5. Check timing marks of timing belt.

Q: Is the check result normal?

- YES :** Go to Step 6 .
NO : Align timing marks.

STEP 6. Check crank shaft sensing bleed.

Q: Is the check result normal?

- YES :** Go to Step 7 .
NO : Replace crank shaft sensing bleed.

STEP 7. Check camshaft position sensing cylinder.

Q: Is the check result normal?

- YES :** Go to Step 8 .
NO : Replace camshaft position sensing cylinder.

STEP 8. Replace crank angle sensor.

- After replacing the crank angle sensor, re-check the trouble symptoms.

Q: Does trouble symptom persist?

- YES :** Go to Step 9 .
NO : Check end.

STEP 9. Replace camshaft position sensor.

- After replacing the camshaft position sensor, re-check the trouble symptoms.

Q: Does trouble symptom persist?

- YES :** Replace engine-A/T-ECU.
NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points P.00-5).

Inspection Procedure 16: Run On (Dieseling)

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by leakage from injector.

PROBABLE CAUSES

- Failed injector
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check injector for spray condition.

- Check each injector for spray condition (Refer to [P.13C-344](#)).

Q: Does trouble symptom persist?**YES** : Replace engine-A/T-ECU.**NO** : Replace injector.

Inspection Procedure 17: Odor, White Smoke, Black Smoke, and High-Concentration CO/HC during Idling

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by improper air-fuel ratio, deteriorated catalyst, failed ignition system, failed fuel system, failed compression pressure or other faults.

PROBABLE CAUSES

- Incorrect air/fuel ratio
- Failed ignition system
- Failed fuel system
- Failed intake and exhaust system
- Failed emission control system
- Failed compression pressure
- Failed catalytic converter
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code**Q: Diagnosis code set?****YES** : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).**NO** : Go to Step 2 .

STEP 2. Check injector for operating sound.

- Check injector for operating sound (Refer to [P.13C-344](#)).

Q: Can operating sound be heard?**YES** : Go to Step 3 .**NO** : Check the injector system of the defective cylinder.(Refer to, Code No. P0201: No. 1 injector system [P.13C-106](#))(Refer to, Code No. P0202: No. 2 injector system [P.13C-110](#))(Refer to, Code No. P0203: No. 3 injector system [P.13C-114](#))(Refer to, Code No. P0204: No. 4 injector system [P.13C-118](#))

STEP 3. Check ignition timing.

- Check ignition timing. (Refer to GROUP 11A – On-vehicle Service –Ignition Timing Check [P.11A-11](#)).

Q: Is the check result normal?**YES** : Go to Step 4 .**NO** : Check for offset ignition timing (Refer to Inspection Procedure 15 [P.13C-266](#)).

STEP 4. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 12: Air flow sensor
 - b. Item 13: Intake air temperature sensor
 - c. Item 21: Engine coolant temperature sensor

Q: Are the check results normal?

YES : Go to Step 5 .

NO : Perform the diagnosis code classified check Procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 5: M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 25: Barometric pressure sensor

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Replace engine-A/T-ECU.

STEP 6. Check air intake from intake hose and inlet manifold.**Q: Is the check result normal?**

YES : Go to Step 7 .

NO : Repair.

STEP 7. Check for emission leakage from exhaust manifold.**Q: Is the check result normal?**

YES : Go to Step 8 .

NO : Repair.

STEP 8. Check throttle body (throttle valve portion) for contamination.**Q: Is the check result normal?**

YES : Go to Step 9 .

NO : Clean throttle body (throttle valve portion) (Refer to [P.13C-335](#)).

STEP 9. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - a. Item 11: Cylinder 1, 4 oxygen sensor (front)
 - b. Item 39: Cylinder 2, 3 oxygen sensor (front)
 - c. Item 59: Cylinder 1, 4 oxygen sensor (rear)
 - d. Item 69: Cylinder 2, 3 oxygen sensor (rear)

Q: Are the check results normal?

YES : Go to Step 10 .

NO : Perform the diagnosis code classified check Procedure for the sensor that has shown an abnormal data value (Refer to Inspection Chart for Diagnosis Code [P.13C-21](#)).

STEP 10. Check purge control solenoid valve itself.

- Check purge control solenoid valve itself (Refer to GROUP 17 –Emission Control System – Evaporative Emission Control System –Purge Control Solenoid Valve Check [P.17-42](#)).

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Replace purge control solenoid valve.

STEP 11. Check EGR valve (stepper motor) itself.

- Check EGR valve (stepper motor) itself [Refer to GROUP 17 –Emission Control System – Exhaust Gas Recirculation (EGR) System –EGR Valve (Stepper Motor) Check [P.17-44](#)].

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Replace EGR valve (stepper motor).

STEP 12. Fuel pressure measurement.

- Fuel pressure measurement (Refer to Fuel Pressure Test [P.13C-335](#)).

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Repair.

STEP 13. Check positive crankcase ventilation valve itself.

- Check positive crankcase ventilation valve itself (Refer to GROUP 17 –Emission Control System –crankcase Emission Control System –Positive Crankcase Ventilation (PCV) Valve Check [P.17-40](#)).

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Replace positive crankcase ventilation valve.

STEP 14. Check spark plug.**Q: Is the check result normal?**

YES : Go to Step 15 .

NO : Replace spark plug.

STEP 15. Check ignition coil itself.

- Check ignition coil itself (Refer to GROUP 16 – Ignition System –On-vehicle Service –Ignition Coil Check [P.16-29](#)).

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Replace ignition coil.

STEP 16. Check compression pressure.

- Check compression pressure (Refer to GROUP 11A –On-vehicle Service –Compression Pressure Check [P.11A-14](#)).

Q: Is the check result normal?

YES : Go to Step 17 .

NO : Repair.

STEP 17. Check injector for spraying condition.

- Check each injector for spray condition (Refer to [P.13C-344](#)).

Q: Does trouble symptom persist?

YES : Go to Step 18 .

NO : Replace injector.

STEP 18. Replace catalytic converter.

- After replacing the catalytic converter, re-check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Check end

Inspection Procedure 18: Battery Run Down**COMMENT ON TROUBLE SYMPTOM**

- Failure is possibly caused by failed alternator, failed generation control circuit or other faults.

PROBABLE CAUSES

- Failed battery
- Alternator G terminal short-circuited
- Failed alternator
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Check battery voltage.**


- Measure battery voltage during cranking.

OK: 8 V or more

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check battery (Refer to GROUP 54A – Battery –On-vehicle Service –Battery Test [P.54A-6](#)).


STEP 2. Connector check: B-119 alternator connector

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Perform voltage measurement at B-119 alternator connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 5 .

NO : Go to Step 4 .

STEP 4. Connector check: C-02 combination meter connector




Q: Is the check result normal?

YES : Check intermediate connectors A-19 and C-125, and repair if necessary. If intermediate connectors are normal, check and repair harness between B-119 (terminal No. 3) alternator connector and C-02 (terminal No. 35) Combination meter connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.


STEP 5. Connector check: C-111 engine-A/T-ECU connector



Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

STEP 6. Perform voltage measurement at C-111 engine-A/T-ECU connector

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 45 and earth.

OK: System voltage



Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 7 .

STEP 7. Check harness between C-111 (terminal No. 45) engine-A/T-ECU and B-119 (terminal No. 1) alternator connector.

NOTE: Before checking harness, check intermediate connector B-17, and repair if necessary.




- Check output line for open/short circuit.

Q: Is the check result normal?

YES : replace alternator.

NO : Repair.

STEP 8. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Engine: Idling after warm-up
- Transmission: P range
- Radiator fan: Inactive
- Voltage between terminal No. 45 and earth.

OK: Switching the headlamps to ON from OFF causes the voltage to increase.

Q: Is the check result normal?

YES : Go to Step 9 .

NO : Replace alternator.

STEP 9. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

Inspection Procedure 19: Overheating

COMMENT ON TROUBLE SYMPTOM

- Failure is possibly caused by failed engine cooling system, failed fan controller, failed engine coolant temperature sensor or other faults.

PROBABLE CAUSES

- Insufficient or deteriorated engine coolant
- Failed fan controller
- Failed engine coolant temperature sensor
- Failed thermostat
- Failed water pump
- Failed radiator core
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. M.U.T.-III diagnosis code

Q: Diagnosis code set?

YES : Inspection chart for diagnosis code (Refer to [P.13C-21](#)).

NO : Go to Step 2 .

STEP 2. Check engine coolant

NOTE: If engine coolant level falls too early, check for leaky spots, and repair if necessary.

- Check engine coolant (Refer to GROUP 14 – On-vehicle Service –Engine Coolant Leak Check [P.14-18](#)).

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Replace or add engine coolant.

STEP 3. M.U.T.-III actuator test

- Item 21: Fan controller

OK: Fan motor rotating

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Check fan control relay system (Refer to Inspection Procedure 23 [P.13C-291](#)).

STEP 4. M.U.T.-III data list


- Item 21: Engine coolant temperature sensor

OK:**Engine cold state: At ambient temperature (atmospheric temperature) or equivalent.****Engine hot state: At 80 –120° C****Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Check engine coolant temperature sensor system (Refer to Code No. P0115 [P.13C-36](#)).**STEP 5. Check thermostat.**

- Check thermostat (Refer to GROUP 14 –Thermostat –Thermostat Inspection [P.14-22](#)).

Q: Is the check result normal?**YES :** Go to Step 6 .**NO :** Replace thermostat.**STEP 6. Check water pump.**

- Check water pump.

Q: Is the check result normal?**YES :** Replace radiator.**NO :** Replace water pump.**Inspection Procedure 20: Abnormal Rotation of Fan Motor****Fan controller (Radiator fan, A/C condensor fan) circuit**

Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- The control (duty) signal is inputted to the fan controller (terminal No. 2) from the engine-A/T-ECU (terminal No. 17).

FUNCTION


- The engine-A/T-ECU inputs a duty signal suitable for the engine coolant temperature, vehicle speed and A/C switch position to the fan controller. In response to the signal, the fan controller controls the rotating speeds of the radiator fan and A/C condenser fan (The fan speed becomes higher as the average voltage of the terminal comes nearer to 5V).

PROBABLE CAUSES

- Failed fan controller
- Open/short circuit in fan controller circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Connector check: C-110 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 2 .

NO : Repair or replace.

STEP 2. Check at C-110 engine-A/T-ECU connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Short-circuit terminal No. 17 to earth.

OK: Fan motor stops rotating.

Q: Is the check result normal?

YES : Go to Step 3 .


NO : Go to Step 4 .

STEP 3. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 4. Perform voltage measurement at C-110 engine-A/T-ECU connector.


- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 17 and earth.

OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Replace fan controller.



NO : Go to Step 5 .

STEP 5. Connector check: A-26 fan controller connector

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

STEP 6. Check harness between A-26 (terminal No. 2) fan controller connector and C-110 (terminal No. 17) engine-A/T-ECU connector.

NOTE: Before checking harness, check intermediate connector A-16, and repair if necessary.

- Check output line for open circuit.


Q: Is the check result normal?

YES : Replace fan controller.

NO : Repair.

Inspection Procedure 21: Engine-A/T-ECU Power Supply, Engine Control Relay, Ignition Switch-IG1 System

Power supply and ignition switch-IG circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION

- The battery voltage is applied to the engine control relay (terminal No. 3 and 4).
- The engine-A/T-ECU (terminal No. 57) makes the power transistor in the unit be in "ON" position and makes currents go on the engine control relay coil, and that makes the relay be in "ON" position.
- When the engine control relay is in "ON" position, the battery voltage is supplied to the engine-A/T-ECU (terminal No. 34 and No. 43), the sensor and the actuator from the engine control relay (terminal No. 1).

FUNCTION

- When the ignition switch ON signal is input to the engine-A/T-ECU, the engine-A/T-ECU places the engine control relay in the ON position. Accordingly, the battery voltage is supplied to the engine-A/T-ECU, sensor and actuator.

PROBABLE CAUSES

- Failed engine control relay
- Open/short circuit in engine control relay circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Check battery voltage.**


- Measure battery voltage during cranking.

OK: 8 V or more

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Check battery (Refer to GROUP 54A – Battery –On-vehicle Service –Battery test P.54A-6).

STEP 2. Connector check: B-15X engine control relay connector**Q: Is the check result normal?**

YES : Go to Step 3 .

NO : Repair or replace.


STEP 3. Check engine control relay.

- Check engine control relay (Refer to P.13C-340).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace engine control relay.

STEP 4. Perform voltage measurement at B-15X engine control relay connector.

- Remove relay, and measure at relay box side.
- Voltage between terminal No. 3 and earth, also between terminal No. 4 and earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 5 .

NO : Check intermediate connector A-16, and repair if necessary. If intermediate connector is normal, check and repair harness between B-15X (terminal No. 3 and terminal No. 4) engine control relay connector and battery.

- Check power supply line for open/short circuit.

STEP 5. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 34 and earth, also between terminal No. 43 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Check and repair C-111 engine-A/T-ECU connector.

NO : Go to Step 6 .

STEP 6. Connector check: C-111 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 7 .

NO : Repair or replace.

STEP 7. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 50 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Go to Step 8 .

STEP 8. Connector check: C-307 ignition switch connector



Q: Is the check result normal?

YES : Go to Step 9 .

NO : Repair or replace.

STEP 9. Check ignition switch.



- Check ignition switch (Refer to GROUP 54A – Ignition Switch – Ignition Switch – Inspection P.54A-49).

Q: Is the check result normal?

YES : Check intermediate connectors C-18, C-205 and C-202, and repair if necessary. If intermediate connectors are normal, check and repair harness between C-307 (terminal No. 2) ignition switch connector and C-111 (terminal No. 50) engine-A/T-ECU connector.

- Check output line for open/short circuit and damage.

NO : Replace ignition switch.

STEP 10. Perform voltage measurement at C-111 engine-A/T-ECU connector.

- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: OFF
- Voltage between terminal No. 57 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Check and repair harness between B-15X (terminal No. 2) engine control relay connector and C-111 (terminal No. 57) engine-A/T-ECU connector.

- Check earthing line for open/short circuit.

STEP 11. Check harness between B-15X (terminal No. 3 and No. 4) engine control relay connector and battery.

NOTE: Before checking harness, check intermediate connector A-16, and repair if necessary.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair.

STEP 12. Check harness between C-307 (terminal No. 2) ignition switch connector and C-111 (terminal No. 50) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connectors C-18, C-205 and C-202, and repair if necessary.


- Check output line for damage.

Q: Is the check result normal?

YES : Go to Step 13 .

NO : Repair.

STEP 13. Perform resistance measurement at C-111 engine-A/T-ECU connector.





- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 33, No. 42 and earth.

OK: 2 Ω or less

Q: Are the check results normal?

YES : Replace engine-A/T-ECU

NO : Go to Step 14

STEP 14. Connector check: C-115 earth connector.**Q: Is the check result normal?**


YES : Check and repair harness between C-111 engine-A/T-ECU connector and C-115 earth connector.

- a. Check and repair harness between C-111 (terminal No. 33) engine-A/T-ECU connector and C-115 (terminal No. 10) earth connector.
 - b. Check and repair harness between C-111 (terminal No. 42) engine-A/T-ECU connector and C-115 (terminal No. 9) earth connector.
- Check earthing line for open circuit and damage.

NO : Repair

Inspection Procedure 22: Fuel Pump System

Fuel pump and gauge unit (main) circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION


- The battery voltage is applied to the fuel pump relay (1) (terminal No. 3) from the ignition switch and is earthed to the vehicle body from the fuel pump relay (1) (terminal No. 2).
- The battery voltage is applied to the fuel pump relay (1) (terminal No. 4) and to the fuel pump relay (2) (terminal No. 1) from the fuel pump relay (1) (terminal No. 1).
- The battery voltage is applied to the fuel pump relay (2) (terminal No. 3) from the ignition switch. The engine-A/T-ECU (terminal No. 16) makes the power transistor in the unit be in ON position and makes currents go on the fuel pump relay (2) coil, and that makes the relay be in ON position.
- When the fuel pump relay (2) is in ON position, the battery voltage is supplied to the fuel pump (low pressure) from the fuel pump relay (2) (terminal No. 4).

FUNCTION


- When the ignition switch ON signal is input to the engine-A/T-ECU, the engine-A/T-ECU places the fuel pump relay in the ON position. Accordingly, the battery voltage is supplied to the fuel pump.

PROBABLE CAUSES

- Failed fuel pump relay
- Failed fuel pump
- Open/short circuit in fuel pump drive circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Connector check: C-216 fuel pump relay (1) connector and C-214 fuel pump relay (2) connector****Q: Is the check result normal?****YES :** Go to Step 2 .**NO :** Repair or replace.**STEP 2. Check fuel pump relay.**

- Fuel pump relay, continuity check (Refer to P.13C-340).

Q: Is the check result normal?**YES :** Go to Step 3 .**NO :** Replace fuel pump relay.**STEP 3. Perform resistance measurement at C-216 fuel pump relay (1) connector.**


- Remove relay, and measure at junction block side.
- Resistance between terminal No. 2 and earth.

OK: 2 Ω or less**Q: Is the check result normal?****YES :** Go to Step 4 .

NO : Check intermediate connectors C-205 and C-49, and repair if necessary. If intermediate connectors are normal, check and repair harness between C-216 (terminal No. 2) fuel pump relay (1) connector and body earth.

- Check earthing line for open circuit and damage.

STEP 4. Perform voltage measurement at C-216 fuel pump relay (1) connector.



- Remove relay, and measure at junction block side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Go to Step 5 .

STEP 5. Connector check: C-307 ignition switch connector




Q: Is the check result normal?

YES : Check intermediate connector C-202, and repair if necessary. If intermediate connector is normal, check and repair harness between C-216 (terminal No. 3) fuel pump relay (1) connector and C-307 (terminal No. 2) ignition switch connector.

- Check power supply line for open circuit and damage.

NO : Repair or replace.

STEP 6. Perform voltage measurement at C-216 fuel pump relay (1) connector.



- Remove relay, and measure at junction block side.
- Voltage between terminal No. 4 and earth.


OK: System voltage

Q: Is the check result normal?



YES : Go to Step 7 .

NO : Check intermediate connectors C-125 and C-203, and repair if necessary. If intermediate connectors are normal, check and repair harness between C-216 (terminal No. 4) fuel pump relay (1) connector and battery.

- Check power supply line for open/short circuit.


STEP 7. Perform voltage measurement at C-214 fuel pump relay (2) connector.

- Remove relay, and measure at junction block side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.



OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 9 .**NO :** Go to Step 8 .**STEP 8. Connector check: C-307 ignition switch connector****Q: Is the check result normal?**

YES : Check intermediate connector C-202, and repair if necessary. If intermediate connector is normal, check and repair harness between C-307 (terminal No. 2) ignition switch connector and C-214 (terminal No. 3) fuel pump relay (2) connector.

- Check power supply line for open circuit.

NO : Repair or replace.**STEP 9. Connector check: C-110 engine-A/T-ECU connector****Q: Is the check result normal?****YES :** Go to Step 10 .**NO :** Repair or replace.

STEP 10. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 16 and earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 11 .

NO : Check intermediate connectors C-18 and C-205, and repair if necessary. If intermediate connectors are normal, check and repair harness between C-214 (terminal No. 2) fuel pump relay (2) connector and C-110 (terminal No. 16) engine-A/T-ECU connector.

- Check earthing line for open/short circuit.

STEP 11. Connector check: D-15 fuel pump connector




Q: Is the check result normal?

YES : Go to Step 12 .

NO : Repair or replace.

STEP 12. Perform voltage measurement at D-15 fuel pump connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Using a jumper wire, connect C-110 (terminal No. 16) engine-A/T-ECU connector and earth.
- Voltage between terminal No. 5 and earth.


OK: System voltage

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Go to Step 13 .

STEP 13. Check harness between C-216 (terminal No. 1) fuel pump relay (1) connector and C-214 (terminal No. 1) fuel pump relay (2) connector.





- Check power supply line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 14

NO : Repair.

STEP 14. Check harness between C-214 (terminal No. 4) fuel pump relay (2) connector and D-15 (terminal No. 5) fuel pump connector.



NOTE: Before checking harness, check intermediate connectors D-210 and D-28, and repair if necessary.


- Check output line for open/short circuit and damage.

Q: Is the check result normal?

YES : Replace engine-A/T-ECU.

NO : Repair.

STEP 15. Perform resistance measurement at D-15 fuel pump connector.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 4 and earth.

OK: 2 Ω or less


Q: Is the check result normal?

YES : Go to Step 16 .

NO : Check intermediate connector D-28, and repair if necessary. If intermediate connector is normal, check and repair harness between D-15 (terminal No. 4) fuel pump connector and body earth.

- Check earthing line for open circuit and damage.

STEP 16. Connector check: C-307 ignition switch connector





Q: Is the check result normal?

YES : Go to Step 17 .

NO : Repair or replace.

STEP 17. Check harness between C-307 (terminal No. 2) ignition switch connector and C-216 (terminal No. 3) fuel pump relay (1) connector.



NOTE: Before checking harness, check intermediate connector C-202, and repair if necessary.


- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 18 .

NO : Repair.

STEP 18. Check harness between battery and C-216 (terminal No. 4) fuel pump relay (1) connector.



NOTE: Before checking harness, check intermediate connectors C-203 and C-125, and repair if necessary.


- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 19 .

NO : Repair.

STEP 19. Check harness between C-216 (terminal No. 1) fuel pump relay (1) connector and C-214 (terminal No. 1) fuel pump relay (2) connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 20 .

NO : Repair.

STEP 20. Check harness between C-307 (terminal No. 2) ignition switch connector and C-214 (terminal No. 3) fuel pump relay (2) connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 21 .

NO : Repair.

STEP 21. Check harness between C-214 (terminal No. 4) fuel pump relay (2) connector and D-15 (terminal No. 5) fuel pump connector.



NOTE: Before checking harness, check intermediate connectors D-28 and C-210, and repair if necessary.



- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 22 .

NO : Repair.

STEP 22. Check harness between C-214 (terminal No. 2) fuel pump relay (2) connector and C-110 (terminal No. 16) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connectors C-18 and C-205, and repair if necessary.

- Check earthing line for damage.


Q: Is the check result normal?

YES : Replace fuel pump.

NO : Repair.

Inspection Procedure 23: Fan Control Relay System

Fan control relay circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION


- The battery voltage is applied to the fan control relay (terminal No. 3) from the engine control relay (terminal No. 1) and is earthed to the vehicle body from the fan control relay (terminal No. 1).
- The battery voltage is applied to the fan control relay (terminal No. 4).
- When the fan control relay is in ON position, the battery voltage is supplied to the fan controller (terminal No. 3) from the fan control relay (terminal No. 2).

FUNCTION


- When the engine control relay is in ON position, the fan control relay is also simultaneously placed in "ON" position. Accordingly, the battery voltage is supplied to the fan controller.

PROBABLE CAUSES

- Failed fan control relay
- Failed fan controller
- Failed radiator fan motor
- Failed condenser fan motor
- Open/short circuit in fan control relay circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Connector check: A-13X fan control relay connector****Q: Is the check result normal?****YES :** Go to Step 2 .**NO :** Repair or replace.**STEP 2. Check fan control relay.**


- Check fan control relay (Refer to GROUP 14 – On-vehicle Service –Fan Control Relay Continuity Check P.14-20).

Q: Is the check result normal?**YES :** Go to Step 3 .**NO :** Replace fan control relay.**STEP 3. Perform resistance measurement at A-13X fan control relay connector.**

- Remove relay and measure at relay box side.
- Resistance between terminal No. 1 and earth.

OK: 2 Ω or less**Q: Is the check result normal?****YES :** Go to Step 4 .**NO :** Check and repair harness between A-13 (terminal No. 1) fan control relay connector and body earth.



- Check earth line for open circuit and damage.

STEP 4. Perform voltage measurement at A-13X fan control relay connector.

- Remove relay and measure at relay box side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 6 .**NO :** Go to Step 5 .

STEP 5. Connector check: B-15X engine control relay connector




Q: Is the check result normal?

YES : Check intermediate connectors A-16 and C-116, and repair if necessary. If intermediate connectors are normal, check and repair harness between B-15X (terminal No. 1) engine control relay connector and A-13X (terminal No. 3) fan control relay connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 6. Perform voltage measurement at A-13X fan control relay connector.



- Remove relay, and measure at relay box side.
- Voltage between terminal No. 4 and earth

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 7 .

NO : Check and repair harness between battery and A-13X (terminal No. 4) fan control relay connector.

- Check power supply line for open/short circuit.

STEP 7. Connector check: A-26 fan controller connector




Q: Is the check result normal?

YES : Go to Step 8 .

NO : Repair or replace.

STEP 8. Perform voltage measurement at A-26 fan controller connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Go to Step 9 .

STEP 9. Check harness between A-13X (terminal No. 2) fan control relay connector and A-26 (terminal No. 3) fan controller connector.




- Check power supply line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair.

STEP 10. Connector check: B-15X engine control relay connector





Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair or replace.

STEP 11. Check harness between B-15X (terminal No. 1) engine control relay connector and A-13X (terminal No. 3) fan control relay connector.



NOTE: Before checking harness, check intermediate connectors A-16 and C-116, and repair if necessary.

- Check power supply line for damage.


Q: Is the check result normal?

YES : Check and repair harness between A-13X (terminal No. 1) fan control relay connector and body earth.

- Check earthing line for damage.

NO : Repair.

STEP 12. Connector check: C-110 engine-ECU engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 13 .

NO : Repair or replace.

STEP 13. Fan motor drive test.



- Disconnect C-110 engine-A/T-ECU connector.
- Ignition switch: ON

OK: Fan motor rotates.

Q: Is the check result normal?

YES : Go to Step 14 .

NO : Go to Step 15 .

STEP 14. M.U.T.-III actuator test

- Refer to Actuator Test Reference Table

[P.13C-321](#)

a. Item 21: Fan controller


OK: Fan motor rotates.

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 15. Perform voltage measurement at C-110 engine-A/T-ECU connector.



- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 17 and earth.


OK: 4.9 –5.1 V

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Go to Step 18 .

STEP 16. Check harness between A-13X (terminal No. 4) fan control relay connector and battery.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 17 .

NO : Repair.

STEP 17. Check harness between A-13X (terminal No. 2) fan control relay connector and A-26 (terminal No. 3) fan controller connector.





- Check power supply line for damage.

Q: Is the check result normal?

YES : Replace fan motor and fan controller.
NO : Repair.

STEP 18. Check harness between A-26 (terminal No. 2) fan controller connector and C-110 (terminal No. 17) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connector A-16, and repair if necessary.


- Check earthing line for short circuit.

Q: Is the check result normal?

YES : Replace fan motor and fan controller.
NO : Repair.

Inspection Procedure 24: A/C Compressor Relay System

A/C compressor relay circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

OPERATION


- The battery voltage is applied to the A/C compressor relay (terminal No. 4).
- The battery voltage is applied to the A/C compressor relay (terminal No. 3) from the ignition switch. The engine-A/T-ECU (terminal No. 8) makes the power transistor in the unit be in ON position and makes currents go on the A/C compressor relay coil, and that makes the relay be in ON position.
- When the A/C compressor is in ON position, the battery voltage is supplied to the A/C compressor (terminal No. 1) from the A/C compressor relay assembly (terminal No. 1).

FUNCTION


- When the A/C switch ON signal is input to the engine-A/T-ECU, the engine-A/T-ECU places the A/C compressor relay in the ON position. Accordingly, the battery voltage supplied to the A/C compressor operates the magnet clutch.

PROBABLE CAUSES

- Failed A/C compressor relay
- Failed A/C compressor magnet clutch
- Open/short circuit in A/C compressor relay circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Connector check: B-16X A/C compressor relay connector****Q: Is the check result normal?****YES :** Go to Step 2 .**NO :** Repair or replace.**STEP 2. A/C compressor relay check.**



- Check A/C compressor relay (Refer to GROUP 55 –On-vehicle Service –Relay Continuity Check [P.55-208](#)).

Q: Is the check result normal?**YES :** Go to Step 3 .**NO :** Replace A/C compressor relay.**STEP 3. Perform voltage measurement at B-16X A/C compressor relay connector.**

- Remove relay, and measure at relay box side.
- Ignition switch: ON
- Voltage between terminal No. 3 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 5 .**NO :** Go to Step 4 .

STEP 4. Connector check: C-307 ignition switch connector




Q: Is the check result normal?

YES : Check intermediate connectors C-17, C-31, C-205 and C-202 and repair if necessary. If intermediate connectors are normal, check and repair harness between B-16X (terminal No. 3) A/C compressor relay connector and C-307 (terminal No. 4) ignition switch connector.

- Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 5. Perform voltage measurement at B-16X A/C compressor relay connector.



- Remove relay, and measure at relay box side.
- Voltage between terminal No. 4 and earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 6 .

NO : Check intermediate connector A-16, and repair if necessary. If intermediate connector is normal, check and repair harness between B-16X (terminal No. 4) A/C compressor relay connector and battery.

- Check power supply line for open/short circuit.



STEP 6. Connector check: B-120 A/C compressor assembly connector



Q: Is the check result normal?

YES : Go to Step 7 .


NO : Repair or replace.

STEP 7. Perform voltage measurement at B-120 A/C compressor assembly connector.


- Disconnect connector, and measure at harness side.
- Remove B-16X (terminal No. 1 and No. 4) A/C compressor relay and short-circuit of harness side connector.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 8 .**NO :** Check and repair harness between B-120 (terminal No. 1) A/C compressor assembly connector and B-16X (terminal No. 1) A/C compressor relay connector.



- Check output line for open/short circuit.

STEP 8. Perform voltage measurement at C-110 engine-A/T-ECU connector.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 8 and earth.

OK: System voltage**Q: Is the check result normal?****YES :** Go to Step 12 .**NO :** Go to Step 9 .**STEP 9. Connector check: C-110 engine-A/T-ECU connector****Q: Is the check result normal?****YES :** Go to Step 10 .**NO :** Repair or replace.

STEP 10. Check harness between B-16X (terminal No. 2) A/C compressor relay connector and C-110 (terminal No. 8) engine-A/T-ECU connector.



- Check earthing line for open/short circuit.

Q: Is the check result normal?

YES : Go to Step 11 .

NO : Repair.

STEP 11. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#)
 - Item 49: A/C relay
 - Engine: Idling
 - A/C set temperature:
 - Maximum Cool when temperature in cabin is 25° C or more
 - Maximum Hot when temperature in cabin is 25° C or less

OK:

ON (when A/C is ON)


OFF (when A/C is OFF)

Q: Is the check result normal?

YES : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

STEP 12. Connector check: C-110 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 13 .

NO : Repair or replace.

STEP 13. Check harness between B-16X (terminal No. 2) A/C compressor relay connector and C-110 (terminal No. 8) engine-A/T-ECU connector.




- Check earthing line for damage.

Q: Is the check result normal?

YES : Go to Step 14 .



NO : Repair.

STEP 14. Connector check: C-307 ignition switch connector

Q: Is the check result normal?

YES : Go to Step 15 .

NO : Repair or replace.

STEP 15. Check harness between C-307 (terminal No. 4) ignition switch connector and B-16X (terminal No. 3) A/C compressor relay connector.


NOTE: Before checking harness, check intermediate connectors C-17, C-31, C-205 and C-202, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 16 .

NO : Repair.

STEP 16. Check harness between battery and B-16X (terminal No. 4) A/C compressor relay connector.



NOTE: Before checking harness, check intermediate connector A-16, and repair if necessary.

- Check power supply line for damage.

Q: Is the check result normal?

YES : Go to Step 17 .

NO : Repair.

STEP 17. Check harness between B-16X (terminal No. 1) A/C compressor relay connector and B-120 (terminal No. 1) A/C compressor assembly connector.

- Check output line for damage.


Q: Is the check result normal?

YES : Replace A/C compressor magnet clutch.

NO : Repair.

Inspection Procedure 25: Ignition Circuit System

Ignition circuit



OPERATION

- The battery voltage is applied to the ignition coil (terminal No. 1) from the ignition switch and is earthed to the vehicle body from the ignition coil (terminal No. 2).
- A power voltage of 12 V is applied to the ignition coil output terminal (terminal No. 3) from the engine-A/T-ECU (terminals No. 31, No. 32, No. 35 and No. 52).

FUNCTION

- When the engine-A/T-ECU makes the power transistor in the unit be in OFF position, the battery voltage in the unit is applied to the power transistor unit, and that makes the power transistor unit be in ON position. The engine-A/T-ECU makes the power transistor in the unit be in ON, and that makes the power transistor unit be in OFF position.
- In response to the signal from the engine-A/T-ECU, the power transistor unit is in ON position. The primary current is going to the ignition coil. When the power transistor unit is in OFF position, the primary current is interrupted and high voltage is generated in the secondary coil.

PROBABLE CAUSES


- Failed ignition coil
- Failed spark plug
- Failed spark plug cable
- Open/short circuit in ignition primary circuit or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE**STEP 1. Check spark plug.**

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Replace spark plug.

STEP 2. Connector check: B-02, B-03, B-04 and B-05 ignition coil connectors

Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.


STEP 3. Check ignition coil itself.

- Check ignition coil itself (Refer to GROUP 16 – Ignition System –On-vehicle Service –Ignition coil check [P.16-29](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace ignition coil.

STEP 4. Perform voltage measurement at B-02, B-03, B-04 and B-05 ignition coil connectors.

- Disconnect connector, and measure at harness side.
- Ignition switch: ON
- Voltage between terminal No. 1 and earth.



OK: System voltage

Q: Is the check result normal?

YES : Go to Step 6 .

NO : Go to Step 5 .

STEP 5. Connector check: C-307 ignition switch connector




Q: Is the check result normal?

YES : Check intermediate connectors C-18, C-202 and C-205, and repair if necessary. If intermediate connectors are normal, check and repair harness between ignition switch connector and ignition coil connector

- a. Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-02 (terminal No. 1) No. 1 ignition coil connector
- b. Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-03 (terminal No. 1) No. 2 ignition coil connector
- c. Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-04 (terminal No. 1) No. 3 ignition coil connector
- d. Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-05 (terminal No. 1) No. 4 ignition coil connector
 - Check power supply line for open/short circuit.

NO : Repair or replace.

STEP 6. Perform voltage measurement at B-02, B-03, B-04 and B-05 ignition coil connectors.





- Disconnect connector, and measure at harness side.
- Engine: Cranking
- Voltage between terminal No. 3 and earth.

OK: 0.3 –3.0 V

Q: Is the check result normal?

YES : Go to Step 12 .

NO : Go to Step 7 .

STEP 7. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Disconnect B-02, B-03, B-04 and B-05 ignition coil connectors.
- Engine: Cranking
 - a. Voltage between terminal No. 31 and earth (No. 1 Ignition coil).
 - b. Voltage between terminal No. 32 and earth (No. 2 Ignition coil).
 - c. Voltage between terminal No. 35 and earth (No. 3 Ignition coil).
 - d. Voltage between terminal No. 52 and earth (No. 4 Ignition coil).

OK: 0.3 –3.0 V

Q: Are the check results normal?

YES : Go to Step 8 .

NO : Go to Step 9 .


STEP 8. Connector check: C-111 engine-A/T-ECU connector**Q: Is the check result normal?**

YES : Check and repair harness between ignition coil connector and engine-A/T-ECU connector

- a. Check and repair harness between B-02 (terminal No. 3) No. 1 ignition coil connector and C-111 (terminal No. 31) engine-A/T-ECU connector.
- b. Check and repair harness between B-03 (terminal No. 3) No. 2 ignition coil connector and C-111 (terminal No. 32) engine-A/T-ECU connector.
- c. Check and repair harness between B-04 (terminal No. 3) No. 3 ignition coil connector and C-111 (terminal No. 35) engine-A/T-ECU connector.
- d. Check and repair harness between B-05 (terminal No. 3) No. 4 ignition coil connector and C-111 (terminal No. 52) engine-A/T-ECU connector.
 - Check output line for open circuit.

NO : Repair or replace.

STEP 9. Connector check: C-111 engine-A/T-ECU connector





Q: Is the check result normal?

YES : Go to Step 10 .

NO : Repair or replace.

STEP 10. Check harness between ignition coil connector and engine-A/T-ECU connector.



- Check and repair harness between B-02 (terminal No. 3) No. 1 ignition coil connector and C-111 (terminal No. 31) engine-A/T-ECU connector.
- Check and repair harness between B-03 (terminal No. 3) No. 2 ignition coil connector and C-111 (terminal No. 32) engine-A/T-ECU connector.
- Check and repair harness between B-04 (terminal No. 3) No. 3 ignition coil connector and C-111 (terminal No. 35) engine-A/T-ECU connector.
- Check and repair harness between B-05 (terminal No. 3) No. 4 ignition coil connector and C-111 (terminal No. 52) engine-A/T-ECU connector.
 - Check output line for short circuit.

Q: Are the check results normal?

YES : Go to Step 11 .

NO : Repair.


STEP 11. Check the trouble symptoms.

Q: Does trouble symptom persist?

YES : Replace engine-A/T-ECU.

NO : Intermittent malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

STEP 12. Perform resistance measurement at B-02, B-03, B-04 and B-05 ignition coil connectors.



- Disconnect connector, and measure at harness side.
- Resistance between terminal No. 2 and earth.

OK: 2 Ω or less



Q: Is the check result normal?

YES : Go to Step 13.

NO : Check and repair harness between ignition coil connector and body earth

- Check and repair harness between B-02 (terminal No. 2) No. 1 ignition coil connector and body earth
- Check and repair harness between B-03 (terminal No. 2) No. 2 ignition coil connector and body earth
- Check and repair harness between B-04 (terminal No. 2) No. 3 ignition coil connector and body earth
- Check and repair harness between B-05 (terminal No. 2) No. 4 ignition coil connector and body earth
 - Check earthing line for open circuit and damage.

STEP 13. Check harness between ignition switch connector and ignition coil connector.



- Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-02 (terminal No. 1) No. 1 ignition coil connector
- Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-03 (terminal No. 1) No. 2 ignition coil connector
- Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-04 (terminal No. 1) No. 3 ignition coil connector
- Check and repair harness between C-307 (terminal No. 2) ignition switch connector and B-05 (terminal No. 1) No. 4 ignition coil connector

NOTE: Before checking harness, check intermediate connectors C-18, C-202 and C-205, and repair if necessary.



- Check power supply line for damage.

Q: Are the check results normal?

YES : Go to Step 14 .

NO : Repair.

STEP 14. Check harness between ignition coil connector and engine-A/T-ECU connector.



- Check and repair harness between B-02 (terminal No. 3) No. 1 ignition coil connector and C-111 (terminal No. 31) engine-A/T-ECU connector.
- Check and repair harness between B-03 (terminal No. 3) No. 2 Ignition coil connector and C-111 (terminal No. 32) engine-A/T-ECU connector.
- Check and repair harness between B-04 (terminal No. 3) No. 3 ignition coil connector and C-111 (terminal No. 35) engine-A/T-ECU connector.
- Check and repair harness between B-05 (terminal No. 3) No. 4 ignition coil connector and C-111 (terminal No. 52) engine-A/T-ECU connector.
 - Check output line for damage.


Q: Are the check results normal?

YES : Go to Step 11 .

NO : Repair.

Inspection Procedure 26: Stop Lamp Switch System

Stop Lamp Switch Circuit



Wire colour code

B: Black LG: Light green G: Green L: Blue W: White Y: Yellow SB: Sky blue BR: Brown O: Orange GR: Gray
R: Red P: Pink V: Violet PU: Purple

AK501592AB

OPERATION

- The battery voltage is applied to the stop lamp switch (terminal No.2).
- The stop lamp switch output terminal (terminal No.1) inputs the switch signal to the engine-A/T-ECU (terminal No. 39).

FUNCTION

- The system checks whether the vehicle has the illuminating stop lamp or not, and inputs the signal to the engine-A/T-ECU. The engine-A/T-ECU knows the vehicle state through the stop lamp switch signal and carries out control of the each system.

POSSIBLE CAUSES

- Failed stop lamp switch
- Open/short circuit in stop lamp switch or loose connector contact
- Failed engine-A/T-ECU

DIAGNOSIS PROCEDURE

STEP 1. Check for height of brake pedal.


- Check for height of brake pedal (Refer to Group 35A –On-vehicle Service –Brake Pedal Check And Adjustment [P.35A-4](#)).

Q: Is the check result normal?

YES : Go to Step 2 .

NO : Adjust.

STEP 2. Connector check: C-127 stop lamp switch connector



Q: Is the check result normal?

YES : Go to Step 3 .

NO : Repair or replace.

STEP 3. Check the stop lamp switch.


- Check the stop lamp switch (Refer to Group 35A –Brake Pedal Inspection [P.35A-14](#)).

Q: Is the check result normal?

YES : Go to Step 4 .

NO : Replace stop lamp switch.

STEP 4. Perform voltage measurement at C-127 stop lamp switch connector



- Disconnect the connector and measure it at harness side.
- Voltage between terminal No. 2 and earth.

OK: System voltage


Q: Is the check result normal?

YES : Go to Step 5 .

NO : Check for the intermediate connector C-125, and repair if necessary. If intermediate connector is normal, check and repair harness between C-127 (terminal No.2) stop lamp switch connector and battery.

- Check power supply line open/short circuit supply.

STEP 5. Connector check: C-111 engine-A/T-ECU connector




Q: Is the check result normal?

YES : Go to Step 6 .

NO : Repair or replace.

STEP 6. Perform voltage measurement at C-111 engine-A/T-ECU connector.



- Measure engine-A/T-ECU terminal voltage.
- Ignition switch: ON
- Voltage between terminal No. 39 and the earth.

OK:



System voltage (Brake pedal: Depressed)
1V or less (Brake pedal: Released)

Q: Is the check result normal?

YES : Go to Step 8 .

NO : Go to Step 7 .

STEP 7. Check harness between C-127 (terminal No. 1) stop lamp switch connector and C-111 (terminal No. 39) engine-A/T-ECU connector.



NOTE: Before checking harness, check intermediate connectors C-18 and C-32, and repair if necessary.

- Check output line open/short circuit.

Q: Is the check result normal?

YES : For a short circuit, check and repair harness and the connector for the stop lamp switch output signal.

NO : Repair.

STEP 8. M.U.T.-III data list

- Refer to Data List Reference Table [P.13C-313](#).
 - Item 67: Stop lamp switch

Q: Is the check result normal?

YES : Intermittent Malfunction (Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points [P.00-5](#)).

NO : Replace engine-A/T-ECU.

Data List Reference Table

M1131152002087

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
11	Cylinder 1,4 oxygen sensor (front)	Engine: After warm-up (leaner by deceleration, richer by acceleration)	Excessive deceleration from 4,000 r/min	200 mV or less	Code No. P0130	P.13C-54
			At excessive acceleration	600 –1,000 mV		
		Engine: After warm-up (using oxygen sensor, check air-fuel ratio as well as control status by engine-A/T-ECU.	Idle operation	400 mV or less		
			2,500 r/min	⇔ 600 – 1,000 mV (altered)		
12	Air flow sensor *1	<ul style="list-style-type: none"> Engine coolant temperature: 85 – 95° C Lamps, electric cooling fan and all accessories: OFF Transmission: "P" range 	Idle operation	2.0 –4.0 gm/s	–	–
			2,500 r/min	6.5 –12.0 gm/s		
			Acceleration	According to acceleration, frequency is amplified.		
13	Intake air temperature sensor	Ignition switch: ON or engine running	Intake air temperature: -20° C	-20° C	Code No. P0110	P.13C-30
			Intake air temperature: 0° C	0° C		
			Intake air temperature: 20° C	20° C		
			Intake air temperature: 40° C	40° C		
			Intake air temperature: 80° C	80° C		
14	Throttle position sensor (sub) *4	<ul style="list-style-type: none"> Remove the intake air hose at the throttle body Disconnect the throttle position sensor, and the connect terminal numbers No. 3, No. 4, No. 5 and No. 6 with the use of the special tool: MB991658. Ignition switch: ON 	Fully close the throttle valve with your finger	2,200 – 2,800 mV	Code No. P0222, P0223	P.13C-122 P.13C-126
			Fully open the throttle valve with your finger	4,000 mV or more		

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
16	Power supply voltage	Ignition switch: "ON"		System voltage	Procedure No. 21	P.13C-277
18	Cranking signal (ignition switch-ST)	Ignition switch: ON	Engine: Stopped	OFF	Procedure No. 21	P.13C-277
			Engine: Cranking	ON		
21	Engine coolant temperature sensor	Ignition switch: ON or engine running	Coolant temperature: -20° C	-20° C	Code No. P0115	P.13C-36
			Coolant temperature: 0° C	0° C		
			Coolant temperature: 20° C	20° C		
			Coolant temperature: 40° C	40° C		
			Coolant temperature: 80° C	80° C		
22	Crank angle sensor	<ul style="list-style-type: none"> Engine: Cranking Tachometer: Connected 	Compare engine speed on tachometer with the value displayed on M.U.T.-III	Matched	Code No. P0335	P.13C-143
		Engine: Idle operation	Coolant temperature: -20° C	1,300 – 1,500 r/min		
			Coolant temperature: 0° C	1,270 – 1,470 r/min		
			Coolant temperature: 20° C	1,230 – 1,430 r/min		
			Coolant temperature: 40° C	1,140 – 1,340 r/min		
			Coolant temperature: 90° C	600 – 800 r/min		
25	Barometric pressure sensor	Ignition switch: ON	Altitude: 0m	101 kPa	–	–
			Altitude: 600m	95 kPa		
			Altitude: 1,200m	88 kPa		
			Altitude: 1,800m	81 kPa		
29	Inhibitor switch	Ignition switch: ON	Selector lever: P or N	P, N	Procedure No. 4	P.13C-249
			Selector lever: D, 2, L, or R	D, 2, L, R		

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
37	Volumetric efficiency	<ul style="list-style-type: none"> Engine coolant temperature: 85 – 95° C Lamps, electric cooling fan and all accessories: OFF Transmission: "P" range 	Idle operation	15 –35 %	—	—
			2,500 r/min	15 –35 %		
			Excessive acceleration	According to acceleration, volumetric efficiency is increased.		
39	Cylinder 2,3 oxygen sensor (front)	Engine: After warm-up (leaner by deceleration, richer acceleration)	Excessive deceleration from 4,000 r/m	200 mV or less	Code No. P0150	P.13C-76
			At excessive acceleration	600 – 1,000 mV		
		Engine: After warm-up (using oxygen sensor, check air-fuel ratio as well as control status by engine-A/T-ECU	Idle operation	400 mV or less		
			2,500 r/min	⇔ 600 – 1,000 mV (altered)		
41	Injectors* ³	<ul style="list-style-type: none"> Engine coolant temperature: 80 – 95° C Lamps, electric cooling fan and all accessories: OFF Transmission: "P" range 	Idle operation	2.0 –3.2 ms	—	—
			2,500 r/min	1.7 –2.9 ms		
			Excessive acceleration	Increased		
44	Ignition advance	<ul style="list-style-type: none"> Engine: After warm-up Install timing light (for use to measure actual ignition timing) 	Idle operation	2 –18° BTDC	Procedure No. 25	P.13C-303
			2,500 r/min	26 –46° BTDC		
49	A/C relay	Engine: After warm-up, idle operation after warm-up	A/C switch: OFF	OFF	Procedure No. 24	P.13C-297
			A/C switch : ON	A/C compressor is not driven		
				A/C compressor is driven		
59	Cylinder 1,4 Oxygen Sensor (rear)	Engine: After warm-up	At excessive acceleration (during the increase in the engine speed)	0 mV or less ⇔ 600 – 1,000 mV (altered)	Code No. P0136	P.13C-64

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
67	Stop lamp switch	Ignition switch: ON	Brake pedal: Depressed	ON	Procedure No. 26	P.13C-310
			Brake pedal: Released	OFF		
68	EGR valve	<ul style="list-style-type: none"> Engine coolant temperature: 85 – 95° C Lights and all accessories: OFF Transmission: "P" range 	Idling	3 STEP	Code No. P0403	P.13C-159
			2,500 r/min	3 – 22 STEP		
69	Cylinder 2,3 oxygen sensor (rear)	Engine: After warm-up	At excessive acceleration (during the increase in the engine speed)	0 mV or less ⇔ 600 – 1,000 mV (altered)	Code No. P0156	P.13C-88
77	Accelerator pedal position sensor (sub)	Ignition switch: ON	Release the accelerator pedal	400 – 1,000 mV	Code No. P2127, P2128	P.13C-223 P.13C-227
			Depress the accelerator pedal gradually	Increases in response to the pedal depression stroke		
			Depress the accelerator pedal fully	3,600 mV or more		
78	Accelerator pedal position sensor (main)	Ignition switch: ON	Release the accelerator pedal	800 – 1,200 mV	Code No. P2122, P2123	P.13C-217 P.13C-221
			Depress the accelerator pedal gradually	Increases in response to the pedal depression stroke		
			Depress the accelerator pedal fully	4,000 mV or more		

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
79	Throttle position sensor (main)	<ul style="list-style-type: none"> Remove the intake air hose at the throttle body Disconnect the throttle position sensor, and then connect terminal numbers No. 3, No. 4, No. 5 and No. 6 with the use of the special tool: MB991658. Ignition switch: ON 	Fully close the throttle valve with your finger	300 –700 mV	Code No. P0122, P0123	P.13C-42 P.13C-46
			Fully open the throttle valve with your finger	4,000 mV or more		
		No load		500 –700 mV		
		• Shift lever: "N" →"D"		Voltage rises		
B4	Power steering fluid pressure sensor	Engine: Idle operation	Steering wheel: Not operated	400 – 1,000 mV	Code No. P0551	P.13C-174
			Steering wheel: Operated	Voltage rises		
			Full lock	3,000 – 4,000 mV		
12 *5	Air flow sensor	<ul style="list-style-type: none"> Engine coolant temperature: 85 – 95° C Lamps, electric cooling fan and all accessories: OFF Transmission: "P" range 	Idle operation	2.0 –4.0 gm/s	–	–
			2,500 r/min	6.5 – 12.0 gm/s		
			Acceleration	According to acceleration, frequency is amplified.		
13 *5	Intake air temperature sensor	Ignition switch: ON or engine running	Intake air temperature: -20° C	-20° C	Code No. P0110	P.13C-30
			Intake air temperature: 0° C	0° C		
			Intake air temperature: 20° C	20° C		
			Intake air temperature: 40° C	40° C		
			Intake air temperature: 80° C	80° C		

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
21 *5	Engine coolant temperature sensor	Ignition switch: ON or engine running	Coolant temperature: -20° C	-20° C	Code No. P0115	P.13C-36
			Coolant temperature: 0° C	0° C		
			Coolant temperature: 20° C	20° C		
			Coolant temperature: 40° C	40° C		
			Coolant temperature: 80° C	80° C		
22 *5	Crank angle sensor	<ul style="list-style-type: none"> Engine: Cranking Tachometer: Connected 	Compare engine speed on tachometer with the value displayed on M.U.T.-III	Matched	—	—
		Engine: Idle operation	Coolant temperature: -20° C	1,300 – 1,500 r/min		
			Coolant temperature: 0° C	1,270 – 1,470 r/min		
			Coolant temperature: 20° C	1,230 – 1,430 r/min		
			Coolant temperature: 40° C	1,140 – 1,340 r/min		
			Coolant temperature: 90° C	600 – 800 r/min		
24 *5	Vehicle speed sensor	Drive 40 km/h		Approximately 40 km/h	—	—
44 *5	Ignition advance	<ul style="list-style-type: none"> Engine: After warm-up Install timing light (for use to measure actual ignition timing) 	Idle operation	2 – 18 deg	—	—
			2,500 r/min	26 – 46 deg		
81 *5	Long-term fuel compensation cylinder 1, 4	Engine: After warm-up, 2,500 r/min without any load (during closed loop)		-13 to 13 %	Code No. P0170	P.13C-100
82 *5	Short-term fuel compensation cylinder 1, 4	Engine: After warm-up, 2,500 r/min without any load (during closed loop)		-10 to 10 %	Code No. P0170	P.13C-100

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
83 *5	Long-term fuel compensati on cylinder 2, 3	Engine: After warm-up, 2,500 r/min without any load (during closed loop)		-13 to 13 %	Code No. P0173	P.13C-103
84 *5	Short-term fuel compensati on cylinder 2, 3	Engine: After warm-up, 2,500 r/min without any load (during closed loop)		-10 to 10 %	Code No. P0173	P.13C-103
87 *5	Calculation load value	Engine: After warm-up	Idle operation	15 –40 %	—	—
			2,500 r/min	15 –40 %		
88 *5	Fuel control condition cylinder 1, 4	Engine: After warm-up	2,500 r/min	Closed loop	—	—
			Acceleration	Open loop-drive condition		
89 *5	Fuel control condition cylinder 2, 3	Engine: After warm-up	2,500 r/min	Closed loop	—	—
			Acceleration	Open loop-drive condition		
8A *5	Throttle position sensor (main) *4	<ul style="list-style-type: none"> Remove the intake air hose at the throttle body Disconnect the throttle position sensor, and then connect terminal numbers No. 3, and No. 4, No. 5 and No. 6 with the use of the special tool: MB991658. Ignition switch: ON 	Fully close the throttle valve with your finger	0 –12 %	Code No. P0122, P0123	P.13C-42 P.13C-46
			Fully open the throttle valve with your finger	75 –100 %		
A1 *5	Cylinder 1,4 oxygen sensor (front)	Engine: After warm-up (leaner by deceleration, richer by acceleration)	Excessive deceleration from 4,000 r/min	0.2 V or less	Code No. P0130	P.13C-54
			At excessive acceleration	0.6 –1 V		
		Engine: After warm-up (using oxygen sensor, check air-fuel ratio as well as control status by engine-A/T-ECU)	Idle operation	0.4 V or less		
			2,500 r/min	⇔ 0.6 –1 V (altered)		

Item No.	Inspection item	Inspection condition		Normal condition	Inspection procedure No.	Reference page
A2 *5	Cylinder 1,4 oxygen sensor (rear)	Engine: After warm-up	At excessive acceleration (during the increase in the engine speed)	0 V or less ⇔ 0.6 –1 V (altered)	Code No. P0136	P.13C-64
A3 *5	Cylinder 2,3 oxygen sensor (front)	Engine: After warm-up (leaner by deceleration, richer by acceleration)	Excessive deceleration from 4,000 r/min	0.2 V or less	Code No. P0150	P.13C-76
			At excessive acceleration	0.6 –1 V		
		Engine: After warm-up (using oxygen sensor, check air-fuel ratio as well as control status by engine-A/T-ECU)	Idle operation 2,500 r/min	0.4 V or less ⇔ 0.6 –1V (altered)		
A4 *5	Cylinder 2,3 oxygen sensor (rear)	Engine: After warm-up	At excessive acceleration (during the increase in the engine speed)	0.6 –1 V	Code No. P0156	P.13C-88
A9 *5	MIL distance	Running distance in the engine warning light on			—	—

⚠ CAUTION

When shifting the select lever to D range, the brakes should be applied so that the vehicle does not move forward

*NOTE: *1: On the new vehicle (mileage: 500 km or less), air flow sensor output frequency may be higher by approx. 10%.*

*NOTE: *2: Injector drive time ranges shown are when power voltage is 11 V and the cranking speed is 250 r/min. or less.*

*NOTE: *3: On the new vehicle (mileage: 500 km or less), injector drive time may be longer by approx. 10%.*

*NOTE: *4: After the inspection has been completed, disconnect the throttle actuator control motor connector, and then use the M.U.T.-III to delete the diagnosis code that was recorded during the inspection.*

*NOTE: *5: When service data in check mode is selected, the data is not displayed.*

Actuator Test Reference Table


M1131152501294

Item No.	Inspection item	Drive content	Inspection conditions		Normal condition	Code No. /Inspection procedure No.	Reference page
01	Injector	Cut off No. 1 injector	Engine: After warm-up, idle operation (Cut off injectors sequentially to check for a cylinder that does not change engine in idle status.		Engine is changed (becomes unstable or stalled)	Code No. P0201	P.13C-106
02		Cut off No. 2 injector				Code No. P0202	P.13C-110
03		Cut off No. 3 injector				Code No. P0203	P.13C-114
04		Cut off No. 4 injector				Code No. P0204	P.13C-118
07	Fuel pump	Drive fuel pump to circulate fuel	Ignition switch: "ON"	Check for pump operating noise near fuel tank	Operating noise audible	Procedure No. 22	P.13C-283
08	Purge control solenoid valve	Switch solenoid valve from OFF to ON	Ignition switch: "OFF"		When the valve is actuated, operating noise is audible	Code No. P0443	P.13C-166
17	Basic ignition timing	Switch engine-A/T-ECU to ignition timing adjusting mode	<ul style="list-style-type: none"> Engine: Idle operation Install timing light 		5° BTDC	—	—
21	Fan controller	Actuate fan motor	<ul style="list-style-type: none"> Ignition switch: "ON" A/C switch: ON 		Fan motor is rotated	Procedure No. 20	P.13C-274
22	Oil control valve	Oil control valve turns from OFF the ON	Ignition switch: "ON"		Clicks when oil control valve is driven	Code No. P1021	P.13C-197
34	Throttle valve control servo	Stop the throttle valve control servo	Ignition switch: "ON"		Throttle valve is open	Code No. P2100, P2101, P2102, P2103	P.13C-204 P.13C-208 P.13C-211 P.13C-214

CHECK AT THE ECU TERMINALS

M1131153500711

TERMINAL VOLTAGE CHECK CHART



1. Connect a needle-nosed wire probe to a voltmeter probe.
2. Insert the needle-nosed wire probe into each of the engine-A/T-ECU connector terminals from the wire side, and measure the voltage while referring to the check chart.

NOTE:

1. Make the voltage measurement with the engine-A/T-ECU connector connected.
2. You may find it convenient to pull out the engine-A/T-ECU to make it easier to reach the connector terminals.
3. The checks can be carried out off the order given in the chart.

CAUTION

Short-circuiting the positive (+) probe between a connector terminal and earth could damage the vehicle wiring, the sensor, engine-A/T-ECU or all of them. Be careful to prevent this!

3. If voltmeter shows any division from standard value, check the corresponding sensor, actuator and related electrical wiring, then repair or replace.
4. After repair or replacement, recheck with the voltmeter to confirm that the repair has corrected the problem.

Engine-A/T-ECU Connector Terminal Arrangement

Engine-A/T-ECU Connector

C-110	C-111	C-112	C-113	C-114
1 2 5 6 14 15 21 22	3 4 31 32 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57	61 62 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88	91 92 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122	123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 727 728 729 730 731 732 733 734 735 736 737 738 739 740 741 742 743 744 745 746 747 748 749 750 751 752 753 754 755 756 757 758 759 760 761 762 763 764 765 766 767 768 769 770 771 772 773 774 775 776 777 778 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 797 798 799 800 801 802 803 804 805 806 807 808 809 810 811 812 813 814 815 816 817 818 819 820 821 822 823 824 825 826 827 828 829 830 831 832 833 834 835 836 837 838 839 840 841 842 843 844 845 846 847 848 849 850 851 852 853 854 855 856 857 858 859 860 861 862 863 864 865 866 867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900 901 902 903 904 905 906 907 908 909 910 911 912 913 914 915 916 917 918 919 920 921 922 923 924 925 926 927 928 929 930 931 932 933 934 935 936 937 938 939 940 941 942 943 944 945 946 947 948 949 950 951 952 953 954 955 956 957 958 959 960 961 962 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 1000

AK303309AD

Terminal No.	Check item	Check condition (Engine condition)	Normal condition
1	No. 1 injector	While engine is idling after having warmed up, suddenly depress the accelerator pedal.	From 9 –13 V*, momentarily drops slightly
5	No. 2 injector		
14	No. 3 injector		
21	No. 4 injector		
3	EGR valve (A)	Ignition switch: Immediately after turning ON	5 –8 V* (fluctuates for approximately 3 seconds)
12	EGR valve (B)		
19	EGR valve (C)		
26	EGR valve (D)		
8	A/C relay	<ul style="list-style-type: none"> • Engine: Idle speed • A/C switch: OFF →ON (A/C compressor is operating) 	System voltage →1 V or less
10	Cylinder 2,3 oxygen sensor heater (front)	Engine: Idling after warming up	2 –5 V*
		Engine: 4,000 r/min or more	0 V

Terminal No.	Check item	Check condition (Engine condition)	Normal condition
15	Throttle valve control servo relay	Ignition switch: ON	System voltage
		Running at 3,500 r/min while engine is warming up after having been started.	1 V or less
16	Fuel pump relay	Ignition switch: ON	System voltage
		Engine: Idle speed	1 V or less
17	Fan controller	Radiator and condenser fan is not operating	0 – 0.3 V*
		Radiator and condenser fan is operating	0.7 V* or more
18	Cylinder 2,3 oxygen sensor heater (rear)	Engine: Idling after warming up	System voltage
		Engine: 4,000 r/min or more	0 V
23	Purge control solenoid valve	Ignition switch: ON	Decreases Voltage
		Running at 3,500 r/min while engine is warming up after having been started.	1 V or less
24	Cylinder 1,4 oxygen sensor heater (rear)	Engine: Idling after warming up	System voltage
		Engine: 4,000 r/min or more	0 V
25	Cylinder 1,4 oxygen sensor heater (front)	Engine: Idling after warming up	2 – 5 V*
		Engine: 4,000 r/min or more	0 V
31	Ignition coil – No. 1	Engine r/min: 3,000 r/min	0.3 – 3.0 V*
32	Ignition coil – No. 2		
35	Ignition coil – No. 3		
52	Ignition coil – No. 4		
34	Power supply	Ignition switch: ON	System voltage
43			
45	Alternator G terminal	<ul style="list-style-type: none"> • Engine: Warm, idle (radiator fan: OFF) • Headlamp: OFF → ON • Stop lamp: OFF → ON • Rear defogger switch: OFF → ON 	Voltage increases
50	Ignition switch –IG	Ignition switch: ON	System voltage
51	Ignition switch –ST	Engine: Cranking	8 V or more
57	Engine control relay (Power supply)	Ignition switch: "LOCK" (OFF)	System voltage
		Ignition switch: ON	1 V or less
58	Backup power supply	Ignition switch: "LOCK" (OFF)	System voltage
63	Air flow sensor	Engine: Gradually increase the speed.	Voltage increase in response to revving
70	Crank angle sensor	Engine: Cranking	0.4 – 4.0 V
		Engine: Idling	2.0 – 3.0 V
71	Camshaft position sensor	Engine: Cranking	2.0 – 4.8 V
		Engine: Idling	3.0 – 4.0 V

Terminal No.	Check item	Check condition (Engine condition)		Normal condition
84	Power steering fluid pressure sensor	Engine: Idling after warning up	When steering wheel is Stationary	0.4 – 1.0 V
			When steering wheel is turned	Voltage rises
			Full lock	3.0 – 4.0 V
86	Alternator FR terminal	<ul style="list-style-type: none"> • Engine: Warm, idle (radiator fan: OFF) • Headlamp: OFF → ON • Stop lamp: OFF → ON • Rear defogger switch: OFF → ON 		Voltage decreases
92	Power supply voltage applied to accelerator pedal position sensor	Ignition switch: "ON"		4.9 – 5.1 V
95	Oil control valve	Ignition switch: ON		System voltage
		Engine: warming up, 4,500 r/min		4.0 – 10 V*
97	Sensor impressed voltage	Ignition switch: ON		4.9 – 5.1 V
98	Engine coolant temperature sensor	Ignition switch: ON	When engine coolant temperature is –20° C	3.9 – 4.5 V
			When engine coolant temperature is 0° C	3.2 – 3.8 V
			When engine coolant temperature is 20° C	2.3 – 2.9 V
			When engine coolant temperature is 40° C	1.3 – 1.9 V
			When engine coolant temperature is 60° C	0.7 – 1.3 V
			When engine coolant temperature is 80° C	0.3 – 0.9 V
99	Intake air temperature sensor	Ignition switch: ON	When intake air temperature is –20° C	3.8 – 4.4 V
			When intake air temperature is 0° C	3.2 – 3.8 V
			When intake air temperature is 20° C	2.3 – 2.9 V
			When intake air temperature is 40° C	1.5 – 2.1 V
			When intake air temperature is 60° C	0.8 – 1.4 V
			When intake air temperature is 80° C	0.4 – 1.0 V
106	Power supply voltage applied to throttle position sensor	Ignition switch: ON		4.9 – 5.1 V

Terminal No.	Check item	Check condition (Engine condition)		Normal condition
107	Accelerator pedal position sensor (sub)	Ignition switch: ON	Release the accelerator pedal	0.4 – 1.0 V
			Depress the accelerator pedal fully	3.6 V or more
108	Cylinder 2,3 oxygen sensor (front)	Engine: Running at 2,500 r/min after warmed up		0.4 V or less ⇔ 0.6 – 1.0 V (Changes repeatedly)
109	Cylinder 1,4 oxygen sensor (front)	Engine: Running at 2,500 r/min after warmed up		0.4 V or less ⇔ 0.6 – 1.0 V (Changes repeatedly)
113	Throttle position sensor (sub)	<ul style="list-style-type: none"> Remove the intake air hose at the throttle body Disconnect the throttle position sensor, and then connect terminal numbers No. 3, No. 4, No. 5 and No. 6 with the use of the special tool (MB991658). Ignition switch: ON 	Fully close the throttle valve with your finger	2.2 – 2.8 V
			Fully open the throttle valve with your finger	4.0 V or more
114	Accelerator pedal position sensor (main)	Ignition switch: ON	Release the accelerator pedal	0.9 – 1.2 V
			Depress the accelerator pedal fully	4.0 V or more
115	Throttle position sensor (main)	<ul style="list-style-type: none"> Remove the intake air hose at the throttle body Disconnect the throttle position sensor, and then connect terminal numbers No. 3, No. 4, No. 5 and No. 6 with the use of the special tool (MB991658). Ignition switch: "ON" 	Fully close the throttle valve with your finger	0.3 – 0.7 V
			Fully open the throttle valve with your finger	4.0 V or more
116	Cylinder 2,3 oxygen sensor (rear)	Engine: Idling after warmed up (Check using a digital type voltmeter)		0.4 V or less ⇔ 0.6 – 1.0 V (Changes repeatedly)
117	Cylinder 1,4 oxygen sensor (rear)	Engine: Idling after warmed up (Check using a digital type voltmeter)		0.4 V or less ⇔ 0.6 – 1.0 V (Changes repeatedly)

Terminal No.	Check item	Check condition (Engine condition)	Normal condition
132	Power supply voltage applied to throttle valve control servo	Ignition switch: ON	System voltage
133	Throttle valve control servo (+)	<ul style="list-style-type: none">• Ignition switch: ON• Accelerator pedal: fully opened → fully closed	Decreases slightly (approximately 2 V) from battery voltage.
141	Throttle valve control servo (-)	<ul style="list-style-type: none">• Ignition switch: ON• Accelerator pedal: fully closed → fully opened	Decreases slightly (approximately 2 V) from battery voltage.

*NOTE: * :The average voltage is shown when an analog voltmeter is used (because the average voltage might not be shown stably when digital voltmeter is used).*

CHECK CHART FOR RESISTANCE AND CONTINUITY BETWEEN TERMINALS

1. Turn the ignition switch to "LOCK" (OFF) position.
2. Disconnect the engine-A/T-ECU connector.
3. Measure the resistance and check for continuity between the terminals of the engine-A/T-ECU harness-side connector while referring to the check chart.

NOTE:

1. When measuring resistance and checking continuity, a harness for checking contact pin pressure should be used instead of inserting a test probe.
2. Checking need not be carried out in the order given in the chart.

CAUTION

If the terminals that should be checked are mistaken, or if connector terminals are not correctly shorted to earth, damage may be caused to the vehicle wiring, sensors, engine-A/T-ECU and/or ohmmeter. Be careful to prevent this!

4. If the ohmmeter shows any deviation from the standard value, check the corresponding sensor, actuator and related electrical wiring, and the repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair or replacement has corrected the problem.

Engine-A/T-ECU Harness Side Connector Terminal Arrangement

Engine-A/T-ECU Harness Side Connector

C-114	C-113	C-112	C-111	C-110
124 123 133 141 146	128 129 130 131 139 144	121 122 125 126 134 135 142 143	93 94 103 104 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146	3 4 13 31 32 36 37 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146

AK303310AD

Terminal No.	Inspection item	Normal condition (Check condition)
1 – 34	No. 1 injector	10.5 – 13.5 Ω (at 20° C)
5 – 34	No. 2 injector	
14 – 34	No. 3 injector	
21 – 34	No. 4 injector	
3 – 34	EGR valve (A)	20 – 24 Ω (at 20° C)
12 – 34	EGR valve (B)	
19 – 34	EGR valve (C)	
26 – 34	EGR valve (D)	
10 – 34	Cylinder 2,3 oxygen sensor heater (front)	4.5 – 8.0 Ω (at 20° C)
25 – 34	Cylinder 1,4 oxygen sensor heater (front)	
18 – 34	Cylinder 2,3 oxygen sensor heater (rear)	11 – 18 Ω (at 20° C)
24 – 34	Cylinder 1,4 oxygen sensor heater (rear)	
23 – 34	Purge control solenoid valve	30 – 34 Ω (at 20° C)


Terminal No.	Inspection item	Normal condition (Check condition)
33 –Body earth	ECU earth	Continuity (2 Ω or less)
42 –Body earth		
144 –Body earth		
145 –Body earth		
34 –95	Oil control valve	6.9 –7.9 Ω (at 20° C)
96 –98	Engine coolant temperature sensor	14 –17 k Ω (When coolant temperature is -20° C)
		5.1 –6.5 k Ω (When coolant temperature is 0° C)
		2.1 –2.7 k Ω (When coolant temperature is 20° C)
		0.9 –1.3 k Ω (When coolant temperature is 40° C)
		0.48 –0.68 k Ω (When coolant temperature is 60° C)
		0.26 –0.36 k Ω (When coolant temperature is 80° C)
96 –99	Intake air temperature sensor	13 –17 k Ω (When intake air temperature is -20° C)
		5.3 –6.7 k Ω (When intake air temperature is 0° C)
		2.3 –3.0 k Ω (When intake air temperature is 20° C)
		1.0 –1.5 k Ω (When intake air temperature is 40° C)
		0.56 –0.76 k Ω (When intake air temperature is 60° C)
		0.30 –0.45 k Ω (When intake air temperature is 80° C)
133 –141	Throttle actuator control motor	0.3 –100 Ω (at 20° C)

INSPECTION PROCEDURE USING OSCILLOSCOPE

M1131154501472


The output signals of the sensors and the conditions of the actuation signals of the actuators can be inspected visually by observing the waveforms on the oscilloscope.

CAMSHAFT POSITION SENSOR AND CRANK ANGLE SENSOR Measurement Method



1. Disconnect the camshaft position sensor connector and connect the special tool Test harness (MB991709) in between (All terminals should be connected).

Standard wave pattern



AK305868AB

2. Connect the oscilloscope special pattern pickup to camshaft position sensor terminal No. 2.
3. Disconnect the crank angle sensor intermediate connector and connect the special tool Test harness (MB991658) in between.
4. Connect the oscilloscope special patterns pickup to crank angle sensor terminal No. 2.

Alternate Method (Test harness not available)

1. Connect the oscilloscope special patterns pickup to engine-A/T-ECU terminal No. 71 (When checking the camshaft position sensor signal wave pattern).
2. Connect the oscilloscope special patterns pickup to engine-A/T-ECU terminal No. 70 (When checking the crank angle sensor signal wave pattern).

Standard Wave Pattern


Observation condition

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine speed	Idle

Wave Pattern Observation Points

Check that cycle time T becomes shorter when the engine speed increases.

Examples of Abnormal Wave Patterns




Example 1

Cause of problem

Sensor interface malfunction

Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.



Example 2

Cause of problem

Loose timing belt


Abnormality in sensor disk

Wave pattern characteristics

Wave pattern is displaced to the left or right.

INJECTOR

Measurement Method



1. Disconnect the injector connector, and then connect the special tool Test harness set (MB991658) in between (All terminals should be connected).
2. Connect the oscilloscope special patterns pickup to terminal No. 2 of the injector connector.

Alternate Method (Test harness not available)


1. Connect the oscilloscope special patterns pickup to engine-A/T-ECU terminal No. 1 (When checking the No. 1 cylinder).
2. Connect the oscilloscope special patterns pickup to engine-A/T-ECU terminal No. 5 (When checking the No. 2 cylinder).
3. Connect the oscilloscope special patterns pickup to engine-A/T-ECU terminal No. 14 (When checking the No. 3 cylinder).
4. Connect the oscilloscope special patterns pickup to engine-A/T-ECU terminal No. 21 (When checking the No. 4 cylinder).

Standard Wave Pattern

Observation conditions

Function	Special patterns
Pattern height	Variable
Variable knob	Adjust while viewing the wave pattern
Pattern selector	Display
Engine	Idle

Standard wave pattern




AK305803AB

Wave Pattern Observation Points

Point A: Height of solenoid back electromotive force

Contrast with standard wave pattern	Probable cause
Solenoid coil back electromotive force is low or doesn't appear at all.	Short in the injector solenoid

Point B: Injector drive time




The injector drive time will be synchronized with the M.U.T.-III tester display.

- When the engine is suddenly raced, the drive time will be greatly extended at first, but the drive time will soon match the engine speed.

IGNITION COIL AND POWER TRANSISTOR

Measurement Method



1. Disconnect the ignition coil connector, and connect the special tool Test harness (MB991658) in between (All terminals should be connected).
2. Connect the oscilloscope special patterns pickup to terminal No. 3 of each ignition coil connector in turn.

Alternate Method (Test harness not available)


1. Connect the oscilloscope probe to engine-A/T-ECU terminal No. 31. (When checking the number 1 cylinder.)
2. Connect the oscilloscope probe to engine-A/T-ECU terminal No. 32. (When checking the number 2 cylinder.)
3. Connect the oscilloscope probe to engine-A/T-ECU terminal No. 35. (When checking the number 3 cylinder.)
4. Connect the oscilloscope probe to engine-A/T-ECU terminal No. 52. (When checking the number 4 cylinder.)

Standard Wave Pattern

Observation condition

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine	Approximately 1,200 r/min

Standard wave pattern




AK305797AB

Wave Pattern Observation Points

Point: When the engine speed increases, verify that the power transistor control signal (ignition timing) advances.

Examples of Abnormal Wave Patterns



AK203246AD

Example

Wave pattern during engine cranking


Cause of problem

Open-circuit in ignition primary circuit

Wave pattern characteristics


Top-right part of the build-up section cannot be seen, and voltage value is approximately 2 V too low.

EGR VALVE (STEPPER MOTOR) Measurement Method



1. Disconnect the EGR valve connector, and connect the special tool test harness (MB991658) in between.
2. Connect the oscilloscope probe to the EGR valve-side connector terminal 1, terminal 3, terminal 4 and terminal 6 respectively.

Standard wave pattern



AK301251AB

Wave pattern Observation Points

Check that the standard wave pattern appears when the EGR control servo is operating.

Point A: Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

Contrast with standard wave pattern	Probable cause
Induced electromotive force does not appear or is extremely small.	Motor is malfunctioning

Alternate Method (Test Harness not Available)

1. Connect the oscilloscope probe to engine-A/T-ECU terminal No. 3, connection terminal No. 12, connection terminal No. 19, and connection terminal No. 26 respectively.

Standard Wave Pattern


Observation condition

Function	Special patterns
Pattern height	High
Pattern selector	Display
Engine	Ignition switch: OFF → ON

Point B: Height of coil reverse electromotive force

Contrast with standard wave pattern	Probable cause
Coil reverse electromotive force does not appear or is extremely small.	Short in the coil

Examples of Abnormal Wave Patterns




Example 1

Cause of problem

Sensor interface malfunction. (Motor is not operating)

Wave pattern characteristics

Induced electromotive force from the motor turning dose not appear.



Example 2

Cause of problem

Open circuit in the line between the EGR valve and the engine-A/T-ECU.

Wave pattern characteristics

Current is not supplied to the motor coil on the open circuit side. (Voltage dose not drop to 0 V.)

Furthermore, the induced electromotive force waveform at the normal side is slightly different from the normal waveform.

ON-VEHICLE SERVICE

THROTTLE BODY (THROTTLE VALVE AREA) CLEANING

M1131001000989

1. Remove the air intake hose from the throttle body.
2. Remove the throttle body assembly.

CAUTION

- Do not spray the cleaning fluid directly to the throttle valve.
 - Make sure the cleaning fluid does not enter the motor from the bypass line. Also make sure it does not enter the sensor through the shaft.
3. Spray cleaning fluid on a clean cloth.
 4. Wipe off the dirt around the throttle valve with the cloth sprayed with cleaning fluid.
 5. Install the throttle body assembly.
 6. Attach the air intake hose.


FUEL PRESSURE TEST

M1131001901275



1. Release residual pressure from the fuel pipe line to prevent fuel gush out (Refer to P.13C-337).

CAUTION

Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.



2. Disconnect the high-pressure fuel hose at the delivery pipe side.




3. Assemble the fuel pressure measurement tools as follows.

<When using the fuel pressure gauge set (special tool)>

- a. Remove the union joint and bolt from the special tool adaptor hose (MD998709) and attach the special tool hose adaptor (MD998742) to the adaptor hose.
- b. Via a gasket, install the special tool fuel pressure gauge set (MB991637 or MB991981) into the special tool that has already assembled as described in (a) above.

<When using the fuel pressure gauge>

- a. Remove the union joint and bolt from special tool adaptor hose (MD998709) and attach the special tool hose adaptor (MD998742) to the adaptor hose.
- b. Via a suitable O-ring or gasket, install the fuel pressure gauge to the special tool that has already assembled as described in (a) above.



4. Install the assembled fuel pressure measurement tools between the fuel rail and high-pressure fuel hose.


CAUTION

To prevent damage to the M.U.T.-III, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting the M.U.T.-III.

5. Connect the M.U.T.-III to the diagnosis connector.
6. Turn the ignition switch to ON position (But do not start the engine).
7. Select "Item No. 07" from the M.U.T.-III actuator test to drive the fuel pump. Check that there are no fuel leaks from any parts.
8. Finish the actuator test or turn the ignition switch to "LOCK" (OFF) position.
9. Start the engine and run at idle.

10. Fuel pressure measurement while the engine is running at idle.

Standard value: Approximately 248 kPa at curb idle



11. Disconnect the vacuum hose from the fuel pressure regulator and measure fuel pressure with the hose end closed by a finger.

Standard value: 324 – 334 kPa at curb idle

12. Check to see that fuel pressure at idle does not drop even after the engine has been raced several times.
13. Racing the engine repeatedly, hold the fuel return hose lightly with fingers to feel that fuel pressure is present in the return hose.
- NOTE: If the fuel flow rate is low, there will be no fuel pressure in the return hose.*
14. If any of fuel pressure measured in steps 10 to 13 is out of specification, troubleshoot and repair according to the table below.

Symptom	Probable cause	Remedy
<ul style="list-style-type: none"> Fuel pressure too low Fuel pressure drops after racing No fuel pressure in fuel return hose 	Clogged fuel filter	Replace fuel filter
	Fuel leaking to return side due to poor fuel regulator valve seating or settled spring	Replace fuel pressure regulator
	Low fuel pump delivery pressure	Replace fuel pump
Fuel pressure too high	Binding valve in fuel pressure regulator	Replace fuel pressure regulator
	Clogged fuel return hose or pipe	Clean or replace hose or pipe
Same fuel pressure when vacuum hose is connected and when disconnected	Damaged vacuum hose or Clogged nipple	Replace vacuum hose or clean nipple

15. Stop the engine and check change of fuel pressure gauge reading. Normal if the reading does not drop within 2 minutes. If it does, observe the rate of drop and troubleshoot and repair according to the table below.

Symptom	Probable cause	Remedy
Fuel pressure drops gradually after engine is stopped	Leaky injector	Replace injector
	Leaky fuel regulator valve seat	Replace fuel pressure regulator
Fuel pressure drops sharply immediately after engine is stopped	Check valve in fuel pump is held open	Replace fuel pump

16. Release residual pressure from the fuel pipe line
(Refer to [P.13C-337](#)).

⚠ CAUTION

Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.

17. Remove the fuel pressure gauge and special tool from the delivery pipe.

18. Replace the O-ring at the end of the fuel high pressure hose with a new one. Furthermore, apply engine oil to the new O-ring before replacement.

19. Fit the fuel high pressure hose over the delivery pipe and tighten the bolt to specified torque.

Tightening torque: 5 ± 1 N·m

20. Check for any fuel leaks by following the procedure in step 7.


21. Disconnect the M.U.T.-III.

FUEL PUMP RELAY DISCONNECTION (HOW TO REDUCE PRESSURIZED FUEL LINES)


M1131000901175

⚠ WARNING

When removing the fuel pipe, etc., release fuel pressure to prevent fuel spray.



1. Remove the instrument panel parcel box (Refer to GROUP 52A –Instrument Panel [P.52A-2](#)).




2. Remove the fuel pump relay (2) in the the junction block.
3. Crank the engine for at least two seconds.
4. If the engine is not started, turn the ignition switch to the "LOCK (OFF)" position.
5. If the engine is started, turn the ignition switch to the "LOCK (OFF)" position after the engine stopped.
6. Install the fuel pump relay (2).
7. Install the instrument panel parcel box (Refer to GROUP 52A –Instrument Panel [P.52A-2](#)).


FUEL PUMP OPERATION CHECK

M1131002001264


1. Remove the fuel tank cap.
NOTE: As the fuel pump is an in-tank type, the fuel pump sound is hard to hear. Then check the sound from the tank inlet.
2. Check the operating of the fuel pump by M.U.T.-III to force-drive the fuel pump.
3. If the fuel pump will not operate, check by using the following procedure. If normal, check the fuel pump drive circuit.
 - (1) Turn the ignition switch to the "LOCK" (OFF) position.
 - (2) Remove the second seat assembly, the rail cover outer and the rail cover inner. (Refer to GROUP 52A, Second Seat Assembly Removal and Installation [P.52A-27](#)).
 - (3) Remove the rear scuff plate (Refer to GROUP 52A, Trim Removal and Installation [P.52A-10](#)), and turn up the floor mat.



- (4) Remove the rear floor fuel gauge maintenance hole cover (LH).



- (5) Disconnect the fuel tank pump and gauge assembly connector.



- (6) When the fuel pump drive connector (Fuel tank pump and gauge assembly side) is attached directly to the battery, check if the sound of the fuel pump operation can be heard. If no operating sound is heard, replace the fuel tank pump (Refer to GROUP 13D, Fuel Pump Module Disassembly and Assembly [P.13D-9](#)).



NOTE: As the fuel pump is an in-tank type, the fuel pump sound is hard to hear. Then check the sound from the tank inlet.

- (7) Connect fuel tank pump and gauge assembly connector.
- (8) Install the rear floor fuel gauge maintenance hole cover (LH).
- (9) Return the floor mat and install the rear scuff plate. (Refer to GROUP 52A, Trim Removal and Installation [P.52A-10](#)).
- (10) Install the rail cover outer, the rail cover inner and the second seat assembly. (Refer to GROUP 52A, Second Seat Assembly Removal and Installation [P.52A-27](#)).
4. Install the fuel tank cap.

COMPONENT LOCATION


M1131002101540

Name	Symbol	Name	Symbol
Accelerator pedal position sensor	V	Electronic-controlled throttle valve (Throttle position sensor and throttle valve control servo)	F
A/C relay	I	Engine-A/T-ECU (with barometric pressure sensor)	S
A/C switch	Q	Engine control relay	I
Air flow sensor (with intake air temperature sensor)	H	Engine coolant temperature sensor	G
Camshaft position sensor	G	Engine warning lamp (check engine lamp)	R
Crank angle sensor	J	Fuel pump relay (1) and (2)	U
Cylinder 1,4 oxygen sensor (front)	K	Ignition coil	M
Cylinder 1,4 oxygen sensor (rear)	L	Inhibitor switch	P
Cylinder 2,3 oxygen sensor (front)	O	Injector	D
Cylinder 2,3 oxygen sensor (rear)	N	Oil control valve	G
Detonation sensor	C	Power steering fluid pressure sensor	A
Diagnosis connector	T	Purge control solenoid valve	B
EGR valve	E	Throttle valve control servo relay	I



ENGINE CONTROL RELAY CONTINUITY CHECK


M1131050000743



Tester Connection Terminal	Battery Voltage	Normal State
2 - 3	No Voltage	Continuity
1 - 4	No Voltage	No continuity
	Voltage (Connect positive (+) terminal of battery to terminal No. 3 and negative (-) terminal of battery to terminal No. 2.)	Continuity

THROTTLE VALVE CONTROL SERVO RELAY CONTINUITY CHECK


M1131053500190



Tester Connection Terminal	Battery Voltage	Normal State
2 - 3	No Voltage	Continuity
1 - 4	No Voltage	No continuity
	Voltage (Connect positive (+) terminal of battery to terminal No. 3 and negative (-) terminal of battery to terminal No. 2.)	Continuity

FUEL PUMP RELAY CONTINUITY CHECK


M1131033000751



Tester Connection Terminal	Battery Voltage	Normal State
2 - 3	No Voltage	Continuity
1 - 4	No Voltage	No continuity
	Voltage (Connect positive (+) terminal of battery to terminal No. 3 and negative (-) terminal of battery to terminal No. 2.)	Continuity

INTAKE AIR TEMPERATURE SENSOR CHECK

M1131002801099




1. Disconnect the air flow sensor connector.
2. Measure resistance between terminals No. 1 and No. 4.

Standard value:

13 -17 k Ω (at -20° C)
 5.3 -6.7 k Ω (at 0° C)
 2.3 -3.0 k Ω (at 20° C)
 1.0 -1.5 k Ω (at 40° C)
 0.56 -0.76 k Ω (at 60° C)
 0.30 -0.45 k Ω (at 80° C)

3. Remove the air flow sensor



4. Measure resistance while heating the sensor using a hair drier.

Normal condition:

Temperature (°C)	Resistance (kΩ)
Higher	Smaller

5. If the value deviates from the standard value or the resistance remains unchanged, replace the air flow sensor assembly.
6. Install the air flow sensor and tighten it to the specified torque.


Tightening torque: 1.8 ± 0.6 N·m

ENGINE COOLANT TEMPERATURE SENSOR CHECK


M1131003101048

CAUTION

Be careful not to touch the connector (resin section) with the tool when removing and installing.



1. Remove the engine coolant temperature sensor.



2. With temperature sensing portion of engine coolant temperature sensor immersed in hot water, check resistance.

Standard value:

14 –17 kΩ (at -20° C)

5.1 –6.5 kΩ (at 0° C)


2.1 –2.7 kΩ (at 20° C)

0.9 –1.3 kΩ (at 40° C)

0.48 –0.68 kΩ (at 60° C)

0.26 –0.36 kΩ (at 80° C)

3. If the resistance deviates from the standard value greatly, replace the sensor.



4. Apply sealant to threaded portion.

Specified sealant:

3M NUT Locking Part No. 4171 or equivalent



5. Install the engine coolant temperature sensor and tighten it to the specified torque.

Tightening torque: 29 ± 10 N·m


OXYGEN SENSOR CHECK

M1131005001401

OXYGEN SENSOR (FRONT)




1. Disconnect the oxygen sensor connector and connect the special tool Test harness (MB991316) to the connector on the oxygen sensor side.



2. Make sure that there is continuity (4.5 –8.0 Ω at 20° C) between terminal No. 1 (red clip of special tool) and No. 3 (blue clip of special tool) on the oxygen sensor connector.

3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80° C or higher.
5. Perform a tracing for 5 minutes or more with the engine speed of 4,500 r/min.



6. Connect a digital voltage meter between terminal No. 2 (black clip of special tool) and No. 4 (white clip of special tool).
7. While repeatedly racing the engine, measure the oxygen sensor output voltage.

Standard value:

Engine	Oxygen sensor output voltage	Remarks
When racing the engine	0.6 –1.0 V	If you make the air-fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 –1.0 V.

CAUTION

- Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.
- Be careful the heater is broken when voltage of beyond 8V is applied to the oxygen sensor heater.



NOTE: If the sufficiently high temperature (of approximate 400° C or more) is not reached although the oxygen sensor is normal, the output voltage would be possibly low although the rich air-fuel ratio. Therefore, if the output voltage is low, use a jumper wire to connect the terminal No. 1 (red clip of special tool) and the terminal No. 3 (blue clip of special tool) of the oxygen sensor with a (+) terminal and (-) terminal of 8 V power supply respectively, then check again.

8. If the sensor is defective, replace the oxygen sensor.


NOTE: For removal and installation of the oxygen sensor, refer to GROUP 15 –Exhaust Manifold.

P.15-7.


OXYGEN SENSOR (REAR)



1. Disconnect the oxygen sensor connector and connect the special tool Test harness (MD998464) to the connector on the oxygen sensor side.



2. Make sure that there is continuity ($11 - 18 \Omega$ at 20°C) between terminal No.1 (red clip of special tool) and No. 3 (blue clip of special tool) on the oxygen sensor connector.
3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80°C or higher.
5. Perform a tracing for 5 minutes or more with the engine speed of 4,500 r/min.



6. Connect a digital voltage meter between terminal No.2 (black clip of special tool) and No. 4 (white clip of special tool).
7. While repeatedly racing the engine, measure the oxygen sensor output voltage.

Standard value:

Engine	Oxygen sensor output voltage	Remarks
When racing the engine	0.6 –1.0 V	If you make the air-fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 –1.0 V.

CAUTION

- Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.
- Be careful the heater is broken when voltage of beyond 12 V is applied to the oxygen sensor heater.


NOTE: If the sufficiently high temperature (of approximate 400 °C or more) is not reached although the oxygen sensor is normal, the output voltage would be possibly low although the rich air-fuel ratio. Therefore, if the output voltage is low, use a jumper wire to connect the terminal No.2 and the terminal No. 1 of the oxygen sensor with a (+) terminal and (-) terminal of 12 V power supply respectively, then check again.

8. If the sensor is defective, replace the oxygen sensor.

NOTE: For removal and installation of the oxygen sensor, refer to GROUP 15 –Exhaust Pipe and Main Muffler P.15-9.

INJECTOR CHECK

M1131005201245

Check the Operation Sound

1. Use a stethoscope to listen to the operation sound (clicking) of the injectors while the engine is idling or cranking.

CAUTION

Beware that the operation sounds of other injectors can be heard even if the injector that is being inspected might not be operating.

2. Verify that the operation sound increases with the engine speed.


NOTE: If the operating sound cannot be heard, inspect the injector actuation circuit.

Measurement of Resistance between Terminals


1. Disconnect the injector connector.
2. Measure the resistance between terminals.
Standard value: 10.5 –13.5 Ω (at 20° C)
3. Connect the injector connector.

Check the Injection Condition

1. Following the steps below, bleed out the residual pressure within the fuel pipe line to prevent flow of the fuel (Refer to P.13C-337).
2. Remove the injector.



3. Assemble the following special tools as shown in Fig.
 - Injector test set (MD998706)
 - Injector test harness (MB991607)
 - Injector test adaptor (MD998741)
 - Injector test holder assembly (MB991976)
4. Connect the M.U.T.-III to the diagnosis connector.
5. Turn the ignition switch to "ON" position (But do not start the engine).
6. Select "Item No. 07" from the M.U.T.-III actuator test to drive the fuel pump.



7. Activate the injector and check the atomized spray condition of the fuel.

The condition can be considered satisfactory unless it is extremely poor.

8. Stop the actuation of the injector, and check for leakage from the injector's nozzle.

Standard value: 1 drop or less per minute

9. Without the fuel pump operation, operate the injector to draw the fuel out.
10. If the spraying is extremely poor or the fuel leakage from the injector nozzle deviates from the standard value, replace the injector.
11. Disconnect the M.U.T.-III.


THROTTLE VALVE CONTROL SERVO CHECK

M1131051000423

OPERATION CHECK

1. Remove the air intake hose from the throttle body.
2. Turn the ignition switch to "ON" position.
3. Operate the accelerator pedal and confirm that the throttle valve is opening and closing accordingly.

CHECK THE COIL RESISTANCE



1. Disconnect the electronic-controlled throttle valve connector.

2. Measure the resistance between terminals No. 1 and No. 2 at the throttle valve control servo connector.


Standard value: 0.3 – 100 Ω (at 20° C)

3. If resistance is outside the standard value, replace the throttle body assembly.

OIL CONTROL VALVE CHECK

M1131053200304

OPERATION CHECK



1. Disconnect the oil control valve connector.

CAUTION

To prevent the coil from burning, keep the duration of the voltage application as short as possible.

2. Apply battery voltage to the terminals of the connector at the oil control valve, and make sure the oil control valve makes a clicking sound.

MEASUREMENT OF RESISTANCE BETWEEN TERMINALS

1. Disconnect the oil control valve connector.
2. Measure the resistance between the terminals of the connector at the oil control valve.

Standard value: 6.9 – 7.9 Ω (at 20° C)

3. If resistance is outside the standard value, replace the oil control valve.

INJECTOR

REMOVAL AND INSTALLATION

M1131007101501

CAUTION


When the fuel injector replacement is performed, use the M.U.T.-III to initialize the learning value (Refer to GROUP 00, Precautions Before Service –Initialization Procedure for Learning Value in MPI Engine P.00-24).

Pre-removal Operation

- Fuel Discharge Prevention (Refer to P.13C-337).
- Engine Cover Removal (Refer to GROUP 11A, Camshaft and Valve Stem Seal P.11A-17).

Post-installation Operation

- Engine Cover Installation (Refer to GROUP 11A, Camshaft and Valve Stem Seal P.11A-17).
- Fuel Leakage Inspection.



AC501650AB

Removal steps

- PCV hose connection
- Ignition coil connector
- Fuel injector connector
- EGR valve connector
- Rocker cover bracket installation bolts
- >>B<< Fuel high-pressure hose connection
- O-ring
- Fuel return hose connection
- Emission control equip hose connection
- Fuel injector hose

Removal steps (Continued)

- >>B<< 11. MPI delivery pipe pressure regulator
12. O-ring
- <<A>> 13. Fuel delivery pipe and fuel injector assembly
14. Fuel injector insulator
- >>B<< 15. Fuel injector assembly
16. O-ring
17. Fuel injector insulator
- >>A<< 18. Fuel injectors
19. Fuel delivery pipe

REMOVAL SERVICE POINT

<<A>> FUEL DELIVERY PIPE AND FUEL INJECTOR ASSEMBLY REMOVAL

CAUTION


Do not drop the injector.

Remove the fuel delivery pipe with the fuel injector assembly attached to it.

INSTALLATION SERVICE POINTS

>>A<< FUEL INJECTORS INSTALLATION

CAUTION



The fuel injectors are classified into A, B and C by the injection quantity. When replacing one of fuel injectors, use a same identification mark fuel injector as the other fuel injectors.

- When replacing the fuel injectors of all cylinders, use the same identification mark fuel injectors.

>>B<< FUEL INJECTOR ASSEMBLY/MPI DELIVERY PIPE PRESSURE REGULATOR/FUEL HIGH-PRESSURE HOSE INSTALLATION

CAUTION

Do not let the engine oil get into the delivery pipe will be damaged.

1. Apply a drop of new engine oil to the O-ring.
2. Turn the fuel injector assembly to the right and left to install to the fuel delivery pipe. Repeat for fuel high-pressure hose. Be careful not to damage the O-ring. After installing, check that the item turns smoothly.
3. If it does not turn smoothly, the O-ring may be trapped, remove the item, re-install it into the fuel delivery pipe and check again.
4. Tighten the MPI delivery pipe pressure regulator and fuel high-pressure hose to the specified torque.

Tightening torque:

$8.9 \pm 1.9 \text{ N} \cdot \text{m}$ <MPI delivery pipe pressure regulator>

$5.0 \pm 1.0 \text{ N} \cdot \text{m}$ <Fuel high-pressure hose>

THROTTLE BODY ASSEMBLY

REMOVAL AND INSTALLATION

M1131007701387

CAUTION


- When the throttle body assembly replacement is performed, use the M.U.T.-III to initialize the learning value (Refer to GROUP 00, Precautions Before Service –Initialization Procedure for Learning Value in MPI Engine [P.00-24](#)).
- Do not loosen the fixing screws for the resin cover of throttle body assembly. If the screws are loosened, the sensor incorporated in the resin cover becomes misaligned and the throttle body can not work normally.

Pre-removal Operation

- Engine Cover Removal (Refer to GROUP 11A, Camshaft and Valve Stem Seal [P.11A-17](#)).
- Engine Coolant Draining (Refer to GROUP 14, On-vehicle Service –Engine Coolant Replacement [P.14-18](#)).
- Air Cleaner Removal (Refer to GROUP 15, Air Cleaner [P.15-3](#)).

Post-installation Operation

- Air Cleaner Installation (Refer to GROUP 15, Air Cleaner [P.15-3](#)).
- Engine Coolant Supplying (Refer to GROUP 14, On-vehicle Service –Engine Coolant Replacement [P.14-18](#)).
- Engine Cover Installation (Refer to GROUP 11A, Camshaft and Valve Stem Seal [P.11A-17](#)).



AC304161AE

Removal steps

- >>B<<
- Initialization (Installation only)
1. Throttle position sensor connector
 2. Water return hose connection

Removal steps (Continued)


- >>A<<
3. Water feed hose connection
 4. Throttle body assembly
 5. Throttle body gasket

INSTALLATION SERVICE POINTS

>>A<< THROTTLE BODY GASKET INSTALLATION

CAUTION

Poor idling etc. may result if the throttle body gasket is installed incorrectly.



Install the throttle body gasket as its protrusion is in the direction shown.

>>B<< INITIALIZATION

When the throttle body is installed, removed or replaced, initialize the electronic-controlled throttle valve system according to the procedure below beforehand.

Turn the ignition switch to the ON position, and back to the "LOCK" (OFF) position. Then hold it in this position for approximately 10 seconds or more.

ENGINE-A/T-ECU

REMOVAL AND INSTALLATION

M1131033400588

CAUTION


Always register the ignition key(s) when the engine-A/T-ECU is replaced (Refer to GROUP 54A, On-vehicle Service - Immobilizer ID Code Registration [P.54A-44](#)).

Pre-removal Operation

- Front Scuff Plate (LH), Cowl Side Trim (LH) Removal (Refer to GROUP 52A Trims [P.52A-10](#)).
- Console Side Cover (LH) Removal (Refer to GROUP 52A, Floor Console assembly [P.52A-9](#)).

Post-installation Operation

- Console Side Cover (LH) Installation (Refer to GROUP 52A, Floor Console assembly [P.52A-9](#)).
- Front Scuff Plate (LH), Cowl Side Trim (LH) Installation (Refer to GROUP 52A Trims [P.52A-10](#)).



AC301810AC

>>A<<

Removal steps

- Initialization (Installation only)
 - Turn up the floor mat. <Front passenger's side>
1. Wiring harness clamp connection
 2. Wiring harness clamp connection
 3. Bracket
 4. Engine-A/T-ECU connector
 5. Engine-A/T-ECU

INSTALLATION SERVICE POINT**>>A<< INITIALIZATION**

When the engine-A/T-ECU is replaced, initialize the electronic-controlled throttle valve system according to the procedure below beforehand.

Turn the ignition switch to the ON position, and back to the "LOCK" (OFF) position. Then hold it in this position for approximately 10 seconds or more.