

GROUP 42

BODY

CONTENTS

HOOD.....	42-4	WINDOW GLASS DIAGNOSIS ...	42-13
HOOD DIAGNOSIS	42-4	INTRODUCTION TO WINDOW GLASS	
INTRODUCTION TO HOOD DIAGNOSIS	42-4	DIAGNOSIS	42-13
HOOD DIAGNOSTIC TROUBLESHOOTING		WINDOW GLASS DIAGNOSTIC	
STRATEGY	42-4	TROUBLESHOOTING STRATEGY....	42-14
SYMPTOM CHART	42-4	WINDOW GLASS DIAGNOSTIC TROUBLE	
SYMPTOM PROCEDURES	42-4	SYMPTOM CHART	42-14
ON-VEHICLE SERVICE.....	42-6	SYMPTOM PROCEDURES.....	42-14
ADJUSTMENT OF CLEARANCE AROUND		SPECIAL TOOLS	42-14
HOOD	42-6	WINDSHIELD	42-15
ADJUSTMENT OF ALIGNMENT OF		REMOVAL AND INSTALLATION.....	42-15
HOOD STEPPED PORTION AND HOOD		REAR WINDOW GLASS	42-20
STRIKER	42-6	REMOVAL AND INSTALLATION.....	42-20
ADJUSTMENT OF HOOD HEIGHT ...	42-6	DOOR.....	42-23
HOOD.....	42-7	GENERAL DESCRIPTION	42-23
REMOVAL AND INSTALLATION	42-7	CENTRAL DOOR LOCKING SYSTEM	
FENDER.....	42-8	DIAGNOSIS	42-23
SPECIAL TOOL.....	42-8	POWER WINDOW DIAGNOSIS...	42-23
FENDER.....	42-9	DOOR DIAGNOSIS	42-23
REMOVAL AND INSTALLATION	42-9	INTRODUCTION TO GLASS AND DOOR	
FUEL FILLER LID	42-11	DIAGNOSIS	42-23
REMOVAL AND INSTALLATION	42-11	GLASS AND DOOR DIAGNOSTIC	
WINDOW GLASS	42-12	TROUBLESHOOTING STRATEGY....	42-23
GENERAL	42-12	SYMPTOM CHART	42-24
		SYMPTOM PROCEDURES.....	42-24
		HOW TO LOCATE WIND NOISE..	42-27

Continued on next page

SPECIAL TOOLS	42-28	SYMPTOM CHART	42-53
ON-VEHICLE SERVICE	42-29	SYMPTOM PROCEDURES	42-54
DOOR FIT ADJUSTMENT	42-29	ON-VEHICLE SERVICE	42-55
DOOR WINDOW GLASS ADJUSTMENT	42-31	TRUNK LID ADJUSTMENT	42-55
GLASS SLIDING MECHANISM CHECK AND ADJUSTMENT	42-31	ADJUSTMENT OF CLEARANCE AROUND TRUNK LID	42-56
POWER WINDOW TIMER FUNCTION CHECK	42-32	TRUNK LID STRIKER ADJUSTMENT ..	42-56
POWER WINDOW OPERATING CURRENT CHECK	42-32	TRUNK LID HEIGHT ADJUSTMENT...	42-56
POWER WINDOW RELAY CHECK ...	42-32	TRUNK LID	42-57
CIRCUIT BREAKER (INCORPORATED IN THE POWER WINDOW MOTOR) INSPECTION	42-33	REMOVAL AND INSTALLATION	42-57
POWER WINDOW CHECK	42-33	INSPECTION	42-60
CENTRAL DOOR LOCKING SYSTEM INSPECTION	42-33	KEYLESS ENTRY SYSTEM ..	42-60
DOOR OUTSIDE HANDLE PLAY CHECK	42-33	GENERAL DESCRIPTION	42-60
DOOR INSIDE HANDLE PLAY ADJUSTMENT	42-34	KEYLESS ENTRY SYSTEM DIAGNOSIS	42-60
DOOR ASSEMBLY	42-35	SPECIAL TOOLS	42-60
REMOVAL AND INSTALLATION	42-35	ON-VEHICLE SERVICE	42-61
INSPECTION	42-36	HOW TO REPLACE THE TRANSMITTER BATTERY	42-61
DOOR TRIM AND WATERPROOF FILM	42-37	KEYLESS ENTRY SYSTEM TIMER LOCK FUNCTION INSPECTION	42-61
REMOVAL AND INSTALLATION	42-37	ENABLING/DISABLING THE ANSWERBACK FUNCTION	42-61
INSPECTION	42-41	HOW TO REGISTER SECRET CODE .	42-64
DOOR GLASS AND REGULATOR	42-43	SUNROOF ASSEMBLY	42-66
REMOVAL AND INSTALLATION	42-43	GENERAL DESCRIPTION	42-66
INSPECTION	42-45	SUNROOF DIAGNOSIS	42-66
DOOR HANDLE AND LATCH	42-46	SPECIAL TOOLS	42-66
REMOVAL AND INSTALLATION	42-46	ON-VEHICLE SERVICE	42-66
INSPECTION	42-48	WATER TEST	42-66
WINDOW GLASS RUNCHANNEL AND DOOR OPENING WEATHER-STRIP	42-51	SUNROOF TIMER FUNCTION CHECK	42-67
REMOVAL AND INSTALLATION	42-51	SUNROOF FIT ADJUSTMENT	42-67
TRUNK LID	42-53	SUNROOF SAFETY FUNCTION CHECK	42-67
TRUNK LID DIAGNOSIS	42-53	SUNROOF CHECK	42-67
INTRODUCTION TO TRUNK LID DIAGNOSIS	42-53		
TRUNK LID DIAGNOSTIC TROUBLESHOOTING STRATEGY ...	42-53		

ROOF LID GLASS OPERATION CURRENT
CHECK 42-68

SUNROOF INITIALIZED ADJUSTMENT
OPERATION CHECK 42-69

SUNROOF ASSEMBLY..... 42-71

REMOVAL AND INSTALLATION 42-71

INSPECTION..... 42-73

DISASSEMBLY AND ASSEMBLY..... 42-74

SPECIFICATIONS 42-75

**FASTENER TIGHTENING
SPECIFICATIONS 42-75**

SERVICE SPECIFICATIONS..... 42-75

SEALANT AND ADHESIVES..... 42-75

COMPONENT IDENTIFICATIONS. 42-76

HOOD

DIAGNOSIS

INTRODUCTION TO HOOD DIAGNOSIS

Wind noise at the hood may be caused by improper hood adjustment.

M1421005800200

HOOD DIAGNOSTIC TROUBLESHOOTING STRATEGY

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a hood fault.

M1421005900177

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

SYMPTOM CHART

M1421006000296

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Difficult locking and unlocking	1	P.42-4
Uneven body clearance	2	P.42-5
Uneven height	3	P.42-5

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Difficult Locking and Unlocking

DIAGNOSIS

STEP 1. Check the release cable routing condition.

Q: Is the release cable routed correctly?

YES : Go to Step 2.

NO : Repair the release cable, then go to Step 4.

STEP 2. Check the engagement of the hood latch and hood striker.

Q: Are the hood latch and hood striker engaged correctly?

YES : Go to Step 3.

NO : Adjust the hood latch (Refer to P.42-6).
Then go to Step 4.

STEP 3. Check for proper lubrication of release cable.

Q: Is the release cable properly lubricated?

YES : Go to Step 4.

NO : Lubricate, then go to Step 4.

STEP 4. Retest the system.

Q: Does the hood lock operate easily?

YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 2: Uneven Body Clearance

DIAGNOSIS

STEP 1. Check the clearance around the hood.

Q: Are the apertures between the hood and the adjacent body panels aligned correctly?
YES : Go to Step 2.
NO : Adjust the hood. Refer to [P.42-6](#). Then go to Step 2.

STEP 2. Retest the system.

Q: Are the clearances between body panels even?
YES : The procedure is complete.
NO : Return to Step 1.

INSPECTION PROCEDURE 3: Uneven Height

DIAGNOSIS

STEP 1. Check the hood bumper height.

Q: Is the hood bumper height proper?
YES : Go to Step 2.
NO : Adjust the hood bumper. Refer to [P.42-6](#). Then go to Step2.

STEP 2. Retest the system.

Q: Are the hood and body height even?
YES : The procedure is complete.
NO : Return to Step 1.

ON-VEHICLE SERVICE



ADJUSTMENT OF CLEARANCE AROUND HOOD

M1421007200011

ADJUSTMENT OF ALIGNMENT OF HOOD


STEPPED PORTION AND HOOD STRIKER

M1421007300018




ADJUSTMENT OF HOOD HEIGHT

M1421007400015



Rotate the hood bumper by using arrow mark on the hood bumper as a guide to adjust the hood height. If the hood bumper is rotated just one turn, the hood height changes by approximately 3 mm (0.1 inch).


SECTION A - A



HOOD

REMOVAL AND INSTALLATION

M1421001600237



REMOVAL

1. HOOD BUMPER
2. HOOD LATCH

HOOD LOCK RELEASE CABLE REMOVAL STEPS


3. HOOD LOCK RELEASE HANDLE
4. HOOD LOCK RELEASE CABLE

HOOD AND HOOD HINGE REMOVAL STEPS

5. HOOD INSULATOR
6. HOOD WEATHERSTRIP
7. HEADLIGHT WEATHERSTRIP

HOOD AND HOOD HINGE REMOVAL STEPS (Continued)


- WASHER HORSE (REFER TO GROUP 51, WINDSHIELD WIPER AND WASHER [P.51-21.](#))
- RADIATOR GRILLE (REFER TO GROUP 51, RADIATOR GRILLE [P.51-11.](#))
- 8. HOOD SUPPORT ROD
- 9. HOOD
- 10. HOOD HINGE



FENDER

SPECIAL TOOL

M1421000600063

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
 <p>MB990784</p>	MB990784 Ornament remover	General service tool	Removal of side turn signal lamp


FENDER

REMOVAL AND INSTALLATION

M1421001900119

Pre-removal and Post-installation Operation

- Front Bumper Removal and Installation (Refer to GROUP 51, Front Bumper [P.51-3.](#))
- Front Deck Garnish Removal and Installation (Refer to GROUP 51, Windshield Wiper and Washer [P.51-21.](#))



AC005957AB

REMOVAL STEPS

- SIDE AIRDAM (REFER TO GROUP 51, AIR DAM, MOLDING AND GARNISH [P.51-13.](#))
1. SPLASH SHIELD
 2. SIDE TURN SIGNAL LIGHT
 3. DELTA GARNISH (REFER TO GROUP 51, AIR DAM, MOLDING AND GARNISH [P.51-13.](#))
 4. FENDER

<<A>> >>A<<


Required Special Tool:

- MB990784: Ornament Remover

REMOVAL SERVICE POINT

<<A>> SIDE TURN SIGNAL LIGHT REMOVAL


Use an appropriate tool such as MB990874 to prize out the tab from the fender, and remove the side turn signal light.



INSTALLATION SERVICE POINT

>>A<< SIDE TURN SIGNAL LIGHT INSTALLATION

Engage the claw with the fender panel, and install the side turn signal light.






FUEL FILLER LID

REMOVAL AND INSTALLATION

M1421002500125

Pre-removal and Post-installation Operation

- Rear Seat Removal and Installation (Refer to GROUP 52A, Rear Seat P.52A-18.)
- Front Scuff Plate (Driver's Seat Side), Rear Scuff Plate (Driver's Side), Center Pillar Lower Trim (Driver's Side), Quarter Trim (Driver's Side) Removal and Installation (Refer to GROUP 52A, Trims P.52A-11.)



AC005973

AC005996AB

REMOVAL STEPS

1. FUEL FILLER DOOR PANEL ASSEMBLY
2. CLIP
3. FUEL FILLER DOOR HOOK ASSEMBLY

REMOVAL STEPS (Continued)

4. FUEL FILLER DOOR LOCK RELEASE CABLE
5. FUEL FILLER DOOR LOCK RELEASE HANDLE

WINDOW GLASS

GENERAL


M1422000100276

The windshield and rear window glass are attached by an urethane-base adhesive to the window frame. This adhesive provides improved glass holding and sealing, and also permits use of body openings having a greater structural strength.

ITEMS

ITEM	APPLICATION	QUANTITY
Wire (dia × length)	For cutting adhesive	Five pieces of wire 0.6 mm × 1 m (0.02 in × 3.3 ft)
Glass adhesive knife	For cutting adhesive	One
Sealant gun	For adhesive application	One
Wiping shop towels	-	As required
Sealer	For prevention of water leaks and gathering after adhesive application	As required
3M AAD™ Part No. 8906 or equivalent	For cleaning	As required
Glass holder MB990480	For holding of window glass	Two
Window molding remover MB990449	For roof drip molding removal	One

WINDOW GLASS INSTALLATION



AC201779

WINDOW GLASS DIAGNOSIS

INTRODUCTION TO WINDOW GLASS DIAGNOSIS

If water leaks from the windshield, or the rear window glass, the seal or body flange may be faulty.

M1422006700157

WINDOW GLASS DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1422006800154

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a window glass fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

WINDOW GLASS DIAGNOSTIC TROUBLE SYMPTOM CHART

M1422006900247

SYMPTOMS	INSPECTION PROCEDURE	REFERENCE PAGE
Water leak through windshield	1	P.42-14
Water leak through rear window glass		

SYMPTOM PROCEDURES**INSPECTION PROCEDURE 1: Water Leak through Windshield/Water Leak through Rear Window glass****DIAGNOSIS****STEP 1. Check if the seal is faulty.**

Q: Is the seal faulty?

YES : Repair the seal, then go to Step 3.

NO : Go to Step 2.

STEP 2. Check if the body flange is deformed.

Q: Is the body flange deformed?

YES : Repair the body flange, then go to Step 3.

NO : Go to Step 3.

STEP 3. Retest the system.



Q: Is any water leaking?

YES : Return to Step 1.

NO : This diagnosis complete.

SPECIAL TOOLS

M1422000600130

TOOL	TOOL NUMBER AND NAME	SUPERSESSON	APPLICATION
 MB990480	MB990480 Glass holder	General service tool	Removal and installation of window glass
 MB990784	MB990784 Ornament remover	General service tool	Removal of rear window lower molding



WINDSHIELD

REMOVAL AND INSTALLATION

M1422001000227

Pre-removal and Post-installation Operation

- Front Deck Garnish Removal and Installation (Refer to GROUP 51, Windshield Wiper and Washer [P.51-21.](#))
- Front Pillar Trim Removal and Installation (Refer to GROUP 52A, Trims [P.52A-11.](#))
- Headlining Removal and Installation (Refer to GROUP 52A, Headlining [P.52A-14.](#))



AC006003AC

REMOVAL STEPS

- ROOF DRIP MOLDING (REFER TO GROUP 51, AIR DAM, MOLDING AND GARNISH P.51-13.)
- <<A>> >>A<< 1. WINDSHIELD
 >>A<< 2. WINDSHIELD MOLDING
 >>A<< 3. WINDOW DAM
 >>A<< 4. GLASS STOPPER

REMOVAL STEPS (Continued)


- >>A<< 5. SPACER
 >>A<< 6. WINDSHIELD SPACER

Required Special Tool:

- MB990480: Glass Holder

REMOVAL SERVICE POINT**<<A>> WINDSHIELD REMOVAL**

1. To protect the body (paint surface), apply cloth tape to all body areas around the installed
2. Make mating marks on the windshield and body.
3. Using piano wire.
 - (1) Using a sharp-point drill, make a hole in the windshield adhesive.
 - (2) Pass the piano wire from the inside of the vehicle through the hole.
 - (3) Using a sharp-point drill, make a hole in the windshield adhesive.
 - (4) Pass the piano wire from the inside of the vehicle through the hole.

**⚠ CAUTION**

Do not let the piano wire touch the edge of the windshield.



- (5) Pull the piano wire alternately from the inside and outside along the windshield to cut the adhesive.



⚠ CAUTION

Putting glass adhesive knife too deeply into windshield adhesive may damage windshield.

4. Using glass adhesive knife

Keep glass adhesive knife at right angles with the windshield edge, and put the blade at windshield edge and surface. Then cut away adhesive along the windshield edge.





5. Use special tool MB990480 to remove the windshield.

⚠ CAUTION

- Be careful not to remove more adhesive than is necessary.
 - Be careful also not to damage the paintwork on the body surface with the knife. If the paintwork is damaged, repair the damaged area with repair paint or anti-rust agent.
6. Use a knife to cut away the remaining adhesive so that the thickness is within 2 mm (0.08 inch) around the entire circumference of the body flange.
 7. Finish the flange surfaces so that they are smooth.

⚠ CAUTION

Allow the cleaned area to dry for at least three minutes. Do not touch any surface that has been cleaned.

8. When reusing the windshield, remove the adhesive still adhering to the windshield, and clean with 3M™ AAD Part number 8906 or equivalent.
9. Clean the body side in the same way.

INSTALLATION SERVICE POINTS


**>>A<< WINDSHIELD SPACER/SPACER/GLASS STOPPER/
WINDOW DAM/WINDSHIELD MOLDING/WINDSHIELD
INSTALLATION**

⚠ CAUTION

Leave the degreased parts for 3 or more minutes to dry well, before starting on the next step. Do not touch the degreased parts.

1. Use 3M™ AAD Part number 8906 or equivalent to degrease the inside and outside of the windshield and the body flanges.

GLASS STOPPER, SPACER, WINDSHIELD SPACER AND WINDOW DAM INSTALLATION POSITION




2. The inner side of the windshield is curved, therefore, make a point to assemble the glass stopper and windshield spacer without any lifting and assemble in the position shown in the Figure of the instructions.
3. Install the windshield molding.

>>B<< WINDSHIELD INSTALLATION

1. When replacing the windshield, temporarily set the windshield against the body, and place a mating mark on the windshield and body.

CAUTION

- The primer strengthens the adhesive, so be sure to apply it evenly around the entire circumference. However, a too thick application will weaken the adhesive.
 - Do not touch the coated surface.
2. Soak a sponge in the primer, and apply evenly to the windshield and the body in the specified places.



3. Allow the windshield to dry for at least three minutes after applying primer.
4. Fill a sealant gun with adhesive. Then apply the adhesive evenly around the windshield within 30 minutes after applying the primer.

NOTE: Cut the tip of the sealant gun nozzle into a V shape to simplify adhesive application.

5. Align the mating marks on the windshield and the body, and lightly press the windshield evenly so that it adheres completely.
6. Use a spatula or similar tool to remove any excessive adhesive. Clean the surface with 3M™ AAD Part number 8906 or equivalent. Avoid moving the vehicle until the adhesive sets.
7. Bond the windshield to the body, and install the roof drip molding quickly before the adhesive cures. (Refer to GROUP51, Air dam, molding and garnish [P.51-13.](#))

⚠ CAUTION




- **Do not move the vehicle unless absolutely necessary.**
 - **When testing for water leakage, do not pinch the end of the hose to spray the water.**
8. Wait 30 minutes or more, and then test for water leakage.

REMOVAL AND INSTALLATION

M1422001600081

Pre-removal and Post-installation Operation

- Rear Wiper Motor Assembly Removal and Installation <Vehicles with Rear Wiper and Washer> (Refer to GROUP 51, Rear Wiper and Washer [P.51-26.](#))
- High Mount Stoplight Assembly Removal and Installation <Rear Shelf Mounted Type> (Refer to GROUP 54A, High Mount Stoplight [P.54A-52.](#))
- Rear Pillar Trim and Rear Shelf Trim Removal and Installation (Refer to GROUP 52A, Trims [P.52A-11.](#))
- Headlining Removal and Installation (Refer to GROUP 52A, Headlining [P.52A-14.](#))



AC006056 AC

REMOVAL STEPS

- ROOF DRIP MOLDING (REFER TO GROUP 51, AIR DAM, MOLDING AND GARNISH [P.51-13.](#))
- <<A>> >>B<< 1. REAR WINDOW LOWER MOLDING
2. CLIP
3. GROMMET A
4. GROMMET B
5. GROMMET C
6. CONNECTING THE HARNESS CONNECTOR
- <> >>A<< 7. REAR WINDOW GLASS

REMOVAL STEPS (Continued)

- >>A<< 8. REAR WINDOW UPPER MOLDING
- >>A<< 9. WINDOW DAM
- >>A<< 10. GLASS STOPPER

Required Special Tools:

- MB990784: Ornament Remover
- MB990480: Glass Holder


REMOVAL SERVICE POINTS

<<A>> REAR WINDOW LOWER MOLDING REMOVAL

⚠ CAUTION

If the drip molding has become warped, it should not be reused.

Use special tool MB990784 to lever out the molding.



<> REAR WINDOW GLASS REMOVAL

Removal the rear window glass using the same procedure as for the windshield. (Refer to [P.42-15.](#))

INSTALLATION SERVICE POINTS

>>A<< GLASS STOPPER/WINDOW DAM/REAR WINDOW UPPER MOLDING/REAR WINDOW GLASS INSTALLATION

1. When replacing the rear window glass, temporarily set the rear window glass against the body, and place a mating mark on the rear window glass and body.


⚠ CAUTION

Leave the degreased parts for 3 or more minutes to dry well, before starting on the next step. Do not touch the degreased parts.

2. Use 3M™ AAD Part number 8906 or equivalent to degrease the inside and outside of the rear window glass and the body flanges.

⚠ CAUTION

- The primer strengthens the adhesive, so be sure to apply it evenly around the entire circumference. However, a too thick application will weaken the adhesive.
 - Do not touch the coated surface.
3. Soak a sponge in the primer, and apply evenly to the rear window glass and the body in the specified places.
 4. Allow the rear window glass to dry for at least three minutes after applying primer.



5. Install the glass stopper and window dam to the specified positions so that there are no adrift or bent surfaces inside the rear window glass.
6. Install the rear window upper molding.
7. Install the glass in the same manner as the windshield.
(Refer to [P.42-15.](#))

>>B<< REAR WINDOW LOWER MOLDING INSTALLATION

Install the clips to the rear window lower molding, and then fix the rear window molding to the vehicle body.

DOOR

GENERAL DESCRIPTION

OPERATION

CENTRAL DOOR LOCKING SYSTEM

The central door locking system operates the door lock actuator to lock or unlock the doors and liftgate using the operation of the door lock switch or key built into the driver's side inside door lock knob and front power window (main or sub) switch. The system has the following operations and features.

- Insert the key into the driver's key cylinder and turn once to the unlock side to unlock the driver's door. Turn the key once again to the unlock side to unlock all doors.
- All doors can be locked or unlocked using the front door <RH> key cylinder key operation.
- All doors and liftgate can be locked using the driver's inside door lock knob.
- All doors can be locked using the door lock switch built into the front power window (main or sub <RH>) switch.

- A key reminder function that automatically unlocks all doors when door lock operation is performed and the front doors are opened while the key is inserted into the ignition switch is provided.

M1423000100194

POWER WINDOWS

When the power window (main or sub) switch is operated, the door windows will open or close. This system has the following operations and features.

- There is a power window lock switch featured on the power window main switch to prevent the door window glass from opening/closing with the front passenger's and rear power window sub-switch.
- The power window of the door window glass can be opened/closed for 30 seconds with the timer function after the ignition switch is turned OFF. (The timer expires if the front door <LH or RH> is opened when the timer is in operation.)
- The power window main switch contains a one-touch down switch that will automatically open driver's side door window only.

CENTRAL DOOR LOCKING SYSTEM DIAGNOSIS

The central door locking system is controlled by the simplified wiring system (SWS). For troubleshooting, refer to GROUP 54B, Diagnosis [P.54Bb-2](#).

M1427000700110

POWER WINDOW DIAGNOSIS

The power window is controlled by the simplified wiring system (SWS). For troubleshooting, refer to GROUP 54B, Diagnosis [P.54Bb-2](#).

M1429000700116

DOOR DIAGNOSIS

INTRODUCTION TO GLASS AND DOOR DIAGNOSIS

Glass and door faults include water leaks and improper opening and closing. Causes for these faults can include faults in the glass, weatherstrip, drain hole, waterproof film or door installation.

M1423007300155

GLASS AND DOOR DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1423006700150

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a glass and door fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

SYMPTOM CHART

M1423007000251

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Water leak through door window glass	1	P.42-24
Door window malfunction	2	P.42-24
Water leak through door edge	3	P.42-25
Water leak from door center	4	P.42-25
Door hard to open	5	P.42-25
Door does not open or close completely	6	P.42-26
Uneven gap between body	7	P.42-26
Wind noise around door	8	P.42-26

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Water Leak Through Door Window Glass

DIAGNOSIS

STEP 1. Check the door window glass installation.

Q: Is the door window glass installed correctly?

YES : Go to Step 2.

NO : Assemble the door window glass again.
Refer to P.42-35. Then go to Step 3.

STEP 2. Check the clearance at the top of the door window glass.

Q: Is the clearance at the top of the door window glass correct?

YES : Go to Step 3.

NO : Adjust the door window glass. Refer to P.42-31. Then go to Step 3.

STEP 3. Retest the system.

Q: Is any water leaking?

YES : Return to Step 1.

NO : The procedure is complete.

INSPECTION PROCEDURE 2: Door Window Glass Malfunction

DIAGNOSIS

STEP 1. Check the door window glass installation condition.

Q: Is the door window glass installed correctly?

YES : Go to Step 2.

NO : Assemble the door window glass again.
(Refer to P.42-43.) Then go to Step 4.

STEP 2. Check the door sash.

Q: Is the door sash in good condition?

YES : Go to Step 3.

NO : Repair or replace the door sash, then go to Step 4.

STEP 3. Inspect the window regulator assembly.

Q: Is the window regulator assembly in good condition?

YES : Go to Step 4.

NO : Repair or replace the window regulator assembly, then go to Step 4.

STEP 4. Retest the system.

Q: Does the door window glass operate correctly?

YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 3: Water Leak Through Door Edge

DIAGNOSIS

STEP 1. Check the weatherstrip.

Q: Is the weatherstrip in good condition?

YES : Go to Step 2.

NO : Replace the weatherstrip, then go to Step 3.

STEP 2. Check the door fit (alignment).

Q: Is the door fit (alignment) correct?

YES : Go to Step 3.

NO : Adjust the door fit. Refer to [P.42-29](#). Then go to Step 3.

STEP 3. Retest the system.

Q: Is any water leaking?

YES : Return to Step 1.

NO : The procedure is complete.

INSPECTION PROCEDURE 4: Water Leak from Door Center

DIAGNOSIS

STEP 1. Check the drain hole.

Q: Is the drain hole clogged?

YES : Clean the drain hole, then go to Step 3.

NO : Go to Step 2.

STEP 2. Check the weatherstrip.

Q: Is the weatherstrip in good condition?

YES : Go to Step 3.

NO : Repair or replace the weatherstrip, then go to Step 3.

STEP 3. Retest the system.

Q: Is any water leaking?

YES : Return to Step 1.

NO : The procedure is complete.

INSPECTION PROCEDURE 5: Door Hard to Open

DIAGNOSIS

STEP 1. Adjust the latch and striker engagement.

Refer to [P.42-29](#).

Q: Is the latch and striker engagement adjusted?

YES : Go to Step 2.

NO : Adjust the latch and striker. Refer to [P.42-29](#). Then go to Step 4.

STEP 2. Check for lock rod damage.

Q: Is the lock rod damaged?

YES : Repair or replace the lock rod, then go to Step 4.

NO : Go to Step 3.

STEP 3. Check the door handle flexibility
(amount of movement of handle required to open door).

Q: Is the door handle flexibility good?

YES : Go to Step 4.

NO : Adjust the door handle. Refer to [P.42-33](#) and [P.42-34](#). Then go to Step 4.

STEP 4. Retest the system.

Q: Does the door open easily?

YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 6: Door does not Open or Close Completely

DIAGNOSIS

STEP 1. Check the door hinge position.

Q: Is the door hinge correct?

YES : Go to Step 2.

NO : Adjust the door hinge. Refer to [P.42-29](#). Then go to Step 4.

STEP 2. Check the door.

Q: Is the door in good condition?

YES : Go to Step 3.

NO : Repair or replace door, then go to Step 4.

STEP 3. Check the grease.

Q: Is the door check or door hinge grease sufficient?

YES : Go to Step 4.

NO : Apply the grease, then go to Step 4.

STEP 4. Retest the system.

Q: Does the door open and close correctly?

YES : The procedure is complete.

NO : Return to Step 1.

INSPECTION PROCEDURE 7: Uneven Gap Between Body

DIAGNOSIS

Adjust the door fit. Refer to [P.42-29](#). Then check that the gap has been improved.

INSPECTION PROCEDURE 8: Wind Noise Around Door

DIAGNOSIS

STEP 1. Check the weatherstrip for holding condition.

Q: Is the weatherstrip holding firmly?

YES : Go to Step 2.

NO : Adjust fit of door. Refer to [P.42-31](#). Then go to Step 5.

STEP 2. Check the weatherstrip for installation condition.

Q: Is the weatherstrip for installed properly?

YES : Go to Step 3.

NO : Repair or replace the weatherstrip. Then go to Step 5.

STEP 3. Check the clearance.

Q: Are the door glass and the door weatherstrip holder assembled correctly?

YES : Go to Step 4.

NO : Adjust the door glass and the door weatherstrip. Refer to [P.42-31](#). Then go to Step 5.

STEP 4. Check the door.

Q: Is the door deformed?

YES : Repair or replace the door. then go to Step 5.

NO : Go to Step 5.

STEP 5. Retest the system.

Q: Has the wind noise been improved?


YES : Return to Step 1.

NO : This diagnosis complete.


HOW TO LOCATE WIND NOISE

M1421004200119


1. Attach cloth tape to every place, such as panel seams, projections, molding seams, glass and body seams, etc. which might conceivably be the source of wind noise.
2. Then make a road test to check that the places not covered by tape are not sources of wind noise.




3. Remove the strips of tape one by one, making a road test after each is removed, until a wind noise source is discovered.




4. When such a place is found, cover it again and repeat the procedure to check if there are any other noise source.
5. If no others are found, the last remaining tape is the only source.



6. Cut the remaining piece of tape into smaller pieces, attach it again as it was before, and then remove the pieces one by one to narrow down the source.








- 7. Check that wind noise occurs when the last remaining tape is removed, and that noise does not occur when it is re-attached.
- 8. When the source(s) of the wind noise is finally located, attach butyl tape, body sealer or similar material to obstruct this source as much as possible.

SPECIAL TOOLS

M1423000600144

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
<p>MB990900</p>	MB990900 or MB991164 Door adjusting wrench	MB990900-01	Adjustment of door fit
<p>MB990925AD</p>	MB990925 Bearing and oil seal installer set A: MB990939 Brass bar	MB990925-01 or General service tool	Adjustment of door striker
<p>MB990211</p>	MB990211 Slider hammer	MB990211-01	
<p>MB990241AC</p>	MB990241 Axle shaft puller A: MB990243 Body puller	MB990241-01 or General service tool	

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
 MB990784	MB990784 Ornament remover	General service tool	Removal of door trim
 MB990480	MB990480 Glass holder	General service tool	Removal of power window regulator assembly
 A B C D MB991223AB	MB991223 Harness set A: MB991219 Test harness B: MB991220 LED harness C: MB991221 LED harness adapter D: MB991222 Probe	MB991223	Measurement of terminal voltage A: Connector pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection


ON-VEHICLE SERVICE

DOOR FIT ADJUSTMENT

M1423001100120

Required Special Tools:

- MB990211: Slide Hammer
- MB990243: Body Puller
- MB990900 or MB991164: Door adjusting Wrench
- MB990939: Brass Bar

**⚠ CAUTION**

- Attach protection tape to the fender and door edges where the hinge is installed.
- Do not rotate special tool MB991164 with a torque of over 98 N·m (72 ft-lb)


1. Use the special tool MB990900 or MB991164 to loosen the hinge mounting bolts on the body side, and then adjust the clearance around the door so that it is uniform on all sides.
2. If the door panel is not flush with the body panels, remove the door hinge (Refer to P.42-35). Use a chisel or a grinder to grind off the weld between the door hinge and the washer. Protect the exposed metal of the ground portion using touch-up paint. Then use special tool MB990900 or MB991164 to temporarily tighten the door hinge mounting bolts, and align the door panel by moving it. On completion, tighten the bolts securely.

NOTE: If the replacement hinge is used or the hinge has already been separated from the washer, use special tool MB990900 or MB991164 to loosen the door-side door hinge mounting bolts, and align the door panel by moving it.

3. When the door is stiff to lock and unlock


- (1) Adjustment by using the striker (toward the inside of the vehicle and vertical direction)

Install an appropriate bolt instead of the striker mounting bolt, and use special tool MB990939 and a hammer to tap the bolt to the desired direction.




- (2) Adjustment by using the striker (toward the outside of the vehicle)

Use special tools MB990211 and MB990243 to pull the striker toward the outside of the vehicle.



- (3) Adjustment by using shims (forward and rearward)

Increase or decrease the number of shims so that the striker engages with the door latch properly.




DOOR WINDOW GLASS ADJUSTMENT

M1423001000112

Check that the door glass moves while contacting the door glass channel when it is raised and lowered fully. If not, adjust the door window according to the following procedures.

1. Remove the door trim and waterproof film. (Refer to P.42-37.)
2. Loosen the door glass mounting screw via the adjusting hole with the door window glass fully closed, then lower the window glass a little.
3. Fully close the door window glass again and tighten the door glass mounting screw firmly via the adjusting hole.



GLASS SLIDING MECHANISM CHECK AND ADJUSTMENT

M1429000900035

If the window glass automatically starts moving downwards at the wrong time while it is being raised, carry out the following adjustment or replacement procedures.


1. Remove the door trim and waterproof film (Refer to P.42-37).

NOTE: Insert a cushion or similar object to prevent damage to the glass if it should happen to fall down.

2. Remove the window regulator assembly from the door window glass, and then raise and lower the door window glass by hand to check the operation force.
3. If the door window glass does not move up and down smoothly, check or repair the following points.
 - Check the installation condition of the runchannel.
 - Repair any twisting in the door sash.
 - Check the installation condition of the lower sash or the center sash.

NOTE: The lower sash cannot normally be adjusted, but it may be possible to adjust the sash span slightly within the range allowed by manufacturing tolerances by pushing the lower sash outwards while re-installing it.

4. If repair or adjustment is not possible, replace the door assembly.



POWER WINDOW TIMER FUNCTION CHECK

M1429004300068

After the doors are closed and the ignition switch is turned to the "LOCK" (OFF) position, the power windows should work within 30 seconds. The timer expires at the point the front door is opened during that 30 second time. If not, carry out the troubleshooting (Refer to GROUP 54B, Diagnosis [P.54Ba-5.](#))


POWER WINDOW OPERATING CURRENT CHECK

M1429001100054

1. Remove the power window fuse and connect an ammeter as shown in the illustration.
2. When the power window switch is pressed to the "UP" position, a large amount of current flows at the time the window starts to close and when it is fully closed, so measure the operation current in the interval between these two points.


Standard value (A): $5 \pm 1A$ [Power supply voltage $14.5 \pm 0.5V$, $25^{\circ}C$ ($77^{\circ}F$)]

3. If the operation current is outside the standard value, refer to GROUP 54B Diagnosis [P.54Bb-2.](#)



POWER WINDOW RELAY CHECK

M1429001800127



BATTERY VOLTAGE	TESTER CONNECTION	SPECIFIED CONDITION
Not applied	4 – 5	Open circuit
<ul style="list-style-type: none">• Connect terminal No. 1 and the positive battery terminal.• Connect terminal No. 3 and the negative battery terminal.		Less than 2 ohms

CIRCUIT BREAKER (INCORPORATED IN THE POWER WINDOW MOTOR) INSPECTION

M1429001000091

1. Pull the power window switch to the UP position to fully close the door window glass, and keep pulling the switch for 10 additional seconds.
2. Release the power window switch from the UP position and immediately press it to the DOWN position. The condition of the circuit breaker is good if the door window glass starts to move downwards within 60 seconds.

POWER WINDOW CHECK

M1429004400076

1. Operate the power window switch of each seat to check and see that the power windows operate properly. If they don't then execute troubleshooting remedies. (Refer to GROUP 54B, Diagnosis [P.54Ba-5.](#))
2. Turn ON the power window lock switch of the power window main switch. Then operate the passenger's seat and back seat's power window sub switch to ensure that they do not operate. If they do, replace the power window main switch. (Refer to [P.42-37.](#))

CENTRAL DOOR LOCKING SYSTEM INSPECTION

M1427001100058

Check the following. Execute troubleshooting procedures if operations malfunction. (Refer to GROUP 54B, Diagnosis [P.54Ba-5.](#))

- Insert the key into the driver's key cylinder and turn once to the unlock side to unlock the driver's door. Turn the key once again to the unlock side to unlock all doors.
- All doors can be locked or unlocked using the front door <RH> key cylinder key operation.
- All door can be locked using the driver's inside door lock knob.
- All doors can be locked using the door lock switch built into the front power window (main or sub <RH>) switch.

DOOR OUTSIDE HANDLE PLAY CHECK

M1423001600103


1. Check that the door outside handle play is within the standard value range.

Standard value (A):



Front door: 2.3 ± 2.1 mm (0.09 ± 0.08 inch)

Rear door: 1.3 ± 1.7 mm (0.05 ± 0.07 inch)

2. If the door outside handle play is not within the standard value range, check the door outside handle or the door latch assembly. Replace, if necessary.



AC006113AB



DOOR INSIDE HANDLE PLAY ADJUSTMENT

M1423001500203

1. Check that the door inside handle play is within the standard value range.

Standard value (B):

Front door: 10.4 ± 9.6 mm (0.41 ± 0.38 inch)

Rear door: 10 ± 9.6 mm (0.39 ± 0.38 inch)

2. If the door inside handle play is outside the standard value range.
3. Remove the door trim assembly. (Refer to [P.42-37.](#))
4. Remove the waterproof film. (Refer to [P.42-37.](#))
5. Adjust the door inside handle play with the outer cable end connecting the door inside handle and inside lock cable.


DOOR ASSEMBLY REMOVAL AND INSTALLATION

M1423002200119


Post-installation Operation

- Door Fit Adjustment (Refer to P.42-29.)

<FRONT DOOR>



<REAR DOOR>



REMOVAL

1. DAMPER MAIL

DOOR ASSEMBLY REMOVAL STEPS

2. HARNESS CONNECTOR
3. DOOR CHECK CONNECTING BOLT
4. DOOR ASSEMBLY
5. DOOR UPPER HINGE
6. DOOR LOWER HINGE

STRIKER REMOVAL STEPS

>>A<<

7. STRIKER

8. STRIKER SHIM


DOOR SWITCH REMOVAL STEPS

9. DOOR SWITCH CAP
10. DOOR SWITCH

INSTALLATION SERVICE POINT

>>A<< STRIKER INSTALLATION


Align the center of the striker and latch within ± 1.5 mm (0.06 inch), and install.



INSPECTION

M1423006000258


DOOR SWITCH CHECK




SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released (ON)	1 – 2, 1 – 3, 2 – 3	Less than 2 ohms
Depressed (OFF)	1 – 2, 1 – 3, 2 – 3	Open circuit

DOOR TRIM AND WATERPROOF FILM REMOVAL AND INSTALLATION


M1423004300112



<FRONT DOOR>



<REAR DOOR>



REMOVAL STEPS

1. CAP
2. PULL HANDLE BOX
3. POWER WINDOW SWITCH PANEL ASSEMBLY
4. DOOR INSIDE HANDLE COVER
5. CLIP
6. REGULATOR HANDLE
7. ESCUTCHEON
8. DOOR TRIM ASSEMBLY

<<A>>

<>

>>B<<

>>B<<

>>B<<

REMOVAL STEPS (Continued)

9. SPEAKER
10. POWER WINDOW SWITCH BRACKET
11. WATERPROOF FILM

>>A<<





Required Special Tool:

- MB990784: Ornament Remover


CLIP AND CLAW POSITIONS

NOTE


 : CLIP POSITIONS
 : CLAW POSITIONS




SECTION A - A




SECTION B - B




SECTION C - C






SECTION D - D




AC100001AB




NOTE
◄ : CLIP POSITIONS
◄◄ : CLAW POSITIONS




SECTION A - A




SECTION B - B



SECTION C - C




SECTION D - D




REMOVAL SERVICE POINTS**<<A>> DOOR INSIDE HANDLE COVER REMOVAL**


1. Insert a flat-tipped screwdriver into the rear end of the tapping screw cap on the door inside handle cover, and prize out the cap to the direction shown. Then remove the tapping screw.



2. Insert special tool MB990784 into the clearance between the door inside handle cover and the door inside handle, and disengage the claws of the door inside handle.
3. Insert special tool MB990784 into the rear end of the inside handle cover, and prize out the cover to the direction shown. Then remove the door inside handle cover.

**<> CLIP REMOVAL**


Use cloth to remove the clip as shown in the illustration.



INSTALLATION SERVICE POINTS


>>A<< WATERPROOF FILM INSTALLATION

Apply the specified adhesive on the waterproof film as shown in the illustration, and then glue it on the door window glass.



>>B<< REGULATOR HANDLE/CLIP/ESCUTCHEON INSTALLATION

1. Install escutcheon and regulator handle to the clip.
2. Close the door window glass fully, and then install the regulator handle as shown in the illustration.




INSPECTION

M1429001600190

POWER WINDOW SWITCH CONTINUITY CHECK


Power window main switch's front <LH> switch check

Connect the terminal number 13 to the battery (+) post, and the terminal number 12 to the battery (-) post.

**Main switch**

SWITCH POSITION		TESTER CONNECTION	SPECIFIED CONDITION
FRONT (LH)	UP	8 – 13, 9 – 12,	Less than 2 ohms
	OFF	8 – 12, 9 – 12, 8 – 9	Less than 2 ohms
	DOWN	9 – 13, 8 – 12	Less than 2 ohms
FRONT (RH)	UP	3 – 13, 11 – 12*	Less than 2 ohms
	OFF	3 – 11, 3 – 12*, 11 – 12*	Less than 2 ohms
	DOWN	11 – 13, 3 – 12*	Less than 2 ohms
REAR (LH)	UP	1 – 13, 2 – 12*	Less than 2 ohms
	OFF	1 – 2, 1 – 12*, 2 – 12*	Less than 2 ohms
	DOWN	2 – 13, 1 – 12*	Less than 2 ohms
REAR (RH)	UP	14 – 13, 6 – 12*	Less than 2 ohms
	OFF	6 – 14, 6 – 12*, 14 – 12*	Less than 2 ohms
	DOWN	6 – 13, 14 – 12*	Less than 2 ohms

NOTE: *: Set switch to UNLOCK position

**Sub switch**

SWITCH POSITION		TESTER CONNECTION	SPECIFIED CONDITION
Sub switch	UP	5 – 7, 6 – 8	Less than 2 ohms
	OFF	4 – 7, 6 – 8	Less than 2 ohms
	DOWN	4 – 7, 5 – 6	Less than 2 ohms

DOOR GLASS AND REGULATOR REMOVAL AND INSTALLATION

M1429001300111


Pre-removal Operation

- Door Trim and Waterproof Film Removal (Refer to [P.42-37.](#))


Post-installation Operation

- Door Window Glass Adjustment (Refer to [P.42-31.](#))
- Door Trim and Waterproof Film Installation (Refer to [P.42-37.](#))

<FRONT DOOR>



<REAR DOOR>



DOOR WINDOW REGULATOR ASSEMBLY REMOVAL STEPS

- <<A>> >>B<< 1. WINDOW REGULATOR ASSEMBLY
<<A>> >>B<< 2. POWER WINDOW MOTOR ASSEMBLY

DOOR WINDOW GLASS REMOVAL STEPS

- WINDOW GLASS RUNCHANNEL (REFER TO [P.42-51.](#))
- DOOR WINDOW GLASS

STATIONARY WINDOW GLASS REMOVAL STEPS

- WINDOW GLASS RUNCHANNEL (REFER TO [P.42-51.](#))
- DOOR BELTLINE INNER WEATHERSTRIP (REFER TO [P.42-51.](#))
- DOOR WINDOW GLASS
- CENTER SASH UPPER
- STATIONARY WINDOW GLASS
- STATIONARY WINDOW WEATHERSTRIP

Required Special Tool:

- MB990480: Window Glass Holder

REMOVAL SERVICE POINTS



<<A>> WINDOW REGULATOR ASSEMBLY/POWER WINDOW MOTOR ASSEMBLY REMOVAL

- Remove the door window glass installation bolts.

⚠ CAUTION

If film or others are adhered to the door window glass, attach special tool MB990480 to the outside of the glass to prevent the film from peeling off.

2. Lift the door window glass, and attach special tool MB990480 to the glass as shown to prevent the glass from falling.
3. Remove the window regulator assembly and power window motor assembly

**<> CENTER SASH UPPER REMOVAL**


1. Remove the door outer opening weatherstrip from the center sash upper only.
2. Remove the center sash upper mounting screws, and then remove the center sash upper from the door panel.

INSTALLATION SERVICE POINTS**>>A<< CENTER SASH UPPER INSTALLATION**


Securely insert the center sash upper into the window rear sash (door).

**>>B<< WINDOW REGULATOR ASSEMBLY/POWER
WINDOW MOTOR ASSEMBLY INSTALLATION**

When installing the window regulator assembly, tighten the bolts to the specified torque in the order shown.

**INSPECTION**

M1429001400215

POWER WINDOW MOTOR CONTINUITY CHECK

TESTER CONNECTION	SLIDER POSITION
<ul style="list-style-type: none">• Connect terminal No. 2 and the positive battery terminal.• Connect terminal No. 1 and the negative battery terminal.	UP
<ul style="list-style-type: none">• Connect terminal No. 1 and the positive battery terminal.• Connect terminal No. 2 and the negative battery terminal.	DOWN

POWER WINDOW MOTOR CHECK

1. Connect a battery directly to the motor terminals and check that the motor runs smoothly.
2. Check that the motor runs in the opposite direction when the battery is connected with the polarity reversed.
3. If defect is found, replace the window regulator as an assembly.

DOOR HANDLE AND LATCH REMOVAL AND INSTALLATION

M1423004600135


Pre-removal Operation

- Door Trim Removal (Refer to [P.42-37.](#))

Post-installation Operation

- Door Inside Handle Play Check (Refer to [P.42-34.](#))
- Door Outside Handle Play Check (Refer to [P.42-33.](#))
- Door Trim Installation (Refer to [P.42-37.](#))


<FRONT DOOR>



DOOR HANDLE AND DOOR LATCH ASSEMBLY REMOVAL STEPS

- >>C<<
1. DOOR INSIDE HANDLE
 - WATERPROOF FILM (REFER TO [P.42-37.](#))
 2. DOOR ENERGY ABSORBER CORE
 - DOOR BELTLINE INNER WEATHERSTRIP (REFER TO [P.42-51.](#))
 - CENTER SASH UPPER (REAR DOOR) (REFER TO [P.42-43.](#))
 3. DOOR LOCK KEY CYLINDER

<REAR DOOR>




DOOR HANDLE AND DOOR LATCH ASSEMBLY REMOVAL STEPS

- >>B<<
4. DOOR OUTSIDE HANDLE
 5. LOWER SASH
 6. DOOR LATCH ASSEMBLY
 7. LINK

DOOR CHECK REMOVAL STEPS

- WATERPROOF FILM (REFER TO [P.42-37.](#))
- >>A<<
8. DOOR CHECK

INSTALLATION SERVICE POINTS




>>A<< DOOR CHECK INSTALLATION

Install the door check so that the identification mark faces upwards.

ITEMS		IDENTIFICATION MARK
Front Door	Left door	39L
	Right door	39R
Rear Door	Left door	40L
	Right door	40R

>>B<< LOWER SASH INSTALLATION

Securely insert the rear lower sash into the window rear sash.



>>C<< DOOR INSIDE HANDLE INSTALLATION

1. Install the inside lock cable to the door inside handle as follows:
 - (1) Install the inner cable end in the inside lock cable to the clip in the door inside handle.
 - (2) Turn the inside lock knob to the door lock position.
 - (3) Install the outer cable end to the door inside handle securely.
 - (4) Install the clip to the inner cable.
2. Install the inside handle rod to the door inside handle.
3. Install the door inside handle to the door.

INSPECTION

FRONT DOOR LOCK ACTUATOR CHECK

Actuator Operation Check <Left side>


LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 4 and the negative battery terminal. Connect terminal No. 6 and the positive battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 4 and the positive battery terminal. Connect terminal No. 6 and the negative battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.


Actuator Switch Check <Left side>

LEVER POSITION	TESTER CONNECTION	SPECIFIED CONDITION
At the "LOCK" position	1 – 3	Less than 2 ohms
At the "UNLOCK" position	1 – 2	Less than 2 ohms

Actuator Operation Check <Right side>

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 4 and the positive battery terminal. Connect terminal No. 6 and the negative battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 4 and the negative battery terminal. Connect terminal No. 6 and the positive battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.




REAR DOOR LOCK ACTUATOR CHECK**Actuator Operation Check <Left side>**

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 2 and the negative battery terminal. Connect terminal No. 3 and the positive battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 2 and the positive battery terminal. Connect terminal No. 3 and the negative battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.

Actuator Operation Check <Right side>

LEVER POSITION	BATTERY CONNECTION	LEVER OPERATION
At the "LOCK" position	<ul style="list-style-type: none"> Connect terminal No. 2 and the positive battery terminal. Connect terminal No. 3 and the negative battery terminal. 	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> Connect terminal No. 2 and the negative battery terminal. Connect terminal No. 3 and the positive battery terminal. 	The lever moves from the "UNLOCK" position to the "LOCK" position.

DOOR LOCK KEY CYLINDER SWITCH CHECK**<Driver's side>**

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
LOCK	2 - 3	Less than 2 ohms
NEUTRAL (OFF)	1 - 2, 2 - 3	Open circuit
UNLOCK	1 - 2	Less than 2 ohms

<Passenger's side>

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
LOCK	1 - 2	Less than 2 ohms
NEUTRAL (OFF)	1 - 2, 2 - 3	Open circuit
UNLOCK	2 - 3	Less than 2 ohms

CENTRAL DOOR LOCK SWITCH CONTINUITY
CHECK



Remove the power window switch. (Refer to P.42-37.)

<Driver's side>

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
LOCK	5 – 12	Less than 2 ohms
OFF	5 – 12, 10 – 12, 5 – 12	Open circuit
UNLOCK	10 – 12	Less than 2 ohms


<Passenger's side>

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
LOCK	1 – 2	Less than 2 ohms
OFF	1 – 2, 2 – 3, 1 – 3	Open circuit
UNLOCK	2 – 3	Less than 2 ohms





WINDOW GLASS RUNCHANNEL AND DOOR OPENING WEATHER-STRIP REMOVAL AND INSTALLATION <FRONT DOOR>

M1423003100115



Y0650AU



AC100105AB

DOOR INNER OPENING WEATHERSTRIP REMOVAL STEPS

- SCUFF PLATE, CENTER PILLAR LOWER TRIM AND COWL SIDE TRIM (REFER TO GROUP 52A, TRIMS [P.52A-11.](#))
- 1. DOOR INNER OPENING WEATHERSTRIP (BODY SIDE)

DOOR OUTER OPENING WEATHERSTRIP REMOVAL STEPS

- FRONT DOOR CHECK MOUNTING BOLT (DOOR SIDE) (REFER TO [P.42-35.](#))

- <<A>> >>A<< 2. DOOR OUTER OPENING WEATHERSTRIP

DOOR WINDOW GLASS RUNCHANNEL REMOVAL

3. DOOR WINDOW GLASS RUNCHANNEL

DOOR BELTLINE INNER WEATHERSTRIP REMOVAL STEPS


- FRONT DOOR TRIM (REFER TO [P.42-37.](#))

4. DOOR BELTLINE INNER WEATHERSTRIP


DOOR BELTLINE MOULDING REMOVAL STEPS

- DOOR MIRROR ASSEMBLY (REFER TO GROUP 51, DOOR MIRROR [P.51-49.](#))
- DOOR WINDOW GLASS (REFER TO [P.42-43.](#))
- 5. DOOR BELTLINE MOULDING


<REAR DOOR>




←:SECTIONAL VIEW OF
CLIP POSITION



←:SECTIONAL VIEW OF
CLIP POSITION




SECTION A - A



DOOR

Y1503AU

SECTION B - B



DOOR

Y1504AU

Y1391AU

AC100106AB

DOOR INNER OPENING WEATHERSTRIP REMOVAL STEPS

- SCUFF PLATE, CENTER PILLAR LOWER TRIM AND COWL SIDE TRIM (REFER TO GROUP 52A, TRIMS [P.52A-11.](#))
- 1. DOOR INNER OPENING WEATHERSTRIP (BODY SIDE)

DOOR OUTER OPENING WEATHERSTRIP REMOVAL STEPS

- REAR DOOR CHECK MOUNTING BOLT (DOOR SIDE) (REFER TO [P.42-35.](#))
- 2. RETAINER WEATHERSTRIP
- 3. DOOR OUTER OPENING WEATHERSTRIP

<<A>> >>A<<

DOOR WINDOW GLASS RUNCHANNEL REMOVAL

- 4. DOOR WINDOW GLASS RUNCHANNEL

DOOR BELTLINE INNER WEATHERSTRIP REMOVAL STEPS

- REAR DOOR TRIM (REFER TO [P.42-37.](#))
- CENTER SASH UPPER (REFER TO [P.42-43.](#))
- 5. DOOR BELTLINE INNER WEATHERSTRIP


DOOR BELTLINE MOULDING REMOVAL STEPS

- DOOR WINDOW GLASS (REFER TO [P.42-43.](#))
- STATIONARY GLASS (REFER TO [P.42-43.](#))
- 6. DOOR BELTLINE MOULDING

REMOVAL SERVICE POINT

<<A>> DOOR OUTER OPENING WEATHERSTRIP
REMOVAL

Make a fabricated tool as shown in the illustration to remove the door weatherstrip.



INSTALLATION SERVICE POINT

>>A<< DOOR OUTER OPENING WEATHERSTRIP INSTAL-
LATION

The clip color identifies the left and right weatherstrips so be sure to use the colors so as to install correctly.

APPLICABLE SIDE	IDENTIFICATION COLOR
Right door	Pink
Left door	Natural (White)

TRUNK LID

TRUNK LID DIAGNOSIS

INTRODUCTION TO TRUNK LID DIAGNOSIS

Difficult locking and unlocking, uneven clearance and height, and generation of wind noise from the trunk lid may be caused by improper adjustment of the trunk lid.

M1421005800211

TRUNK LID DIAGNOSTIC TROUBLESHOOTING STRATEGY

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a trunk lid fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

M1421005900188

SYMPTOM CHART

M1421006000304

SYMPTOM	INSPECTION PROCEDURE	REFERENCE PAGE
Difficult locking and unlocking	1	P.42-54
Uneven body clearance	2	P.42-54
Uneven height	3	P.42-54

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Difficult Locking and Unlocking

DIAGNOSIS

STEP 1. Check the release cable routing condition.**Q: Is the release cable routing condition good?****YES :** Go to Step 3.**NO :** Repair the release cable, then go to Step 2.

STEP 2. Check the engagement of the trunk lid latch and trunk lid striker.**Q: Are the trunk lid latch and trunk lid striker engaged correctly?****YES :** Adjust the trunk lid striker. Refer to [P.42-56](#).**NO :** Then go to Step 3.

STEP 3. Retest the system.**Q: Does the trunk lid lock operate easily?****YES :** The procedure is complete.**NO :** Return to Step 1.

INSPECTION PROCEDURE 2: Uneven Body Clearance

DIAGNOSIS

STEP 1. Check the clearance around the trunk lid..**Q: Are the apertures between the trunk lid and the adjacent body panels aligned correctly?****YES :** Adjust the trunk lid panel assembly. Refer to [P.42-56](#).**NO :** Then go to Step 2.

STEP 2. Retest the system.**Q: Are the clearances between the body panels even?****YES :** The procedure is complete.**NO :** Return to Step 1.

INSPECTION PROCEDURE 3: Uneven Height

DIAGNOSIS

STEP 1. Check the trunk lid bumper height.**Q: Is the trunk lid bumper height proper?****YES :** Adjust the trunk lid bumper. Refer to [P.42-57](#).**NO :** Then go to Step 2.


STEP 2. Retest the system.**Q: Are the trunk lid and body height even?****YES :** The procedure is complete.**NO :** Return to Step 1.

ON-VEHICLE SERVICE

TRUNK LID ADJUSTMENT

M1421001000020

1. If the clearance around the trunk lid panel assembly is uneven, and the trunk lid locks and unlocks stiffly, adjust the trunk lid bumper (refer to [P.42-56](#)) and trunk lid hinge (refer to [P.42-56](#)).
2. If the clearance around the trunk lid panel assembly is even, and the trunk lid locks and unlocks stiffly, adjust the trunk lid bumper (refer to [P.42-56](#)) and trunk lid striker (refer to [P.42-56](#)).
3. If the side outer panel is not flush with the trunk lid panel, check the trunk lid hinge and replace it if necessary.




4. If the clearance around the trunk lid panel assembly is uneven, and the trunk lid locks and unlocks stiffly, readjust the trunk lid hinge (Refer to [P.42-56](#)).
5. If the trunk lid locks or unlocks stiffly still after the adjustments above, adjust the trunk lid striker (Refer to [P.42-56](#)).

ADJUSTMENT OF CLEARANCE AROUND TRUNK LID


M1421008100017

Loosen the trunk lid panel assembly mounting bolts, and adjust the clearance around the trunk lid panel assembly by moving it.

**TRUNK LID STRIKER ADJUSTMENT**

M1421008200014


Make sure that the routing of the trunk lid release cable is good. Loosen the trunk lid striker mounting bolts, and then adjust the striker by moving it until it engages with the trunk lid latch assembly properly.

**TRUNK LID HEIGHT ADJUSTMENT**

M1421008300011

Turn each trunk lid bumper until the height shown in the drawing trunk lid bumper.



Standard value (B): 14 mm (0.5 inch)



TRUNK LID

REMOVAL AND INSTALLATION

M1421002200168



TRUNK LID WEATHERSTRIP REMOVAL STEPS

- REAR END TRIM (REFER TO GROUP 52A, TRIM [P.52A-11.](#))
- >>B<<

1. TRUNK LID WEATHERSTRIP TRUNK LID RELEASE CABLE AND TRUNK LID RELEASE HANDLE REMOVAL STEPS

- TRUNK REAR SIDE TRIM (LH) (REFER TO GROUP 52A, TRIM [P.52A-11.](#))
 - REAR SEAT (REFER TO GROUP 52A, SEAT [P.52A-18.](#))
 - CENTER PILLAR LOWER TRIM (REFER TO GROUP 52A, TRIM [P.52A-11.](#))
 - COWL SIDE TRIM (REFER TO GROUP 52A, TRIM [P.52A-11.](#))
 - ACCELERATOR PEDAL STOPPER (REFER TO GROUP 17, ACCELERATOR PEDAL [P.51-13.](#))
2. TRUNK LID RELEASE HANDLE
 3. TRUNK LID RELEASE CABLE

<<A>> >>A<<
<<A>> >>A<<

TRUNK LID STRIKER REMOVAL STEPS

- REAR END TRIM (REFER TO GROUP 52A, TRIM [P.52A-11.](#))

4. TRUNK LID STRIKER

TRUNK LID PANEL REMOVAL STEPS

5. TRUNK LID BUMPER
6. TRUNK LID LOCK CYLINDER
7. TRUNK LID LATCH ASSEMBLY
8. HANDLE HOLDER
9. TRUNK LID HINGE MOUNTING BOLT
10. TRUNK LID PANEL ASSEMBLY

TRUNK LID LATCH REMOVAL


7. TRUNK LID LATCH ASSEMBLY

TRUNK LID HINGE REMOVAL STEPS


- REAR SHIELD TRIM (REFER TO GROUP 52A, TRIM [P.52A-11.](#))
 - REAR SEAT (REFER TO GROUP 52A, SEAT [P.52A-18.](#))
10. TRUNK LID PANEL ASSEMBLY
 11. TRUNK LID TORSION BAR (LH)
 12. TRUNK LID TORSION BAR (RH)
 13. TRUNK LID HINGE

AC204020AB


GREASE APPLICATION AREA



Y0635AU



AC005974



AC006100


AC006101AB

REMOVAL SERVICE POINT

<<A>> TRUNK LID TORSION BAR REMOVAL

Insert the tire lever into the torsion bar, and then pull upward the tire lever to remove the torsion bar as shown in the illustration.

NOTE: As the left and right trunk lid torsion bars are crossed at the center, first remove the front trunk lid torsion bar at the center.



AC006102AB

INSTALLATION SERVICE POINTS

>>A<< TRUNK LID TORSION BAR INSTALLATION

Install the trunk lid torsion bar by the following procedure.

CAUTION

As the trunk lid torsion bar (RH) is painted with differentiation color in the middle to differentiate between RH and LH, be careful when installing.

1. Ensure that there is the identification color at the center of the trunk lid torsion bar.

EQUIPMENT	IDENTIFICATION COLOR
Trunk lid torsion bar (LH) <Vehicles without rear spoiler>	-
Trunk lid torsion bar (RH) <Vehicles without rear spoiler>	Red
Trunk lid torsion bar (LH) <Vehicles with rear spoiler>	Green
Trunk lid torsion bar (RH) <Vehicles with rear spoiler>	Yellow



2. Install the trunk lid torsion bar (LH) as follows.

- (1) For terminal A, insert the trunk lid hinge (LH) into the fixed hole B.
- (2) For terminal C, touch the trunk lid hinge (RH) against portion E.
- (3) For terminal D, insert the trunk lid hinge (RH) into portion F until portion G while twisting with the tool such as a tire lever, etc.
- (4) For terminal C, set the trunk lid hinge (RH) at portion H while twisting with the tool such as a tire lever, etc.

3. Install the trunk lid torsion bar (RH) in the same way as above.

>>B<< TRUNK LID WEATHERSTRIP INSTALLATION


Install the trunk lid weatherstrip so that the marking and the joint are aligned with the body center line,



INSPECTION

M1421004800111

TRUNK LID LATCH SWITCH CONTINUITY CHECK



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
ON (Latch open)	1 – Ground	Less than 2 ohms
OFF (Latch shut)	-	Open circuit

KEYLESS ENTRY SYSTEM

GENERAL DESCRIPTION

M1428000100100

Some models are equipped with a radio-controlled keyless entry system. The main features are:

- Antenna and receiver are incorporated in the ETACS-ECU.
- ID code can be registered by using the scan tool (MUT-II).
- Transmitter is a key holder type, which incorporates lock switch and unlock switch.

- The locking is answered back by two times' flashing of the room lamp, two times' flashing of the turn signal lamp and one time sounding of the horn answerback.
- The unlocking is answered back by illuminating of the room lamp for 15 seconds and one time flashing of the turn signal lamp.

KEYLESS ENTRY SYSTEM DIAGNOSIS

M1428000700113

The keyless entry system is controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, Diagnosis [P.54Bb-2](#).

SPECIAL TOOLS

M1428000600105

TOOL	TOOL NUMBER AND NAME	SUPERSESSON	APPLICATION
 B991502	MB991502 Scan tool (MUT-II)	DRB-III scan tool	For registration of secret code
 MB991529	MB991529 Diagnostic trouble code check harness	MB991529	For setting of hazard answerback function

ON-VEHICLE SERVICE

HOW TO REPLACE THE TRANSMITTER BATTERY

M1428000900106


CAUTION

Do not allow water or dust to enter the inside of the transmitter when it is open. Also, do not touch the precision electronic device.

1. Remove the set screw to remove the battery from the transmitter.
2. Install a battery with its (+) side face-down.

Battery required for replacement: Coin type battery CR2032

3. Insert the claw first, and assemble the transmitter.
4. Verify that the keyless entry system operates.



KEYLESS ENTRY SYSTEM TIMER LOCK FUNCTION INSPECTION

M1428004000042

Unlock the transmitter and check to see that the doors lock within 30 seconds. If it doesn't, then execute troubleshooting remedies. Refer to GROUP 54B, Diagnosis [P.54Ba-5](#).


ENABLING/DISABLING THE ANSWERBACK FUNCTION


M1428003200151

If the keyless entry system locks or unlocks the doors, the dome light flashes or illuminates, the hazard warning light flashes (hazard answerback function) and the horn sounds (horn answerback function). The hazard and horn answerback functions can be enabled or disabled according to the following procedure:

ENABLING/DISABLING THE HAZARD ANSWERBACK FUNCTION

The hazard answerback function can be enabled or disabled by one of the two following procedures.





<When the transmitter is used after connecting scan tool MB991502 to the data link connector or grounding data link connector terminal (1)>

1. Enter the hazard answerback customize mode by observing one of the following steps. If the ETACS-ECU enters the customize mode, its tone alarm will sound once.
 - (1) Turn the ignition switch to "LOCK"(OFF) position.
 - (2) Turn off the hazard warning light switch.
 - (3) Connect scan tool MB991502 to the data link connector terminal (1).
 - (4) Close the driver's side door.
 - (5) Leave the windshield washer switch on for at least ten seconds. Then the ETACS-ECU tone alarm will sound once.
2. If the transmitter "LOCK" switch is pushed consecutively twice (within two seconds), the ETACS-ECU tone alarm will sound, indicating that the hazard answerback function can be enabled or disabled when the doors are locked.
 - **Enable the hazard answerback function when the doors are locked: The ETACS-ECU tone alarm will sound once.**
 - **Disable the hazard answerback function when the doors are locked: The ETACS-ECU tone alarm will sound twice.**
3. If the transmitter "UNLOCK" switch is pushed consecutively twice (within two seconds), the ETACS-ECU tone alarm will sound, indicating that the hazard answerback function can be enabled or disabled when the doors are unlocked.
 - **Enable the hazard answerback function when the doors are unlocked: The ETACS-ECU tone alarm will sound once.**
 - **Disable the hazard answerback function when the doors are unlocked: The ETACS-ECU tone alarm will sound twice.**
4. Exit the hazard answerback customize mode by observing one of the following steps.
 - (1) Disconnect scan tool MB991502 from the data link connector, or disconnect data link connector terminal (1) from the ground.
 - (2) Turn the ignition switch to position other than "LOCK"(OFF), or remove the ignition key.
 - (3) Open the driver's side door,
 - (4) Any other warning tone alarm output occurs

NOTE: If any operation is not done for at least three minutes after the ETACS-ECU has entered the customize mode, the hazard answerback customize mode will be canceled automatically.

<When only the transmitter is used>

1. Remove the ignition key.

2. Push the "LOCK" switch while holding the "UNLOCK" switch pushed for four to ten seconds.
3. If the "LOCK" switch and "UNLOCK" switch are released in that order, the ETACS-ECU tone alarm will sound, indicating that the hazard answerback function can be enabled or disabled when the doors are locked.
 - **Enable the hazard answerback function when the doors are locked: The ETACS-ECU tone alarm will sound once.**
 - **Disable the hazard answerback function when the doors are locked: The ETACS-ECU tone alarm will sound twice.**
4. If the "UNLOCK" switch and "LOCK" switch are released in that order, the ETACS-ECU tone alarm will sound, indicating that the hazard answerback function can be enabled or disabled when the door are unlocked.
 - **Enable the hazard answerback function when the doors are unlocked: The ETACS-ECU tone alarm will sound once.**
 - **Disable the hazard answerback function when the doors are unlocked: The ETACS-ECU tone alarm will sound twice.**

ENABLING/DISABLING THE HORN ANSWERBACK FUNCTION

<When only the transmitter is used>

1. Remove the ignition key.
2. Push the "UNLOCK" switch while holding the "LOCK" switch pushed for four to 10 seconds.
3. If the "LOCK" switch and "UNLOCK" switch are released at the same time, the ETACS-ECU tone alarm will sound, indicating that the horn answerback function can be enabled or disabled.
 - **Enable the horn answerback function: The ETACS-ECU tone alarm will sound once.**
 - **Disable the horn answerback function: The ETACS-ECU tone alarm will sound twice.**
4. If the "LOCK" switch and "UNLOCK" switch are released at the same time, the ETACS-ECU tone alarm will sound, indicating that the horn answerback function can be enabled or disabled.
 - **Enable the horn answerback function*: The ETACS-ECU tone alarm will sound once.**
 - **Disable the horn answerback function: The ETACS-ECU tone alarm will sound twice.**
 - **Enable the horn answerback function**: The ETACS-ECU tone alarm will sound three times.**

NOTE:

*: The horn will sound if the doors are locked with the keyless entry system.

****:** The horns sound when the other doors are locked by the keyless entry system with some door(s) has been locked.

HOW TO REGISTER SECRET CODE

M1428001000106

Each individual secret code is registered inside the transmitter, and so it is necessary to register these codes with the EEPROM inside the receiver in the following cases.



- When the transmitter or ETACS-ECU is replaced
- If more transmitters are to be used
- If it appears that a problem is occurring because of faulty registration of a code.

A maximum of four different codes can be stored in the EEPROM memory (four different transmitters can be used). When the code for the first transmitter is registered, the previously registered codes for all transmitters are cleared. Therefore, if you are using four transmitters or are adding more transmitters, the codes for all transmitters must be registered at the same time.

1. Check that the doors lock normally when the key is used.
2. Insert the ignition key.


⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to “LOCK” (OFF) position before connecting or disconnecting scan tool MB991502.



3. Connect the scan tool to the data link connector. If the scan tool is not used, ground terminal (1) of the data link connector.

NOTE: This will connect terminal (1) of the data link connector to ground, and the system will be in secret code registration standby mode.



4. Press the hazard switch six times within 10 seconds.
NOTE: At this time the code registration monitor request is output (all doors locked and unlocked) and becomes registration mode.
NOTE: The hazard warning light switch is turned on and off alternately whenever it is pushed.
5. Press the transmitter switch, and then press it two times within 10 seconds of the first press. This will register the code.
6. When registration is completed, the code registration monitor request is output (all doors locked and unlocked).
7. If you are using two or more transmitters or have added a second transmitter, the same registration procedure should be carried out within one minute after registering the code for the first transmitter. After the second registration is completed, the code registration monitor request is output (all doors locked and unlocked).
8. Registration mode will be canceled under the following conditions:
 - When the secret code for four transmitters has been registered;
 - When one minute has been passed after registration mode started;
 - When scan tool MB991502 is disconnected (the ground connection is broken);
 - When the key is removed from the key cylinder;
9. After the registration is completed, carry out the following work, and then check that the keyless entry system operates normally.
 - Remove the ignition key.
 - Close all of the doors.

SUNROOF ASSEMBLY

GENERAL DESCRIPTION

A motor-driven outer slide-type glass sunroof with a tilt-up mechanism is adopted in some models as optional equipment. Even when the sunroof is

fully closed, a sufficient amount of light and a feeling of openness can still be obtained by opening the sunroof sunshade.

M1426000100171

SUNROOF DIAGNOSIS





The sunroof system is controlled by the Simplified Wiring System (SWS). For troubleshooting,

refer to GROUP 54B, Diagnosis [P.54Ba-5](#).

M1426000700173

SPECIAL TOOLS

M1426000600187

TOOL	TOOL NUMBER AND NAME	SUPER SESSION	APPLICATION
<div><div>A</div><div>B</div><div>C</div><div>D</div><div>MB991223AD</div></div>	<div>MB991223 Harness set</div> <ul style="list-style-type: none">• A: MB991219 Test harness• B: MB991220 LED harness• C: MB991221 LED harness adapter• D: MB991222 Probe	MB991223	<div>Measurement of terminal voltage</div> <ul style="list-style-type: none">• A: Connector pin contact pressure inspection• B: Power circuit inspection• C: Power circuit inspection• D: Commercial tester connection


ON-VEHICLE SERVICE

WATER TEST

M1426000900188

Check if there are any leaks in the sunroof by the following procedure.

1. Fully close the roof lid glass.
2. Adjust the water pressure so that water comes out of the hose to a height of approximately 50 cm (19.7 inches) when the hose is held vertically facing upwards.
3. Hold the end of the hose approximately 30 cm (11.8 inches) above the roof and let the water run onto the weatherstrip for 5 minutes or more.
4. Check if any water leaks can be found in the room while watering. Even though there are any water leaks around the roof lid glass, it can be acceptable as long as water is caught in the drip area.



SUNROOF TIMER FUNCTION CHECK


M1426004300047

Keep the door closed, turn OFF the ignition switch and check to see if the sunroof operates for 30 seconds after that. If operations malfunction then execute troubleshooting remedies. (Refer to GROUP 54B, Diagnosis [P.54Ba-5.](#))

SUNROOF FIT ADJUSTMENT

M1426001000188


1. Fully close the roof lid glass.
2. Fully open the sunshade.
3. Loosen the screws fixing the roof lid glass assembly, move the roof lid glass assembly along the long hole of the drive cable assembly, adjust the height of the roof lid glass, and check that the space between the roof lid glass and body is consistent along the whole circumference.
4. After adjusting, check that the sunroof operates smoothly.



SUNROOF SAFETY FUNCTION CHECK

M1426004400044


1. Close the roof lid glass by applying an approximately 10mm (0.39 inch) thickness wood chip placed in a right angle with the roof lid glass.
2. Check to see if the roof lid glass opens after the motor turns when the roof lid glass catches the wooden chip. (Refer to GROUP 54B, Diagnosis [P.54Ba-5.](#))



SUNROOF CHECK

M1426004700034

Check to see that the sunroof operates by pressing the sunroof switch. Execute troubleshooting remedies if operations malfunction. (Refer to GROUP 54B, Diagnosis [P.54Ba-5.](#))

**ROOF LID GLASS OPERATION CURRENT CHECK**

M1426003200081

1. Remove the fuse of the sunroof then connect the circuit tester as shown in the Figure.
2. Turn ON the sunroof switch then measure the operating current of the intermediary segment when operations is starting, the sunroof is fully closed, the sunroof is fully opened and the sunroof is tilted fully up.

Standard value: 7 A or less [at 20 °C (68 °F)]

3. Check the following areas if the operating current of the roof lid glass exceeds the standard value.
 - Sunroof assembly assembling state, deformation and biting of any foreign substances.
 - Drive cable fastening
 - Tilting of roof lid glass

SUNROOF INITIALIZED ADJUSTMENT

M1426004600048

1. Assemble the roof lid glass assembly and sunroof motor assembly on the sunroof assembly.
2. Connect the sunroof motor assembly connector and sunroof switch connector to the wire ring harness connector on the vehicle side.
3. Fully open the roof lid glass by pressing the sunroof switch then fully close the sunroof by repeating to press the close switch.
4. Continuously press the close switch for a minimum of 3 seconds from the fully closed state.
5. Press the open switch to fully open the sunroof then press the close switch to fully close the sunroof.

NOTE: Do not stop the sunroof before the sunroof is fully opened or fully closed in Step 5, above. If the fully open or close operation is interrupted/stopped then start over from Step 3.

OPERATION CHECK

M1426002600213

Check that the following items. If faulty, replace the sunroof-ECU (sunroof motor assembly).

⚠ CAUTION

Check that the following items are normal before carrying out this operation check.

1. Installation condition of the sunroof assembly
2. Installation condition, deforms and attached foreign material of the sunroof drive cable
3. Unfitted sunroof lid glass
4. Sunroof switch and sunroof motor assembly

Basic operation

NO.	SUNROOF FUNCTION	REQUIREMENTS FOR THE SUNROOF TO FUNCTION		NORMAL OPERATION
01	OPEN	1. Ignition switch: ON 2. Sunroof switch: OPEN		The sunroof opens fully and automatically.
02	CLOSE	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN		The sunroof closes while the sunroof switch is pushed to the CLOSE/TILT-DOWN position.
03	TILT-UP	1. Ignition switch: ON 2. Sunroof switch: TILT-UP		The sunroof tilts up fully and automatically.
04	TILT-DOWN	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN		The sunroof closes while the sunroof switch is pushed to the CLOSE/TILT-DOWN position.
05	AUTOMATIC OPERATION INTERRUPTION	A	1. Ignition switch: ON 2. Sunroof switch: TILT-UP or CLOSE/TILT DOWN (Push the sunroof switch to the CLOSE/TILT-DOWN position while the sunroof is automatically opening and release the switch within two seconds)	The sunroof stops the automatic opening operation.
		B	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT DOWN (Push the sunroof switch to the CLOSE/TILT-DOWN position more than two seconds while the sunroof is automatically opening)	The sunroof stops the automatic opening operation, and the sunroof closes while the sunroof switch is pushed to the CLOSE/TILT-DOWN position.

Jam preventing mechanism

NO.	SUNROOF FUNCTION	REQUIREMENTS FOR THE SUNROOF TO FUNCTION	NORMAL OPERATION
01	CLOSE	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN 3. Sunroof initial position: being closed or opened 4. Interrupt the sunroof operation before the sunroof is fully closed.	After you interrupts the sunroof operation, it opens by the predetermined distance and then stops automatically.
02	TILT-DOWN	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN 3. Sunroof initial position: being tilting down 4. Interrupt the sunroof operation before the sunroof is fully close.	The sunroof tilts up automatically after it is interrupted.

Sunroof timer mechanism

In cases except the followings, the basic operation and jam preventing mechanism will be maintained for thirty seconds after the ignition switch is turned to the LOCK (OFF) position. (Sunroof timer function)

- If you open a door within that period (i.e. a door switch is on), the sunroof timer function will be cancelled immediately.
- If you closes the sunroof fully while the timer is working, the sunroof timer function is cancelled after that sunroof operation.
- If you turns the ignition switch to the LOCK (OFF) position while the timer is working, the sunroof will continue moving until it closes fully regardless of the time-out period.


SUNROOF ASSEMBLY

REMOVAL AND INSTALLATION

M1426001200193

Post-installation Operation <Roof lid glass assembly, Sunroof assembly>

- Sunroof Water Test (Refer to [P.42-66.](#))
- Sunroof Fit Adjustment (Refer to [P.42-67.](#))
- Sunroof Initializing Adjustment (Refer to [P.42-68.](#))



AC202751AB

1. ROOF LID GLASS ASSEMBLY
SUNROOF SWITCH REMOVAL STEPS

2. SUNROOF SWITCH COVER
3. SUNROOF SWITCH

DRAIN PIPE REMOVAL STEPS

- SPLASH SHIELD (REFER TO [P.42-9.](#))
- HEADLINING (REFER TO GROUP 52A [P.52A-14.](#))

<<A>> >>A<< 4. DRAIN PIPE

**SUNROOF MOTOR ASSEMBLY
REMOVAL STEPS**

- HEADLINING (REFER TO GROUP 52A [P.52A-14.](#))

>>B<< 5. SUNROOF MOTOR ASSEMBLY
SUNROOF ASSEMBLY REMOVAL STEPS

- HEADLINING (REFER TO GROUP 52A [P.52A-14.](#))

- <<A>> >>A<< 4. DRAIN PIPE
6. SUNROOF SWITCH BRACKET
7. ROOM LAMP BRACKET

**SUNROOF ASSEMBLY REMOVAL
STEPS (Continued)****Required Special Tool:**


- MB991223: Harness set

8. SET BRACKET
9. SUNROOF ASSEMBLY


>>B<<

INSTALLATION SERVICE POINTS**<<A>> DRAIN PIPE REMOVAL**


Tie a cord to the end of the drain pipe, and wind tape around it so that there is no unevenness. Then pull the drain pipe out to the wheel house side.


**<> SUNROOF ASSEMBLY REMOVAL**

Using round nose pliers or the like, turn the caulking the way shown in the illustration and then remove the sunroof assembly.

**INSTALLATION SERVICE POINTS****>>A<< DRAIN PIPE INSTALLATION**

1. Tie the cord that was used during removal to the end of the drain pipe, and wind tape around it so that there is no unevenness.
2. Pull the cord to pass through the drain pipe.





3. Install the grommet, and then position the drain pipe so that it protrudes from the grommet as shown in the illustration.

>>B<< SUNROOF MOTOR ASSEMBLY INSTALLATION


1. Install the roof lid glass assembly and the sunroof motor assembly with the sunroof assembly.
2. Connect the sunroof motor assembly connector and the sunroof switch connector to the vehicle wiring harness connector.
3. Operate the sunroof switch to slide the roof lid glass to the fully-open position, and then tilt it up in steps of 30 mm (1.18inch) to the fully-open position and then keep pressing the switch for 0.5 second or more.

NOTE: During initialization (learning mode), use only the CLOSE/OPEN switch to move the roof lid glass from the fully-closed position to the fully-open position. During initialization, the TILT UP switch will not work when pressed. Furthermore, the sunroof-ECU will stop running in learning mode as soon as the glass is tilted up.

INSPECTION

M1421007600332




SUNROOF SWITCH CONTINUITY CHECK



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Open	4 – 5	Less than 2 ohms
Off	3 – 4, 4 – 5, 4 – 6	Open circuit
Tilt up	3 – 4	Less than 2 ohms
Slide closed, Tilt down	4 – 6	Less than 2 ohms

DISASSEMBLY AND ASSEMBLY

M1426001400197

**DISASSEMBLY STEPS**

1. ROOF LID GLASS ASSEMBLY
2. WEATHERSTRIP
3. SUNROOF MOTOR ASSEMBLY
4. REAR DRIP
5. FRAME
6. DRIP RAIL ASSEMBLY
7. CLIP <LEFT SIDE ONLY>
8. SUN SHADE ASSEMBLY
9. DRIVE UNIT ASSEMBLY

DISASSEMBLY STEPS

10. DRIP LINK
11. DRIP SHOE ASSEMBLY
12. SHAFT
13. LIFTER ASSEMBLY
14. CABLE ASSEMBLY
15. SET PLATE
16. REAR SET PLATE
17. DEFLECTOR ASSEMBLY
18. FRAME ASSEMBLY

W0373AU

AC202752 AC

SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

M1421005300142

ITEM	SPECIFICATION
Hood	
Hood hinge bolt (hood side)	11 ± 2 N·m (98 ± 43.18 cm-lb)
Hood hinge bolt (body side)	21 ± 4 N·m (16 ± 60.96 cm-lb)
Hood hinge nut (body side)	11 ± 2 N·m (98 ± 43.18 cm-lb)
Hood latch bolt	9.0 ± 2.0 N·m (80 ± 43.18 cm-lb)
Fuel filler lid	
Fuel filler lid bolt	5.0 ± 1.0 N·m (44 ± 22.86 cm-lb)
Door	
Door check bolt (body side)	11 ± 2 N·m (98 ± 43.18 cm-lb)
Door check bolt (door side)	5.0 ± 1.0 N·m (44 ± 22.86 cm-lb)
Door hinge bolt (body side)	27 ± 5 N·m (20 ± 121.92 cm-lb)
Door hinge bolt (door side)	21 ± 4 N·m (16 ± 60.96 cm-lb)
Door outside handle bolt	5.0 ± 1.0 N·m (44 ± 22.86 cm-lb)
Door latch assembly screw	9.0 ± 2.0 N·m (80 ± 43.18 cm-lb)
Door switch screw	1.5 ± 0.5 N·m (14 ± 10.16 cm-lb)
Striker screw	11 ± 2 N·m (98 ± 43.18 cm-lb)
Trunk lid	
Trunk lid latch assembly bolt	8.8 ± 2.0 N·m (78 ± 43.18 cm-lb)
Striker bolt	8.8 ± 2.0 N·m (78 ± 43.18 cm-lb)

SERVICE SPECIFICATIONS

M1421000300170

<DOOR>

ITEM	STANDARD VALUE
Door inside handle play mm (in)	Front 2.3 ± 2.1 (0.09 ± 0.08)
	Rear 1.3 ± 1.7 (0.05 ± 0.07)
Door outside handle play mm (in)	Front 9.6 ± 9.2 (0.38 ± 0.36)
	Rear 9.0 ± 9.2 (0.35 ± 0.36)
Power window operation current A	5 ± 1 [Power supply voltage 14.5 ± 0.5V 25°C (77°F)]

<SUNROOF>

ITEM	STANDARD VALUE
Roof lid glass operation current A	7 or more [20°C (68°F)]

SEALANT AND ADHESIVES

M1421000500152

<DOOR>

ITEM	SPECIFIED SEALANT	REMARK
Waterproof film	3 M™AAD Part No. 8633 or equivalent	Ribbon sealer

<WINDOW GLASS>

ITEM	SPECIFIED ADHESIVES
Rear window glass	3 M™ AAD Part No. 8609 Super Fast Urethane and 3 M™ AAD Part No. 8608 Super Fast Urethane Primer or equivalent
Windshield	

<SUNROOF>

ITEM	SPECIFIED ADHESIVES
Rear drip	3 M™ AAD Part No. 8531 or 8646 or equivalent

COMPONENT IDENTIFICATIONS

M1421005400127

<DOOR CHECK>

APPLICABLE LOCATION		IDENTIFICATION MARK
LH	Front door	39L
	Rear door	40L
RH	Front door	39R
	Rear door	40R

<DOOR OUTER OPENING WEATHERSTRIP>

APPLICABLE SIDE	IDENTIFICATION COLOR
Left door	Natural (White)
Right door	Pink

<TRUNK LID TORSION BAR>

EQUIPMENT		IDENTIFICATION COLOR
Vehicles without rear spoiler	LH	-
	RH	Red
Vehicles with rear spoiler	LH	Green
	RH	Yellow