


Fastener Tightening Specifications

Application	Specification	
	Metric	English
Driver Seat Lumbar Support Actuator Screw	5 N·m	44 lb in
Front Seat Assembly Bolt	45 N·m	33 lb ft
Front Seat Back Frame Bolt	50 N·m	37 lb ft
Front Seat Inner Adjuster Finish Cover Screw	2 N·m	18 lb in
Front Seat Inner Recliner Finish Cover Screw	2 N·m	18 lb in
Front Seat Outer Adjuster Finish Cover Screw	2 N·m	18 lb in
Rear Seat Armrest Nut	10 N·m	89 lb in
Rear Seat Assembly Bolt	40 N·m	30 lb ft
Rear Seat Back Cushion Frame Bolt	45 N·m	33 lb ft
Rear Seat Belt Buckle Bolt	45 N·m	33 lb ft
Rear Seat Cushion Frame Bolt - Rear	45 N·m	33 lb ft
Rear Seat Cushion Frame Bolt - Front	28 N·m	21 lb ft
Rear Seat Cushion Frame Bolt - Upper	10 N·m	89 lb in
Rear Seat Inner Latch Bolt	28 N·m	21 lb ft
Rear Seat Inner Recliner Finish Cover Screw	2 N·m	18 lb in
Rear Seat Latch Release Strap Bezel Bolt	5 N·m	44 lb in
Rear Seat Outer Latch Bolt	28 N·m	21 lb ft
Rear Seat Recliner Outer Finish Cover Screw	2 N·m	18 lb in




Front Seat Replacement - Bucket



Callout	Component Name
1	<p>Front Seat Assembly Bolt (Qty: 2)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 45 N·m (33 lb ft)</p>
2	<p>Front Seat Assembly</p> <p>Procedure</p> <ol style="list-style-type: none">1. Disable the SIR. Refer to SIR Disabling and Enabling.2. Lift the seat upward at the rear of the seat.3. Disconnect the electrical connectors.4. Slide the seat rearward to disengage the adjuster hooks holding the seat to the floor pan.




Front Seat Adjuster Replacement



Callout	Component Name
Preliminary Procedures 1. Remove the front seat back cushion cover and pad. Refer to Front Seat Back Cushion Cover and Cushion Pad Replacement . 2. Remove the front seat cushion cover and pad. Refer to Front Seat Cushion Cover and Pad Replacement .	
1	Front Seat Back Frame Bolt (Qty: 4) Caution: Refer to Fastener Caution in the Preface section. Tighten 50 N·m (37 lb ft)
2	Front Seat Adjuster Procedure If replacing the front seat adjuster components as necessary.




Driver or Passenger Seat Adjuster Handle Replacement



Callout	Component Name
1	Front Seat Adjuster Handle Tip Pull forward to remove.




Front Seat Adjuster Track Finish Cover Replacement



Callout	Component Name
1	Front Seat Adjuster Track Finish Cover Retainer (Qty: 2) Tip Use a trim tool or equivalent to aid in the removal of the retainers.
2	Front Seat Adjuster Track Finish Cover




Driver or Passenger Seat Head Restraint Replacement



Callout	Component Name
1	<div>Front Seat Head Restraint</div> <div>Procedure</div> <div><div><div>1.</div><div>Depress the button on the left head restraint guide to raise the head restraint to the full up position.</div></div><div><div>2.</div><div>Insert a small diameter tool into the hole on the right side of the right head restraint guide and pull upward to remove.</div></div></div>




Front Seat Head Restraint Guide Replacement



Callout	Component Name
Preliminary Procedure	
Remove the front seat back panel. Refer to Driver or Passenger Seat Back Cushion Finish Panel Replacement .	
1	<p>Front Seat Head Restraint</p> <p>Procedure</p> <ol style="list-style-type: none">1. Depress the button on the left head restraint guide to raise the head restraint to the full up position.2. Insert a small diameter tool into the hole on the right side of the right head restraint guide and pull upward to remove.
2	<p>Front Seat Head Restraint Guide (Qty: 2)</p> <p>Procedure</p> <ol style="list-style-type: none">1. Release the j-channel and reposition the seat back cushion cover to gain access to the release tabs on the guide.2. Squeeze the head restraint guides in the location shown and pull upward to


Driver or Passenger Seat Inner Adjuster Finish Cover Replacement



Callout	Component Name
Preliminary Procedure	
Remove the front seat. Refer to Front Seat Replacement - Bucket .	
1	<div>Front Seat Inner Adjuster Finish Cover Screw</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 2 N·m (18 lb in)</div>
2	<div>Front Seat Inner Adjuster Finish Cover</div> <div>Procedure<ol style="list-style-type: none">Release the rear of the adjuster cover first.Pull outward from the bottom of the adjuster cover and push upward to release the cover from the seat cushion frame.</div>




Driver or Passenger Seat Outer Adjuster Finish Cover Replacement (without Power Seat)



Callout	Component Name
Preliminary Procedures	
<ol style="list-style-type: none">1. Remove the seat adjuster handle. Refer to Driver or Passenger Seat Adjuster Handle Replacement.2. Remove the front seat recliner handle. Refer to Driver or Passenger Seat Recliner Handle Replacement.	
1	<div>Front Seat Outer Adjuster Finish Cover Screw</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 2 N·m (18 lb in)</div>
2	<div>Front Seat Outer Adjuster Finish Cover</div> <div>Procedure</div> <div><ol style="list-style-type: none">1. Release the rear of the adjuster cover first.</div>

--	--


Driver or Passenger Seat Outer Adjuster Finish Cover Replacement (with Power Seat)



Callout	Component Name
1	<div>Front Seat Outer Adjuster Finish Cover Screw</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 2 N·m (18 lb in)</div>
2	<div>Front Seat Outer Adjuster Finish Cover</div> <div>Procedure <div>1. Release the rear of the adjuster cover first. 2. Pull outward from the bottom of the adjuster cover and push upward to release the cover from the seat cushion frame. 3. Disconnect the power seat switch electrical connector.</div></div>




Driver or Passenger Seat Inner Recliner Finish Cover Replacement



Callout	Component Name
Preliminary Procedures 1. Remove the front seat back cushion cover and pad. Refer to Front Seat Back Cushion Cover and Cushion Pad Replacement . 2. Remove the front seat cushion cover and pad. Refer to Front Seat Cushion Cover and Pad Replacement .	
1	Front Seat Inner Recliner Finish Cover Screw Caution: Refer to Fastener Caution in the Preface section. Tighten 2 N·m (18 lb in)
2	Front Seat Inner Recliner Finish Cover




Front Seat Cushion Cover and Pad Replacement (without KA1)



Callout	Component Name
<div data-bbox="147 1073 1406 1129">Preliminary Procedures</div> <div data-bbox="180 1166 1365 1323"><ol style="list-style-type: none">1. Remove the front seat. Refer to Front Seat Replacement - Bucket .2. Remove the front seat outer adjuster finish cover. Refer to Driver or Passenger Seat Outer Adjuster Finish Cover Replacement .3. Remove the front seat inner adjuster finish cover. Refer to Driver or Passenger Seat Inner Adjuster Finish Cover Replacement .</div>	
1	<div data-bbox="282 1332 1406 1387">Front Seat Cushion Cover</div> <div data-bbox="282 1387 1406 1742">Procedure<ol style="list-style-type: none">1. Disengage the j-channel retainers from the seat back cushion frame.2. Disconnect the electrical connectors that attach to the seat back cushion, if equipped.3. Remove the seat belt buckle pretensioner electrical wire from the seat cushion and cover.4. Remove the seat cushion cover and pad as an assembly.5. Pull the cover away from the pad to disengage the retainers.</div>

Front Seat Cushion Cover and Pad Replacement (with KA1)




Callout	Component Name
<div data-bbox="147 1073 1408 1129">Preliminary Procedures</div> <div data-bbox="180 1166 1365 1323"><ol style="list-style-type: none">1. Remove the front seat. Refer to Front Seat Replacement - Bucket .2. Remove the front seat outer adjuster finish cover. Refer to Driver or Passenger Seat Outer Adjuster Finish Cover Replacement .3. Remove the front seat inner adjuster finish cover. Refer to Driver or Passenger Seat Inner Adjuster Finish Cover Replacement .</div>	
1	<div data-bbox="284 1332 1408 1387">Front Seat Cushion Cover</div> <div data-bbox="284 1387 1408 1748"><div data-bbox="284 1387 1408 1443">Procedure</div><div data-bbox="316 1480 1365 1720"><ol style="list-style-type: none">1. Disengage the j-channel retainers from the seat back cushion frame.2. Disconnect the electrical connectors that attach to the seat back cushion, if equipped.3. Remove the seat belt buckle pretensioner electrical wire from the seat cushion and cover.4. Remove the seat cushion cover and pad as an assembly.5. Pull the cover away from the pad to disengage the retainers.</div></div>

3

Front Seat Cushion Pad


Driver or Passenger Seat Back Cushion Cover and Pad Replacement (without KA1)



Callout	Component Name
<h2>Preliminary Procedures</h2> <ol style="list-style-type: none">1. Remove the front seat. Refer to Front Seat Replacement - Bucket .2. Remove the front seat back panel. Refer to Driver or Passenger Seat Back Cushion Finish Panel Replacement .3. Remove the front seat head restraint. Refer to Front Seat Head Restraint Replacement .4. Remove the front seat head restraint guides. Refer to Front Seat Head Restraint Guide Replacement .5. Remove the front seat lumbar support actuator knob and bezel, if equipped. Refer to Driver Seat Lumbar Support Actuator Knob Bezel Replacement .6. Remove the front seat outer adjuster finish cover. Refer to Driver or Passenger Seat Outer Adjuster Finish Cover Replacement .7. Remove the front seat inner adjuster finish cover. Refer to Driver or Passenger Seat Inner Adjuster Finish Cover Replacement .	
	Front Seat Back Cushion Cover
Procedure	

1	<p>equipped.</p> <ol style="list-style-type: none">3. Remove the inflatable restraint module hog rings from the seat cover, use new hog rings when installing.4. Remove the seat back cushion cover and pad as an assembly.5. Pull the cover away from the pad to disengage the retainers.
2	Front Seat Back Cushion Pad


Driver or Passenger Seat Back Cushion Cover and Pad Replacement (with KA1)



Callout	Component Name
<h2>Preliminary Procedures</h2> <ol style="list-style-type: none">1. Remove the front seat. Refer to Front Seat Replacement - Bucket .2. Remove the front seat back panel. Refer to Driver or Passenger Seat Back Cushion Finish Panel Replacement .3. Remove the front seat head restraint. Refer to Front Seat Head Restraint Replacement .4. Remove the front seat head restraint guides. Refer to Front Seat Head Restraint Guide Replacement .5. Remove the front seat lumbar support actuator knob and bezel, if equipped. Refer to Driver Seat Lumbar Support Actuator Knob Bezel Replacement .6. Remove the front seat outer adjuster finish cover. Refer to Driver or Passenger Seat Outer Adjuster Finish Cover Replacement .7. Remove the front seat inner adjuster finish cover. Refer to Driver or Passenger Seat Inner Adjuster Finish Cover Replacement .	
	Front Seat Back Cushion Cover
Procedure	


1	<div>equipped.</div> <div>3. Remove the inflatable restraint module hog rings from the seat cover, use new hog rings when installing.</div> <div>4. Remove the seat back cushion cover and pad as an assembly.</div> <div>5. Pull the cover away from the pad to disengage the retainers.</div>
2	Front Seat Back Cushion Heater
3	Front Seat Back Cushion Pad

Driver or Passenger Seat Back Cushion Frame Replacement (with Power Seat)




Callout	Component Name
Preliminary Procedures 1. Remove the front seat back cushion cover and pad. Refer to Front Seat Back Cushion Cover and Cushion Pad Replacement . 2. Remove the front seat cushion cover and pad. Refer to Front Seat Cushion Cover and Pad Replacement .	
1	Front Seat Back Frame Bolt (Qty: 4) Caution: Refer to Fastener Caution in the Preface section. Tighten 50 N·m (37 lb ft)
2	Front Seat Back Frame Procedure 1. Disconnect the electrical connector.


Driver or Passenger Seat Back Cushion Frame Replacement (without Power Seat)



Callout	Component Name
Preliminary Procedures 1. Remove the front seat back cushion cover and pad. Refer to Front Seat Back Cushion Cover and Cushion Pad Replacement . 2. Remove the front seat cushion cover and pad. Refer to Front Seat Cushion Cover and Pad Replacement .	
1	Front Seat Back Frame Bolt (Qty: 4) Caution: Refer to Fastener Caution in the Preface section. Tighten 50 N·m (37 lb ft)
2	Front Seat Back Frame Procedure If replacing the seat back frame transfer components as necessary.




Passenger Seat Recliner Upper Finish Cover Replacement



Callout	Component Name
	Passenger Seat Recliner Upper Finish Cover
1	Procedure 1. Use a door pad trim removal tool or equivalent to aid in the removal of the cover. 2. Release the lower retainers and slide upward to release the cover from the seat.




Driver or Passenger Seat Recliner Handle Replacement



Callout	Component Name
1	Front Seat Recliner Handle Tip Pull forward and up to remove.




Driver or Passenger Seat Back Cushion Finish Panel Replacement



Callout	Component Name
1	Front Seat Recliner Handle
Procedure 1. Pull rearward at the bottom of the seat to release the push in retainers. 2. Use a flat bladed tool to push inward on the sides of the seat back panel to release the upper portion of the panel from the seat back frame.	




Front Seat Lumbar Support Replacement



Callout	Component Name
<h2>Preliminary Procedures</h2> <p>Remove the front seat back cushion cover and pad. Refer to Front Seat Back Cushion Cover and Cushion Pad Replacement.</p>	
1	<p>Driver Seat Lumbar Support Actuator Screw (Qty: 2)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 5 N·m (44 lb in)</p>
2	<p>Driver Seat Lumbar Support Assembly</p> <p>Tip Compress the lumbar support upper tabs and pull the lumbar assembly forward from the seat to remove from the seat back frame.</p>




Driver Seat Lumbar Support Actuator Knob Replacement



Callout	Component Name
1	<div>Driver Seat Lumbar Support Actuator Knob</div> <div>Tip Pull outward to release from the seat.</div>




Driver Seat Lumbar Support Actuator Knob Bezel Replacement



Callout	Component Name
1	Driver Seat Lumbar Support Actuator Knob Tip Pull outward to disengage the knob from the actuator.
2	Driver Seat Lumbar Support Actuator Knob Bezel Tip Use a small flat bladed tool and push in on the tabs behind the bezel to release the bezel from the actuator.



Child Seat Bracket Trim Cover Replacement




Callout	Component Name
1	<div>Child Seat Bracket Trim Cover</div> <div>Tip Use a flat bladed tool and pry the tabs inward at the four locations shown to release the cover from the seat back.</div>




Rear Seat Replacement

Removal Procedure




1. Remove the rear seat riser finish covers.
2. Remove the rear seat bolts (1).
3. Open the rear compartment floor stowage compartment cover and remove the foam insulator over the spare tire to gain access to the rear seat latches.




4. Unlatch the rear seat (2) by pushing forward on the seat latch buttons located on the inboard


Installation Procedure




1. Install the rear seat (2) to the vehicle, locating the front seat riser pins into the floor.
2. Secure the rear of the seat by pushing down on the back of the seat ensuring that the seat latch (1) is securely latched.
3. Install the foam insulator over the spare tire and close the rear compartment floor stowage compartment cover.

Caution: Refer to [Fastener Caution](#) in the Preface section.



- 
4. Install the 2 seat attachments bolts (1) to the front of the seat risers and tighten the bolts to **40 N·m (30 lb ft)**.

Rear Seat Armrest Replacement




Callout	Component Name
<h2>Preliminary Procedures</h2> <ol style="list-style-type: none">1. Remove the rear seat. Refer to Rear Seat Replacement.2. Remove the rear seat recliner covers. Refer to Rear Seat Recliner Outer Finish Cover Replacement - Inboard and Rear Seat Recliner Outer Finish Cover Replacement - Outboard.3. Remove the rear seat head restraint. Refer to Rear Seat Head Restraint Replacement.4. Remove the rear child seat bracket trim cover. Refer to Child Seat Bracket Trim Cover Replacement.5. Remove the rear seat latch release strap bezel. Refer to Rear Seat Latch Release Strap Bezel Replacement.6. Remove the rear seat back panel. Refer to Rear Seat Back Cushion Panel Replacement.	
1	<p>Rear Seat Armrest Nut (Qty: 2)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tighten 10 N·m (89 lb in)</p>
	<p>Rear Seat Armrest</p>

2

Rear seat back armrest close out comes out when the armrest is removed..


Rear Seat Head Restraint Replacement



Callout	Component Name
1	<div>Rear Seat Head Restraint</div> <div>Procedure<ol style="list-style-type: none">Depress the button on the left head restraint guide to raise the head restraint to the full up position.Insert a small diameter tool into the hole on the right side of the right head restraint guide and pull upward to remove.</div>



Rear Seat Head Restraint Guide Replacement




Callout	Component Name
Preliminary Procedures <ol style="list-style-type: none">1. Remove the rear seat. Refer to Rear Seat Replacement.2. Remove the rear seat recliner covers. Refer to Rear Seat Recliner Outer Finish Cover Replacement - Inboard and Rear Seat Recliner Outer Finish Cover Replacement - Outboard.3. Remove the rear child seat bracket trim cover. Refer to Child Seat Bracket Trim Cover Replacement.4. Remove the rear seat latch release strap bezel. Refer to Rear Seat Latch Release Strap Bezel Replacement.5. Remove the rear seat back panel. Refer to Rear Seat Back Cushion Panel Replacement.	
1	<p>Rear Seat Head Restraint</p> <p>Procedure</p> <ol style="list-style-type: none">1. Depress the button on the left head restraint guide to raise the head restraint to the full up position.2. Insert a small diameter tool into the hole on the right side of the right head restraint guide and pull upward to remove.

Procedure

Squeeze the bottom of the head restraint guide together and push up to remove.


Rear Seat Recliner Outer Finish Cover Replacement - Inboard (with 40 Percent Seat)



Callout	Component Name
1	<p>Rear Seat Recliner Outer Finish Cover Screw (Qty: 4)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tip Release the rear seat latches to fold the seat up by pressing forward on the latch button located on the inboard side of each of the lower latches.</p> <p>Tighten 2 N·m (18 lb in)</p>
2	Rear Seat Recliner Outer Finish Cover - Inboard




Rear Seat Recliner Outer Finish Cover Replacement - Inboard (with 60 Percent Seat)



Callout	Component Name
1	<p>Rear Seat Recliner Outer Finish Cover Screw (Qty: 4)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tip Release the rear seat latches to fold the seat up by pressing forward on the latch button located on the inboard side of each of the lower latches.</p> <p>Tighten 2 N·m (18 lb in)</p>
2	Rear Seat Recliner Outer Finish Cover - Inboard




Rear Seat Recliner Outer Finish Cover Replacement - Outboard (with 60 Percent Seat)



Callout	Component Name
1	<p>Rear Seat Recliner Outer Finish Cover Screw (Qty: 4)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tip Release the rear seat latches to fold the seat up by pressing forward on the latch button located on the inboard side of each of the lower latches.</p> <p>Tighten 2 N·m (18 lb in)</p>
2	Rear Seat Recliner Outer Finish Cover - Outboard


Rear Seat Recliner Outer Finish Cover Replacement - Outboard (with 40 Percent Seat)



Callout	Component Name
1	<p>Rear Seat Recliner Outer Finish Cover Screw (Qty: 4)</p> <p>Caution: Refer to Fastener Caution in the Preface section.</p> <p>Tip Release the rear seat latches to fold the seat up by pressing forward on the latch button located on the inboard side of each of the lower latches.</p> <p>Tighten 2 N·m (18 lb in)</p>
2	Rear Seat Recliner Outer Finish Cover - Outboard




Rear Seat Cushion Cover and Pad Replacement (with 60 Percent Seat)



Callout	Component Name
Preliminary Procedures	
<div>1. Remove the rear seat. Refer to Rear Seat Replacement.</div> <div>2. Remove the rear seat recliner covers. Refer to Rear Seat Recliner Outer Finish Cover Replacement - Inboard and Rear Seat Recliner Outer Finish Cover Replacement - Outboard.</div> <div>3. Remove the rear seat belt buckle. Refer to Rear Seat Belt Buckle Replacement or Rear Seat Center Belt Buckle Replacement.</div>	
1	Rear Seat Pivot Pin Clip (Qty: 2)
2	Rear Seat Pivot Pin (Qty: 2)
3	<div>Rear Seat Cushion Cover</div> <div>Procedure</div> <div><div>1. Lift the rear seat cushion frame up away from the seat riser far enough to slide the seat cushion cover away from the frame.</div><div>2. Disconnect the rear seat cushion cover j-channels and straps from the rear</div></div>

4	Rear Seat Cushion Pad


Rear Seat Cushion Frame Replacement (with 40 Percent Seat)



Callout	Component Name
Preliminary Procedures	
<div>1. Remove the rear seat. Refer to Rear Seat Replacement.</div> <div>2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement.</div> <div>3. Remove the rear seat cushion cover and pad. Refer to Rear Seat Cushion Cover and Pad Replacement.</div>	
1	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 10 N·m (89 lb in)</div>
2	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>Tighten 45 N·m (33 lb ft)</div>
	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div>


4	Rear Seat Belt Buckle Bolt Tighten 45 N·m (33 lb ft)
5	Rear Seat Belt Buckle
6	Rear Seat Back Cushion Frame

Rear Seat Cushion Frame Replacement (with 60 Percent Seat)



Callout	Component Name
Preliminary Procedures	
<div>1. Remove the rear seat. Refer to Rear Seat Replacement.</div> <div>2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement.</div> <div>3. Remove the rear seat cushion cover and pad. Refer to Rear Seat Cushion Cover and Pad Replacement.</div>	
1	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 45 N·m (33 lb ft)</div>
2	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>Tighten 28 N·m (21 lb ft)</div>
3	Rear Seat Cu <div></div>


Rear Seat Latch Release Strap Bezel Replacement



Callout	Component Name
1	Rear Seat Latch Release Strap Bezel Bolt Cover Tip Use a small flat-bladed tool to aid in the removal of the bolt cover.
2	Rear Seat Latch Release Strap Bezel Bolt Caution: Refer to Fastener Caution in the Preface section. Tighten 5 N·m (44 lb in)
3	Rear Seat Latch Release Strap Bezel




Rear Seat Latch Replacement (Outer with 60 Percent Seat)



Callout	Component Name
1	<div>Rear Seat Latch - Outer Bolt</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tip Release the rear seat latches to fold the seat up by pressing forward on the latch button located on the inboard side of each of the lower latches.</div> <div>Tighten 25 N·m (18 lb ft)</div>
2	<div>Rear Seat Latch - Outer Bolt (Qty: 2)</div> <div>Tighten 25 N·m (18 lb ft)</div>
3	Rear Seat Latch - Outer




Rear Seat Latch Replacement (Inner with 60 Percent Seat)



Callout	Component Name
1	<div>Rear Seat Latch - Inner Bolt (Qty: 2)</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tip Release the rear seat latches to fold the seat up by pressing forward on the latch button located on the inboard side of each of the lower latches.</div> <div>Tighten 25 N·m (18 lb ft)</div>
2	<div>Rear Seat Latch - Inner Bolt (Qty: 2)</div> <div>Tighten 25 N·m (18 lb ft)</div>
3	Rear Seat Latch - Inner




Rear Seat Shoulder Belt Opening Bezel Replacement (with 60 Percent Seat)



Callout	Component Name
1	<div>Rear Seat Shoulder Belt Opening Bezel</div> <div>Tip<ul style="list-style-type: none">• Push inward and upward from the front of the bezel to release from the seat back.• The rear seat shoulder belt opening bezel is part of the rear seat center belt assembly and is replaced as an assembly.</div>




Rear Seat Back Cushion Panel Replacement (with 60 Percent Seat)



Callout	Component Name
<div data-bbox="147 1073 1411 1136">Preliminary Procedures</div> <div data-bbox="183 1169 1411 1530"><ol style="list-style-type: none">1. Remove the rear seat. Refer to Rear Seat Replacement .2. Remove the rear seat recliner covers. Refer to Rear Seat Recliner Outer Finish Cover Replacement - Inboard and Rear Seat Recliner Outer Finish Cover Replacement - Outboard .3. Remove the rear seat head restraint. Refer to Rear Seat Head Restraint Replacement .4. Remove the seat belt opening cover, if equipped. Refer to Rear Seat Shoulder Belt Opening Bezel Replacement .5. Remove the rear child seat bracket trim cover. Refer to Child Seat Bracket Trim Cover Replacement .6. Remove the rear seat latch release strap bezel. Refer to Rear Seat Latch Release Strap Bezel Replacement .</div>	
1	<div data-bbox="289 1530 1411 1617">Rear Seat Back Cushion Panel</div> <div data-bbox="289 1617 1411 1672">Procedure</div> <div data-bbox="321 1709 1352 1748"><ol style="list-style-type: none">1. Disconnect the j-channel retainer on the bottom and reposition the cover</div>

	<ol style="list-style-type: none">3. Pull rearward on the back panel to remove.4. Position the clips to the back panel and clip onto the back frame wires for installation.
--	--


Rear Seat Back Cushion Cover and Pad Replacement (with 60 Percent Seat)



Callout	Component Name
<h2>Preliminary Procedures</h2> <ol style="list-style-type: none">1. Remove the rear seat. Refer to Rear Seat Replacement.2. Remove the rear seat recliner covers. Refer to Rear Seat Recliner Outer Finish Cover Replacement - Inboard and Rear Seat Recliner Outer Finish Cover Replacement - Outboard.3. Remove the rear seat head restraint. Refer to Rear Seat Head Restraint Replacement.4. Remove the seat belt opening cover, if equipped. Refer to Rear Seat Shoulder Belt Opening Bezel Replacement.5. Remove the rear child seat bracket trim cover. Refer to Child Seat Bracket Trim Cover Replacement.6. Remove the rear seat latch release strap bezel. Refer to Rear Seat Latch Release Strap Bezel Replacement.7. Remove the rear seat back panel. Refer to Rear Seat Back Cushion Panel Replacement.8. Remove the rear seat head restraint guides. Refer to Rear Seat Head Restraint Guide Replacement.9. Remove the rear seat center belt anchor bolt.10. Remove the rear seat armrest. Refer to Rear Seat Armrest Replacement.	
	Rear Seat Back Cushion Cover

1	<ol style="list-style-type: none">1. Disconnect the rear seat back cushion cover j-channel.2. Disconnect the straps from the rear seat back cushion cover to the bottom of the seat cushion.3. Remove the rear seat back cushion cover from the rear seat back cushion pad.
2	Rear Seat Back Cushion Pad


Rear Seat Back Cushion Frame Replacement (with 40 Percent Seat)



Callout	Component Name
Preliminary Procedures	
<div>1. Remove the rear seat. Refer to Rear Seat Replacement.</div> <div>2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement.</div> <div>3. Remove the rear seat cushion cover and pad. Refer to Rear Seat Cushion Cover and Pad Replacement.</div>	
1	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 10 N·m (89 lb in)</div>
2	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>Tighten 45 N·m (33 lb ft)</div>
	<div>Rear Seat Cushion Frame Bolt (Qty: 2)</div> <div>© 2010 General Motors Corporation. All rights reserved.</div>


4	Rear Seat Belt Buckle Bolt Tighten 28 N·m (21 lb ft)
5	Rear Seat Recliner Bolt Tighten 28 N·m (21 lb ft)
6	Rear Seat Recliner Assembly
7	Rear Seat Back Cushion Frame Assembly

Rear Seat Back Cushion Frame Replacement (with 60 Percent Seat)



Callout	Component Name
<h2>Preliminary Procedures</h2> <ol style="list-style-type: none">1. Remove the rear seat. Refer to Rear Seat Replacement.2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement.3. Remove the rear seat back latch release handle assembly. Refer to Rear Seat Back Cushion Latch Release Handle Replacement.	
1	<div>Rear Seat Back Cushion Frame Bolt (Qty: 2)</div> <div>Caution: Refer to Fastener Caution in the Preface section.</div> <div>Tighten 45 N·m (33 lb ft)</div>
2	<div>Rear Seat Back Cushion Frame Bolt (Qty: 2)</div> <div>Tighten 45 N·m (33 lb ft)</div>
3	<div>Rear Seat Back Latch Release Handle Assembly</div>


Rear Seat Back Cushion Latch Release Handle Replacement (with 60 Percent Seat)



Callout	Component Name
<div data-bbox="147 1073 1408 1129">Preliminary Procedures</div> <div data-bbox="180 1166 1393 1326"><ol style="list-style-type: none">1. Remove the rear seat. Refer to Rear Seat Replacement.2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement.3. Remove the rear seat inner recliner covers. Refer to Rear Seat Recliner Inner Finish Cover Replacement.</div>	
1	<div data-bbox="289 1332 1408 1387">Rear Seat Back Cushion Latch Release Handle Assembly</div> <div data-bbox="289 1387 1408 1568">Procedure<ol style="list-style-type: none">1. Disconnect the seat back latch cables from the recliners.2. Slide the handle assembly forward to remove from the seat back frame.</div>




Rear Seat Back Cushion Latch Release Handle Replacement (with 40 Percent Seat)



Callout	Component Name
Preliminary Procedures 1. Remove the rear seat. Refer to Rear Seat Replacement . 2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement . 3. Remove the rear seat inner recliner covers. Refer to Rear Seat Recliner Inner Finish Cover Replacement .	
1	<div>Rear Seat Back Cushion Latch Release Handle Assembly</div> Procedure 1. Disconnect the seat back latch cables from the recliners. 2. Slide the handle assembly forward to remove from the seat back frame.




Rear Seat Recliner Inner Finish Cover Replacement



Callout	Component Name
Preliminary Procedures 1. Remove the rear seat. Refer to Rear Seat Replacement . 2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement .	
1	Rear Seat Inner Recliner Finish Cover Screw Caution: Refer to Fastener Caution in the Preface section. Tighten 2 N·m (18 lb in)
2	Rear Seat Inner Recliner Finish Cover




Rear Seat Recliner Replacement (with 40 Percent Seat)



Callout	Component Name
Preliminary Procedures 1. Remove the rear seat. Refer to Rear Seat Replacement . 2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement . 3. Remove the rear seat cushion cover and pad. Refer to Rear Seat Cushion Cover and Pad Replacement .	
1	Rear Seat Cushion Frame Bolt (Qty: 2) Caution: Refer to Fastener Caution in the Preface section. Tighten 10 N·m (89 lb in)
2	Rear Seat Cushion Frame Bolt (Qty: 2) Tighten 45 N·m (33 lb ft)
3	Rear Seat Cushion Frame Bolt (Qty: 2)

4	Rear Seat Cushion Frame Bolt (Qty: 2) Tighten 28 N·m (21 lb ft)
5	Rear Seat Belt Buckle Bolt Tighten 45 N·m (33 lb ft)
6	Rear Seat Belt Buckle
7	Rear Seat Recliner Assembly

Rear Seat Recliner Replacement (with 60 Percent Seat)



Callout	Component Name
Preliminary Procedures 1. Remove the rear seat. Refer to Rear Seat Replacement . 2. Remove the rear seat back cover and pad. Refer to Rear Seat Back Cushion Cover and Pad Replacement . 3. Remove the rear seat cushion cover and pad. Refer to Rear Seat Cushion Cover and Pad Replacement .	
1	Rear Seat Back Cushion Frame Bolt (Qty: 4) Caution: Refer to Fastener Caution in the Preface section. Tighten 45 N·m (33 lb ft)
2	Rear Seat Cushion Frame Bolt (Qty: 2) Tighten 45 N·m (33 lb ft)
3	Rear Seat Cushion Frame Bolt (Qty: 2)

4	<div>Rear Seat Recliner Assembly (Qty: 2)</div> <div>Procedure</div> <div>Disconnect the rear seat back latch release handle cables from the recliner assemblies.</div>