

# **MITSUBISHI COLT/LANCER**

## **WORKSHOP MANUAL SUPPLEMENT**

General .....	<b>00</b>
Fuel .....	<b>13</b>
Automatic Transmission .....	<b>23</b>

### **FOREWORD**

This manual outlines changes in servicing procedures related to the chassis including vehicle inspections, adjustments, and improvements in the newly equipped models. Use the following manuals in combination with this manual as required.

TECHNICAL INFORMATION MANUAL	PYME9501
WORKSHOP MANUAL	
ENGINE GROUP	PWEE□□□□ (Looseleaf edition)
CHASSIS GROUP	PWME9511 (Basic) PWME9511-A (Supplement)
BODY REPAIR MANUAL	PBME9501
ELECTRICAL WIRING	PHME9511 (Basic) PHME9511-A (Supplement) PHME9511-B (Supplement)
PARTS CATALOGUE	B606F008A□

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.