

2008 MITSUBISHI LANCER BODY REPAIR MANUAL

FOREWORD

This manual has been prepared for the use of all service mechanics engaged in the body repair service. Body dimensions, welded panel replacement procedures, body sealing application instructions, and all the other information required to provide quick and accurate body repair service are contained herein. One especially important point is the welding method. All of the vehicle's original strength and durability can be maintained by following the welding procedures contained in this manual.

Now that, in order to maximize the efficiency of the repair work, first, both the extent of the damage and the replacement parts that are needed must be calculated accurately, and then the actual work must be performed accurately and efficiently.

The publications shown on the following page are also available, and should be used in conjunction with this manual.

GROUP INDEX

BODY CONSTRUCTION	1
BODY DIMENSIONS	2
WELDED PANEL REPLACEMENT..	3
CORROSION PROTECTION	4
SYNTHETIC-RESIN PARTS	5
BODY COLOR	6
BASE OF BODY REPAIR	9



Mitsubishi Motors Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

©2007 Mitsubishi Motors Corporation
All Rights Reserved
Printed in USA
MSSP-406B-2008

