

35B ANTI-SKID BRAKING SYSTEM (ABS) <2WD>

CONTENTS

GENERAL INFORMATION

SERVICE SPECIFICATIONS

SPECIAL TOOLS

TROUBLESHOOTING

STANDARD FLOW OF DIAGNOSTIC
TROUBLESHOOTING

NOTES WITH REGARD TO DIAGNOSIS

ABS WARNING LAMP INSPECTION

DIAGNOSIS FUNCTION

INSPECTION CHART FOR DIAGNOSIS CODES

INSPECTION PROCEDURE FOR DIAGNOSIS
CODES

INSPECTION CHART FOR TROUBLE
SYMPTOMS

INSPECTION PROCEDURE FOR TROUBLE
SYMPTOMS

DATA LIST REFERENCE TABLE

ACTUATOR TEST REFERENCE TABLE

CHECK AT ABS-ECU

ON-VEHICLE SERVICE

WHEEL SPEED SENSOR OUTPUT VOLTAGE
CHECK

ABS WARNING LAMP RELAY CONTINUITY
CHECK

HYDRAULIC UNIT CHECK

REMEDY FOR A FLAT BATTERY

HYDRAULIC UNIT AND ABS-ECU

WHEEL SPEED SENSOR