
54C CIRCUIT DIAGRAMS 1999

CONTENTS

STARTING SYSTEM

IGNITION SYSTEM

4G15

4G93

CHARGING SYSTEM

4G15

4G93

MPI SYSTEM

4G15

4G93

ELC 4-SPEED AUTOMATIC TRANSMISSION

MPI <Vehicles for Australia and New Zealand
(without sport mode)>

MPI <Vehicles for Australia (with sport mode)>

ROOM LAMP AND LUGGAGE COMPARTMENT LAMP

Hatchback <Vehicles for Australia and New
Zealand>

Sedan

METER AND GAUGE

FUEL WARNING LAMP SEAT BELT WARNING LAMP

POWER WINDOWS

2-door sedan

IMMOBILIZER SYSTEM

Vehicles for Australia and New Zealand
