




STARTING SYSTEM
<Vehicles for Australia>




IGNITION SYSTEM

4G15




IGNITION SYSTEM

4G93



CHARGING SYSTEM
4G15



A-19X

1	2
3	4

A-20

1	2
---	---

A-82

1

A-83

1	2
---	---

B-02

31	32	33	34	35	36	37	38	39	40	41	42
											43
44	45	46	47	48	49	50	51	52	53	54	55

B-20

1	2	3	4	5	6	7	8	9		
10	11	12	13	14	15	16	17	18	19	20

B-62

1	2				3	4
5	6	7	8	9	10	11

B-69

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16


B-70

1	2	3	4
5	6	7	8

HC



CHARGING SYSTEM

4G93




4G15

MPI SYSTEM <4G15> (CONTINUED)





MPI SYSTEM <4G15> (CONTINUED)





(A-05)	(A-54)	(A-56)	(A-72)	(A-74)	(A-75)	(A-76)	(A-80)	(A-81)	(A-86)	(A-87)	(B-34)	(B-37)
1234	123	123456	12	12	12	12	12	12	12	12	71727374757677787980818283848586878889909192	1234567891011121314151617181920212223242526

MPI SYSTEM <4G15> (CONTINUED)






MPI SYSTEM
4G93





ELC 4-SPEED AUTOMATIC TRANSMISSION

<Vehicles for Australia>



ELC 4-SPEED AUTOMATIC TRANSMISSION <Vehicles for Australia>
(CONTINUED)



HC07L00CA



HC07L00CB



ROOM LAMP AND LUGGAGE COMPARTMENT LAMP

<Hatchback>




ROOM LAMP AND LUGGAGE COMPARTMENT LAMP

<Sedan>



METER AND GAUGE



A-71

1

2

3

4

5

6

7

8

B-02

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

B-03

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

B-32

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

B-33

1

2

3

4

5

6

7

8

9

10

11

12

13

B-47

1

2

3

4

5

6

7

8

9

10

11

12

13

14

B-49

1

2

3

4

5

6

7

8

9

10

11

12

13

14

B-50 <LHD>

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

<RHD>

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

B-62

1

2

3

4

5

6

7

8

9

10

11

B-64

1

2

3

4

5

6

7

8

9

10

11

12

13

14

B-69

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

B-70

1

2

3

4

5

6

7

8

B-74

1

2

3

4

5

6

7

8

9

10

11

12

13

C-01

1

2

D-04

1

2

3

4

5

6

7

8

9

10

D-10

1



2

3

HC10L00AA


HC10L00AA

FUEL WARNING LAMP / SEAT BELT WARNING LAMP



POWER WINDOWS

<2-door sedan>



IMMOBILIZER SYSTEM

