



# LANCER WAGON

## TECHNICAL INFORMATION MANUAL

### FOREWORD

This manual has been prepared as an introduction to the specifications, features, construction, functions, etc. of the newly developed LANCER WAGON. Please read this manual carefully so that it will be of assistance for your service activities. Please note the following service manuals are also available and should be used in conjunction with this manual.

#### WORKSHOP MANUAL

#### BODY REPAIR MANUAL

#### PARTS CATALOGUE

PWWE0405  
PWWE0405-1  
PBWE0401  
PBWE0401-1

BFA6K005A\_  
BFA6K006A\_

All information, illustrations and product descriptions contained in this manual are current as of the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

### MAIN INDEX

General .....	00
Engine.....	11
Fuel .....	13
Engine Cooling .....	14
Intake and Exhaust .....	15
Engine Electrical .....	16
Engine and Emission Control.....	17
Clutch .....	21
Manual Transmission .....	22
Automatic Transmission.....	23
Front Axle.....	26
Rear Axle .....	27
Wheel and Tyre .....	31
Power Plant Mount .....	32
Front Suspension .....	33
Rear Suspension .....	34
Service Brakes.....	35
Parking Brakes.....	36
Power Steering.....	37
Body .....	42
Exterior.....	51
Interior and Supplemental Restraint System (SRS) .....	52
Chassis Electrical .....	54
Heater, Air Conditioner and Ventilation .....	55