


EXHAUST PIPE AND MAIN MUFFLER

REMOVAL AND INSTALLATION

<AWD>

Main
Index15
Index15
AWD

05TJ024A

Caution

Support exhaust system during removal,
to prevent damage to flexible front pipe
section and personal injury.

Main muffler removal steps

1. Hanger
2. Main muffler assembly
3. Hanger bracket
4. Gasket
5. Rear floor heat protector panel

Centre exhaust pipe removal steps

6. Hanger
7. Centre exhaust pipe
8. Gasket
9. Hanger bracket

10. Harness protector
11. Catalytic converter or pre-muffler
12. Gasket

Front exhaust pipe removal steps

13. Oxygen sensor
14. Hanger
15. Front exhaust pipe
16. Gasket
17. Hanger bracket
18. Front floor heat protector