

16 ENGINE ELECTRICAL

CONTENTS

CHARGING SYSTEM

GENERAL INFORMATION

SERVICE SPECIFICATIONS

SPECIAL TOOL

ON-VEHICLE SERVICE

WAVE PATTERN CHECK USING AN
ANALYSER

ALTERNATOR RELAY CONTINUITY CHECK

ALTERNATOR

REMOVAL AND INSTALLATION

ALTERNATOR

DISASSEMBLY AND REASSEMBLY

DISASSEMBLY SERVICE POINTS

INSPECTION

STARTING SYSTEM

GENERAL INFORMATION

SERVICE SPECIFICATIONS

STARTER MOTOR

REMOVAL AND INSTALLATION

STARTER MOTOR

DISASSEMBLY AND REASSEMBLY

DISASSEMBLY SERVICE POINTS

STARTER MOTOR PART CLEANING

REASSEMBLY SERVICE POINT

INSPECTION

BRUSH AND SPRING REPLACEMENT

ARMATURE TEST

IGNITION SYSTEM

GENERAL INFORMATION

SERVICE SPECIFICATIONS

ON-VEHICLE SERVICE

SPARK PLUG CABLE TEST

SPARK PLUG TEST

IGNITION COIL CHECK

POWER TRANSISTOR CHECK

SPARK PLUG CABLE RESISTANCE CHECK

SPARK PLUG CHECK AND CLEANING

CAMSHAFT POSITION SENSOR CHECK

IGNITION SECONDARY VOLTAGE WAVE
PATTERN CHECK

IGNITION PRIMARY VOLTAGE WAVE
PATTERN CHECK

IGNITION SYSTEM

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINTS

DISTRIBUTOR

DISASSEMBLY AND REASSEMBLY

INSPECTION

CRANK ANGLE SENSOR

REMOVAL AND INSTALLATION

INSPECTION