

# 21 CLUTCH

## CONTENTS

### **GENERAL INFORMATION**

### **SERVICE SPECIFICATIONS**

### **LUBRICANTS**

### **ON-VEHICLE SERVICE**

CLUTCH PEDAL CHECK AND ADJUSTMENT

BLEEDING

### **CLUTCH PEDAL**

REMOVAL AND INSTALLATION

INSPECTION

### **CLUTCH DISC**

REMOVAL AND INSTALLATION

SERVICE POINTS OF REMOVAL

SERVICE POINT OF INSTALLATION

INSPECTION

### **CLUTCH CONTROL**

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINT

INSTALLATION SERVICE POINT

INSPECTION

### **CLUTCH MASTER CYLINDER**

DISASSEMBLY AND REASSEMBLY

INSPECTION

### **CLUTCH RELEASE CYLINDER**

DISASSEMBLY AND REASSEMBLY

REMOVAL SERVICE POINT

INSTALLATION SERVICE POINT

INSPECTION

---