

# 52A INTERIOR

## CONTENTS

### SPECIAL TOOLS

#### INSTRUMENT PANEL

- REMOVAL AND INSTALLATION
- REMOVAL SERVICE POINTS
- INSTALLATION SERVICE POINTS
- DISASSEMBLY AND REASSEMBLY

#### FLOOR CONSOLE

- REMOVAL AND INSTALLATION

#### TRIMS<SEDAN>

- REMOVAL AND INSTALLATION

#### TRIMS<SEDAN>

- REMOVAL AND INSTALLATION

#### TRIMS<WAGON>

- REMOVAL AND INSTALLATION

#### HEADLINING AND INSIDE REAR VIEW

##### MIRROR<SEDAN>

- REMOVAL AND INSTALLATION

#### HEADLINING AND INSIDE REAR VIEW

##### MIRROR<WAGON>

- REMOVAL AND INSTALLATION

- REMOVAL SERVICE POINTS

### FRONT SEAT

- REMOVAL AND INSTALLATION
- REMOVAL AND INSTALLATION
- DISASSEMBLY AND REASSEMBLY
- DISASSEMBLY SERVICE POINT
- INSPECTION

#### REAR SEAT<SEDAN>

- REMOVAL AND INSTALLATION

#### REAR SEAT<WAGON>

- REMOVAL AND INSTALLATION

#### FRONT SEAT BELT

- REMOVAL AND INSTALLATION
- INSPECTION

#### REAR SEAT BELT<SEDAN>

- REMOVAL AND INSTALLATION

#### REAR SEAT BELT<WAGON>

- REMOVAL AND INSTALLATION

#### REAR CENTRE SEAT BELT<WAGON>

- REMOVAL AND INSTALLATION
- REMOVAL SERVICE POINTS
- INSTALLATION SERVICE POINTS

### WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

#### WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).
- (2) If it is possible that the SRS components are subjected to heat over 93°C in baking or drying after painting, remove the SRS components (air bag module and SRS-ECU) beforehand.
- (3) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorised MITSUBISHI dealer.
- (4) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) and GROUP 00 – Maintenance Service before beginning any service or maintenance of any component of the SRS or any SRS-related component.

#### NOTE

Section titles with the asterisk (\*) in the table of contents in each group indicate operations requiring warnings.