

54C CIRCUIT DIAGRAMS

CONTENTS

JUNCTION BLOCK (J/B)

CENTRALISED JUNCTION

FUSIBLE LINK (Relay box in engine compartment)

DEDICATED FUSE (Relay box and fuse box)

MULTI-PURPOSE FUSE (In junction block)

CENTRALISED RELAY (Relay box in engine compartment)

POWER DISTRIBUTION SYSTEM

STARTING SYSTEM

IGNITION SYSTEM

CHARGING SYSTEM

MPI SYSTEM <Manual Transmission Vehicles>

MPI SYSTEM <Automatic Transmission Vehicles>

COOLING SYSTEM <MAGNA & SPORTS>

COOLING SYSTEM <VERADA>

ELC 4-SPEED AUTOMATIC TRANSMISSION

ELC 4-SPEED AUTOMATIC TRANSMISSION <VERADA>

ELC 5-SPEED AUTOMATIC TRANSMISSION <SPORTS>

HEADLAMP <MAGNA>

HEADLAMP <VERADA>

TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP <WAGON>

FOG LAMP <VERADA AND SPORTS>

ROOM LAMP, PERSONAL LAMP AND FOOT LAMP <SEDAN>

ROOM LAMP, PERSONAL LAMP AND FOOT LAMP <WAGON>

GLOVE COMPARTMENT LAMP AND TRUNK LAMP

DOOR LAMP AND FOOT LAMP

EC MIRROR

IGNITION KEY CYLINDER LAMP

STOP LAMP <SEDAN>

STOP LAMP <WAGON>

STOP LAMP <SPORTS>

TURN SIGNAL AND HAZARD LAMP <SEDAN>

TURN SIGNAL AND HAZARD LAMP <WAGON>

BACKUP LAMP <SEDAN>

BACKUP LAMP <WAGON>

HORN

METER <Standard Meter>

METER <High Contrast Meter>

CENTRE MESSAGE DISPLAY

OIL PRESSURE WARNING LAMP

FUEL WARNING LAMP

BRAKE WARNING LAMP

SEAT BELT WARNING LAMP

DOOR AJAR WARNING LAMP

POWER WINDOWS

CENTRAL DOOR LOCKING AND KEYLESS ENTRY <ALL MODELS EXCEPT VERADA Xi>

CENTRAL DOOR LOCKING AND KEYLESS
ENTRY <VERADA Xi ONLY>

TRUNK LID/FUEL TANK DOOR OPENER
<ALL MODELS EXCEPT VERADA Xi>

TRUNK LID/FUEL TANK DOOR OPENER
<VERADA Xi ONLY>

MANUAL AIR CONDITIONING

FULL AUTOMATIC AIR CONDITIONING

WINDSHIELD WIPER/WASHER <FRONT>

WINDSHIELD WIPER/WASHER <REAR>

DEFOGGER <MAGNA>

DEFOGGER <VERADA>

REMOTE CONTROL MIRROR

CLOCK <VERADA Xi ONLY>

CIGARETTE LIGHTER AND ASHTRAY LAMP

PHONE CONNECTION

AUDIO <4 SPEAKER SYSTEM>

AUDIO <6 & 8 SPEAKER SYSTEM>

ANTI-SKID BRAKING SYSTEM (ABS)
<Without Traction Control>

ANTI-SKID BRAKING SYSTEM (ABS) <With
Traction Control>

TRACTION CONTROL SYSTEM

CRUISE CONTROL

SUPPLEMENTAL RESTRAINT SYSTEM
(SRS)

THEFT ALARM

IMMOBILISATION

SUNROOF

POWER SEAT

LIGHT MONITOR/ALARM BUZZER

RHEOSTAT