

# 14 ENGINE COOLING

## CONTENTS

### GENERAL INFORMATION

CONSTRUCTION DIAGRAM

### SERVICE SPECIFICATIONS

### LUBRICANT

### SEALANT

### ON-VEHICLE SERVICE

ENGINE COOLANT LEAK CHECK

RADIATOR CAP VALVE OPENING PRESSURE  
CHECK

ENGINE COOLANT REPLACEMENT

CONCENTRATION MEASUREMENT

### THERMOSTAT

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINT

INSTALLATION SERVICE POINTS

INSPECTION

### WATER PUMP

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINT

### WATER HOSE AND WATER PIPE

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINT

INSTALLATION SERVICE POINTS

INSPECTION

### RADIATOR

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINT

INSPECTION