

33 FRONT SUSPENSION

CONTENTS

GENERAL INFORMATION

- COIL SPRINGS
- SHOCK ABSORBER
- CONSTRUCTION DIAGRAM

SERVICE SPECIFICATIONS

SPECIAL TOOLS

ON-VEHICLE SERVICE

- FRONT WHEEL ALIGNMENT CHECK AND
ADJUSTMENT

STRUT ASSEMBLY

- REMOVAL AND INSTALLATION
- REMOVAL SERVICE POINT
- INSPECTION

STRUT ASSEMBLY

- DISASSEMBLY AND REASSEMBLY
- DISASSEMBLY SERVICE POINTS
- REASSEMBLY SERVICE POINTS

LOWER ARM

- REMOVAL AND INSTALLATION
- REMOVAL SERVICE POINTS
- INSTALLATION SERVICE POINTS
- INSPECTION
- BALL JOINT DUST COVER REPLACEMENT

STABILISER BAR

- REMOVAL AND INSTALLATION
- INSTALLATION SERVICE POINT
- INSPECTION
- BALL JOINT DUST COVER REPLACEMENT
