

35A BRAKES

CONTENTS

GENERAL INFORMATION

CONSTRUCTION DIAGRAM

GENERAL SPECIFICATIONS

SERVICE SPECIFICATIONS

LUBRICANTS

SEALANT

SPECIAL TOOLS

ON-VEHICLE SERVICE

BRAKE PEDAL HEIGHT CHECK

STOP LIGHT SWITCH ADJUSTMENT

STOP LIGHT SWITCH CHECK

BRAKE BOOSTER OPERATING TEST

CHECK VALVE OPERATION CHECK

PROPORTIONING VALVE FUNCTION TEST

BRAKE FLUID LEVEL SENSOR CHECK

BLEEDING

FRONT DISC BRAKE PAD CHECK AND
REPLACEMENT

DISC BRAKE ROTOR CHECK

FRONT BRAKE DISC RUN-OUT CHECK

FRONT BRAKE DISC RUN-OUT CORRECTION

FRONT BRAKE DISC THICKNESS CHECK

REAR DISC BRAKE PAD CHECK AND
REPLACEMENT

REAR BRAKE DISC THICKNESS CHECK

REAR BRAKE DISC RUN-OUT CHECK

REAR BRAKE DISC RUN-OUT CORRECTION

BRAKE PEDAL

MASTER CYLINDER AND BRAKE BOOSTER

FRONT DISC BRAKE

REAR DISC BRAKE

PROPORTIONING VALVE <VEHICLES WITHOUT ABS>