

35B ANTI-LOCK BRAKING SYSTEM (ABS)

CONTENTS

GENERAL INFORMATION

CONSTRUCTION DIAGRAM <2WD>

CONSTRUCTION DIAGRAM <AWD>

SERVICE SPECIFICATIONS

SEALANT

SPECIAL TOOLS

TROUBLESHOOTING

DIAGNOSIS FUNCTION

ERASING DIAGNOSIS CODES

INSPECTION CHART FOR DIAGNOSIS CODES

ABS WARNING LIGHT INSPECTION

ACTUATOR TEST REFERENCE TABLE

CHECK AT THE ABS-ECU

ON-VEHICLE SERVICE

BLEEDING

ABS OPERATION CHECK

MASTER CYLINDER AND BRAKE BOOSTER

HYDRAULIC UNIT

INSTALLATION SERVICE POINT

WHEEL SPEED SENSOR <2WD>

WHEEL SPEED SENSOR <AWD>

G SENSOR <AWD>

INSPECTION

Refer to GROUP 35 for the following items.

BRAKE PEDAL

FRONT DISC BRAKE

LUBRICANTS

ON-VEHICLE SERVICE

Brake Booster Operating Test

Brake Fluid Level Sensor Check

Check Valve Operation Check

Front Brake Disc Run-out Check

Front Brake Disc Run-out Correction

Front Brake Disc Thickness Check

Front Disc Brake Pad Check and Replacement

Front Disc Brake Rotor Inspection

Proportioning Valve Function Test

Rear Brake Disc Run-out Check

Rear Brake Disc Run-out Correction

Rear Brake Disc Thickness Check

Rear Disc Brake Pad Check and Replacement

REAR DISC BRAKE