

# **MITSUBISHI** **TW/KW SERIES** **Magna / Verada** **Diamante** **WORKSHOP** **MANUAL**



## **SEDAN / WAGON** **FOREWORD**

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnostic, disassembly, repair and installation procedures along with complete specifications and tightening references. Please read this manual carefully before proceeding, as incorrect service procedures may result in injury or death to service personnel or to the operator's of the vehicle.

**COPYRIGHT 2004**  
**SERVICE DIVISION**  
**TONSLEY PARK**  
**SOUTH AUSTRALIA**



AUST. CO. No. 007 870 395

Mitsubishi Motors Australia Limited reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

© Mitsubishi Motors Australia Ltd. October 2004

## GROUP INDEX

<b>General</b> .....	<b>00</b>
<b>Engine</b> .....	<b>11A</b>
<b>Engine Overhaul</b> .....	<b>11B</b>
<b>Lubrication</b> .....	<b>12</b>
<b>Multipoint Fuel Injection</b> ....	<b>13A</b>
<b>Fuel Supply</b> .....	<b>13F</b>
<b>Traction Control System</b> ....	<b>13H</b>
<b>Engine Cooling</b> .....	<b>14</b>
<b>Intake and Exhaust</b> .....	<b>15</b>
<b>Engine Electrical</b> .....	<b>16</b>
<b>Engine and Emission Control</b>	<b>17</b>
<b>Clutch</b> .....	<b>21</b>
<b>Manual Transmission</b> .....	<b>22</b>
<b>Automatic Transmission</b> ....	<b>23</b>
<b>Propeller Shaft</b> .....	<b>25</b>
<b>Front Axle</b> .....	<b>26</b>
<b>Rear Axle</b> .....	<b>27</b>
<b>Wheel and Tyre</b> .....	<b>31</b>
<b>Power Plant Mount</b> .....	<b>32</b>
<b>Front Suspension</b> .....	<b>33</b>
<b>Rear Suspension</b> .....	<b>34</b>
<b>Service Brakes</b> .....	<b>35</b>
<b>Parking Brakes</b> .....	<b>36</b>
<b>Steering</b> .....	<b>37</b>
<b>Body</b> .....	<b>42</b>
<b>Exterior</b> .....	<b>51</b>
<b>Interior</b> .....	<b>52A</b>
<b>Supplemental Restraint System (SRS)</b> .....	<b>52B</b>
<b>Chassis Electrical</b> .....	<b>54</b>
<b>Heater, Air Conditioning and Ventilation</b> .....	<b>55</b>