

MITSUBISHI TL/KL SERIES Magna / Verada Diamante WORKSHOP MANUAL



SEDAN / WAGON FOREWORD

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnostic, disassembly, repair and installation procedures along with complete specifications and tightening references. Please read this manual carefully before proceeding, as incorrect service procedures may result in injury or death to service personnel or to the operator's of the vehicle.

**COPYRIGHT 2003
SERVICE DIVISION
TONSLEY PARK
SOUTH AUSTRALIA**



AUST. CO. No. 007 870 395

Mitsubishi Motors Australia Limited reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

© Mitsubishi Motors Australia Ltd. August 2003

GROUP INDEX

General	00
Engine	11A
Engine Overhaul	11B
Lubrication	12
Multipoint Fuel Injection	13A
Fuel Supply	13F
Traction Control System	13H
Engine Cooling	14
Intake and Exhaust	15
Engine Electrical	16
Engine and Emission Control	17
Clutch	21
Manual Transmission	22
Automatic Transmission	23
Propeller Shaft	25
Front Axle	26
Rear Axle	27
Wheel and Tyre	31
Power Plant Mount	32
Front Suspension	33
Rear Suspension	34
Service Brakes	35
Parking Brakes	36
Steering	37
Body	42
Exterior	51
Interior	52A
Supplemental Restraint System (SRS)	52B
Chassis Electrical	54
Heater, Air Conditioning and Ventilation	55