



# Owner's Handbook

## Quick Tips & Fun Facts

LANCER **FAMILY**



PLEASE PLACE COPIES OF THE FOLLOWING ITEMS IN THE POCKET BELOW:

1. Pre-Delivery Inspection Form (Customer Copy)
2. Triple Diamond Delivery Checklist (Customer Copy)
3. Sales Person or Key Dealership Contact's Business Card




Thank you for buying your Lancer. Whether you are a Lancer, Lancer Evolution or Lancer Sportback owner, there's no doubt you've already realized how well your car drives on the open road. What you may not know is all the cool features that help your car perform the way it does. In the pages ahead we're going to run through some quick tips about your vehicle and some fun facts about Mitsubishi.

Take a look through this book and get to know your new car. If you forget anything, just reach back into your glove box, grab this book and give yourself a refresher.

Another great place to stay up to date on the latest Mitsubishi news and special offers is at the Mitsubishi Owner's Site. Here you can keep track of your car's warranty and servicing needs and access a wide range of useful information exclusively for Mitsubishi owners. Just log on to [www.mitsubishicars.com/ownersonly](http://www.mitsubishicars.com/ownersonly).

On the owner's site you can also find information about Mitsubishi's Roadside Assistance for 5 years and unlimited miles. It's 24/7 coverage you can count on. For Roadside Assistance, call 1-888-648-7820.





## At Your Fingertips

### 1 Headlights Switch



Rotate the outer knob to the first position to turn on the tail, parking and dash lights. Rotate the outer knob to the second position to turn on the headlights. Pull the lever towards you to activate or flash the high beams.

### 2 Steering wheel audio remote control switch



The switch can be operated when the ignition switch is in either the **ON** or **ACC** position.

**TO INCREASE VOLUME:** While the button [1] is pressed, the volume will continue to increase.

**TO DECREASE VOLUME:** While the button [2] is pressed, the volume will continue to decrease.

Do not press multiple buttons at the same time when using the steering wheel audio remote control switch.

### 3 Sportronic steering wheel paddle shifters (if equipped)



Rapid gear shifting is possible simply by operating the sportronic steering wheel paddle shifters. Pull the right (+) sportronic steering wheel paddle shifter once to shift up one gear. Pull the left (-) sportronic steering wheel paddle shifter once to shift down one gear.

To default back to the automatic mode, pull and hold the right (+) paddle shifter for about three seconds.

### 4 Hands-Free Bluetooth® cellular phone interface system with voice recognition (if equipped) (Additional equipment may be required)



You should first connect (pair) your Bluetooth compatible cellular phone to the system. For instructions on pairing your phone, see page 9.

**TO PICK UP:** Press the button [2] when an incoming call is received to answer the phone. **TO HANG UP:** Press the button [3] during a call to end the current call. **MAKING A CALL BY USING THE TELEPHONE NUMBER:** 1. Press the button [1]. 2. Say DIAL. 3. After the voice guide says **NUMBER PLEASE**, say the telephone number. The system, using voice recognition, will then make the call.

### 5 Cruise control switch



**TO ACTIVATE:** Press the **ON OFF** switch. Press the **COAST SET** switch while driving at the desired speed.

**TO INCREASE THE SET SPEED:** Use one of the following options: 1. **ACC RES** switch: If you press and hold down the **ACC RES** switch, the speed will gradually increase. When you reach your desired speed, release the switch. Your cruising speed is now set.

2. **ACCELERATOR PEDAL:** Use the accelerator pedal to reach your desired speed. Press the **COAST SET** switch.

### 6 Front window wiper and washer switch



Make sure the ignition switch is in the **ON** or **ACC** position. Pull down the wiper lever to move the front window wiper.

To activate windshield washers, pull the lever toward you.

### Rear window wiper and washer switch (if equipped)

Make sure the ignition switch is in the **ON** or **ACC** position. Turn the knob to operate the switch.

For more details, see page 11.





## Audio System

NAVIGATION SYSTEM (IF EQUIPPED) - PRESSING THE PANEL KEYS OR TOUCHING THE SCREEN BUTTONS CAN PERFORM VARIOUS FUNCTIONS. OPERATE THE SCREEN BY TOUCHING LIGHTLY WITH A FINGERTIP. FOR AUDIO SYSTEM OPERATING INSTRUCTIONS IN LANCERS WITHOUT A NAVIGATION SYSTEM, PLEASE REFER TO YOUR OWNER'S MANUAL.


Panel Operation Buttons:

- 1 **MODE** - displays the AV mode selection screen
- 2 **AUDIO** - switches between the selected AV mode and Navigation screen
- 3 **VOL** - adjust the volume
- 4 **PWR** - turns ON and OFF the audio functions
- 5 **SET** - displays the settings screen
- 6 **OPEN** - opens and closes the monitor panel
- 7 **ENT** with Joystick - implements the selected item, scrolls the maps and implements item selection.
- 8 **MENU** - displays the Navigation menu screen
- 9 **SCALE** - changes the map scale
- 10 **NAVI** - displays the current location screen
- 11 **INFO** - displays the info screen

## Climate Control System


- 12 **Temperature Control Dial** - Turn the temperature control dial clockwise to make the air warmer. Turn it counterclockwise to make the air cooler. While the engine coolant temperature is low, the temperature of the air from the heater will be cool/cold until the engine warms up, even if you have selected warm air with the dial.
- 13 **Air Selection Switch** - Select the outside airflow position to keep the windshield and side windows clear and to quickly remove fog or frost from the windshield. To change the air selection, simply press the air selection switch. When the air conditioning turns on, the air selection is controlled automatically.
- 14 **Blower Speed Selection Dial** - When the ignition switch is in the **ON** position, turn the blower speed selection dial to set speed. When the blower speed selection dial is set to the **OFF** position, all fan-driven airflow will stop.
- 15 **Air Conditioning Switch** - Push the switch and the air conditioning compressor and indicator light will come on.
- 16 **Mode Selection Dial** - This dial controls the direction of airflow, not the amount of airflow. The amount of airflow is controlled by the blower selection dial. To change the direction of air flowing from the vents, turn the mode selection dial to the desired airflow position. If equipped with Auto Temperature Control, select **AUTO** for automatic air direction and blower fan speed. In **AUTO** mode, the system will adjust fan speed, mode selection and temperature automatically.
- 17 **Electric Rear Window Defogger Switch** - When the engine is running, the indicator light will come on when you push the electric rear window defogger switch helping clear away moisture or light frost.

### TIP: For Quick Defrosting

1. Set the mode selection dial to the  position.
2. Set blower dial to the maximum speed.
3. Set the temperature to the highest position.

### External Audio Input Function (if equipped)

You can listen to your portable audio equipment, through your vehicle's speakers by connecting the audio equipment to the RCA input connectors found in the upper front console area or the USB port in glove box area. To activate the RCA input mode, press and hold the CD button for more than 2 seconds.



## What does all this stuff do?

### 1) Digital Clock

Time is displayed when the ignition key is in the **ON** or **ACC** position. To set the time, press and hold the **CLOCK** [1] button until the display flashes. To change the hour, press the **H** [2] button. To change the minutes, press the **M** [3] button.

Once you have made your adjustments to the hours and minutes, then press the [1] button once more to lock in the time.



### 2) Multi-Information Meter (INFO) Button



The INFO button changes display information for warnings, odometer/tripmeter, service reminder, engine coolant temperature, average and momentary fuel consumption, driving range and average speed. It is also possible to change elements such as the language and units used on the multi-information display by pushing the multi-information meter (INFO) Button.

### 3) Rheostat Meter Illumination Button

The brightness of the instrument panel can be adjusted by pressing the button.



### 4) Power Outlet (if equipped)



#### 12 V POWER OUTLETS:

Located in front of the floor console. Accessories can be operated when the ignition switch is in either the **ON** or **ACC** position.




## 5) Sunroof (if equipped)

**TO OPEN:** Push the switch in the desired direction [1]

**TO CLOSE:** Push the switch in the desired direction [3]

**TO TILT UP:** Push the switch [2]

**TO TILT DOWN:** Push the switch in the desired direction [3]





## 6) Heated Seats (if equipped)

The heated seat controls are located at the floor console. The heated seats can be operated by pushing the switch when the ignition switch is in the **ON** position. The indicator light will illuminate while the heater is on.



## 7) Multi-Information Display (if equipped)

The multi-information display shows fuel remaining, outside temperature, selector lever (CVT) or gearshift lever (Twin Clutch SST) position, Twin Clutch control mode (Type 2), ACD control mode (Type 2), etc. It is also possible to change elements such as the language and units by using the multi-information meter (INFO) button. The display screen is different depending on whether the ignition switch is in the **OFF** or **ON** position.



## Navigation Tip Sheet (if equipped)

### To find a Point of Interest (POI):

- 1) Display the NAVI menu and touch Point of Interest
- 2) Input the State and City
- 3) Touch the Category button
- 4) Touch the desired POI category and follow the prompts to your desired Mitsubishi dealer, Gas Station, Parking area, Restaurant or Hotel

### If you already know the POI name, follow these steps:

- 1) Display the NAVI menu and touch Point of Interest
- 2) Input the State and City
- 3) Touch the Category button
- 4) Touch "All POI's"
- 5) Input the POI name
- 6) Touch "SET"

### Searching for a Location by Address/Intersection

- 1) Display the NAVI menu and touch "Address/Intersection"
- 2) Touch the "State" button
- 3) Input the State name
- 4) Touch the "City" button
- 5) Input the City name, touch "List" to select a city from the list
- 6) Touch the "Street" button
- 7) Input the Street name, touch "List" to select a street from the list.
- 8) Touch **House #** or **intersection**

Here are some tips on how to maximize your Navigation experience:

- For your safety, you are only able to enter information into the Navigation system when the vehicle is at a complete stop.
- To save you time, the Navigation system begins to populate possible destinations as you start typing. Choose your location when it appears on the screen.
- To help you reduce your time spent on the road your Navigation system displays traffic conditions on its screen using Real Time Traffic via RDS. This service is included at no charge for the life of your vehicle.
- Information included in your Navigation system is current at time of delivery. Check with your Mitsubishi dealer for future updates.

### Points of Interest (POI) Name

Used when the name of the desired POI is known.

#### 1 Display the Navi Menu and touch [POI Name]

**2 Input the "State" and "City"**  
Input the "State" and "City" with the same operations as in "From Address/Intersection" (4-3).



#### 3 Touch [All Categories]

The "POI Category" screen is displayed. The operation in step 5 can be performed even if a category is not selected.

#### 4 Touch the category of the desired POI



#### 5 Touch category type to select

#### 6 Touch [All POIs]

**7 Input the POI name**  
>>> "How to Enter Text" (3-14)



#### 8 Touch [Set]



### Searching for a Location by Address/Intersection

1. Display the Navi Menu and touch [Address / Intersection].



2. Touch the "State" button.

The name of the previously set state is displayed in the "State" button.



3. Input the state name.



4. Touch the "City" button.



5. Input the city name, touch [List] to select a city from the list.



6. Touch the "Street" button.

7. Input the street name, touch [List] to select a street from the list.



8. Touch House # or intersection.


## FUSE Tip Sheet

THE MITSUBISHI FUSE HANDS-FREE LINK SYSTEM™ IS AT THE CENTER OF YOUR IN CAR MULTI-MEDIA EXPERIENCE. IT COMBINES AN ALL-NEW VOICE-RECOGNITION SYSTEM AND BLUETOOTH® INTERFACE WITH USB PORT TO PROVIDE HANDS-FREE SAFETY AND ENTERTAINMENT WHILE DRIVING.



### USB Connect (if equipped):

Located in the glove box and can be used to run compatible personal audio players through your audio system. Please note that it may take some time for the system to engage as it processes information from your device.



### To pair\* your Bluetooth® enabled device:

- 1) Park your vehicle in a safe location.
- 2) Press the **SPEECH** button
- 3) Say "**Setup**"
- 4) Say "**Pairing Options**"
- 5) The voice guide will say "**Select one of the following: pair, edit, delete, or list.**" Say "**Pair**"

**Note:** If your vehicle is equipped with a navigation system, you can pair a device using the prompts on the HDD Navigation Screen.

**TIP:** For best results always speak loudly and at a normal pace.

### With FUSE\*, you can:

- Stream audio from a personal audio player
- Play music stored on an audio player by holding the CD button for two seconds which turns on the AUX mode (if equipped)
- Display song information (if supported by phone)
- Play music stored on most USB memory sticks/devices
- Use voice recognition to select music
- Charge USB compatible portable devices
- Automatically sync your telephone's phone book
- Recognize up to 7 phones
- Select songs by files or playlists

\*For a list of compatible Bluetooth® devices and/or more information on FUSE, please go to [www.mitsubishihandsfree.com](http://www.mitsubishihandsfree.com)  
If you are having difficulties operating your phone or connecting to the system, please call **Mitsubishi Handsfree at (888) 702-4100**




## Look at this...

- 1) **FAST-Key (if equipped)** - with FAST-Key, you do not need to use the key to open the door or start the car. You can leave the key in your pocket or purse.  
**LOCK** the doors and tailgate by pressing either the lock button on the key fob or pressing the black button to the right of the door handle or under the liftgate handle.  
**UNLOCK** the doors by pressing either the unlock button on the key fob or by pressing the black button to the right of the door handle. Listen for the beep and then open the door.  
**UNLOCK TAILGATE** by grasping the liftgate handle.  
***FAST-Key Tip:***  
 In the event the key fob loses power, remove the emergency key from the fob, turn it around and insert the head of the key into the slot in the fob and use it as a traditional key to unlock the doors and start the car. It is not a valet key. If you leave the FAST-Key in the vehicle and try to lock the doors, you will hear a series of beeps.
- 2) **Seatbelts** - in order to help with securing child safety seats and other cargo, Mitsubishi's seat belts have an Auto Locking Restraint (ALR) system. When the seat belt is pulled all the way out, it engages the ALR which restricts it from pulling out. To release the ALR, simply allow the seat belt to retract to its original position.
- 3) **Tire Pressure Monitoring System (TPMS)** - illuminates a warning light when your tire pressure is too low. **Please note that changes in the outside temperature may decrease tire pressure causing the TPMS light to turn on.** If the TPMS light stays illuminated, check your tire pressure. For more information on TPMS, refer to your Owner's Manual.
- 4) **Anti-Lock Braking System (ABS)** - each time your vehicle is started and driven a short distance, you will hear the sound of the ABS motor operating from the right front engine compartment. This is the normal sound the Anti-Lock Braking System makes when performing a self check.

**5) Windshield Wiper Lever** - the wiper control lever is located on the right hand side of the steering column.


- Push the wiper lever down:
  - o One position to INT for intermittent wiping  
Vehicles equipped with **Rain Sensing Wipers** will display AUTO rather than INT. When selected and moisture is detected on the windshield, the wipers will automatically make a swipe across the glass.
  - o Two positions for LOW wiping speed
  - o Three positions for HIGH speed
- Pull the lever towards you to dispense windshield washer fluid and wipers will automatically make several passes across the windshield
- Push the lever up to have the wipers complete a single pass



*Shown with rain sensing feature if equipped, otherwise AUTO = intermittent feature.*

**6) Rear Windshield Wiper Knob (if equipped)** - the wiper control knob is located on the right hand side of the wiper control lever. The Rear Window Wiper/Washer is activated using the outer knob of the windshield wiper controls.

- Twist the wiper knob clockwise:
  - o ONE position down to INT for intermittent wiping
  - o TWO positions down to ON for normal speed
  - o Push the end of the lever towards the steering column to spray the rear glass



**7) Brembo Brakes (Lancer Evolution only)** - the Brembo brakes supplied on the Lancer Evolution are designed for high performance stopping power. Brake noise in this type of performance vehicle is common. Make sure to stay on regularly scheduled maintenance to keep your brakes and your vehicle operating at their peak performance.

**8) Tires (Lancer Evolution only)** - the tires on the Lancer Evolution are performance tires designed to grip the road surface tightly to maximize performance. This may cause the tires to wear quicker than regular tires. Make sure to rotate and inspect your tires regularly according to your vehicle's schedule maintenance plan.



## Lancer Quick Tips and Fun Facts

- 1) Not sure which side of your Lancer the gas tank is on? Take a look at the gas gauge next to your speedometer - a triangle points to the side where your Lancer gas tank is.



- 2) Here's a little surprise. Tap the turn signal lever up or down quickly when changing lanes and the turn signal indicator light will automatically flash three times.
- 3) You can actually set your power doors lock function to unlock automatically when the shift lever is moved into the "P" position.



- 4) If equipped, the Navigation System includes Real-Time Traffic (RTT). This system shows traffic conditions on your navigation screen, yellow for slowing and red for stop and go traffic. Real-Time Traffic is free for the life of your Lancer if purchased with a Navigation System.

## Mitsubishi Fun Facts

- 1) The word “Mitsubishi” is Japanese for “three diamonds”.
- 2) Mitsubishi’s first motor car was produced in 1917 and included room for 7 passengers.
- 3) Mitsubishi was the first company in the world to design a Traction Control System, commonly referred to today as simply “TCS”.
- 4) A world record was set by Mitsubishi in 1999 when its electric car was the first to cover 1,000 kilometers (over 620 miles) in 24 hours.
- 5) 2007 saw Mitsubishi become the first company to score 7 straight Dakar Rally wins.
- 6) In 2009 Mitsubishi began producing and selling the i-MiEV electric vehicle.



- 7) Stay in touch with Mitsubishi on the following social media sites:



[facebook.com/Mitsubishi](https://facebook.com/Mitsubishi)



[YouTube.com/mitsubishicars](https://YouTube.com/mitsubishicars)



[twitter.com/mitsucars](https://twitter.com/mitsucars)



[flickr.com/mitsucars](https://flickr.com/mitsucars)

[www.mitsubishicars.com](http://www.mitsubishicars.com)

ACAD-P07900 (10/10)

