

---

# 21 CLUTCH

## CONTENTS

<b>GENERAL INFORMATION .....</b>	<b>21-2</b>	<b>CLUTCH PEDAL POSITION SWITCH</b>	
<b>SERVICE SPECIFICATIONS .....</b>	<b>21-2</b>	<b>CONTINUITY CHECK .....</b>	<b>21-3</b>
<b>LUBRICANTS .....</b>	<b>21-2</b>	<b>BLEEDING .....</b>	<b>21-3</b>
<b>ON-VEHICLE SERVICE .....</b>	<b>21-2</b>	<b>CLUTCH PEDAL .....</b>	<b>21-4</b>
CLUTCH PEDAL INSPECTION AND		<b>CLUTCH CONTROL .....</b>	<b>21-5</b>
ADJUSTMENT .....	21-2	INSTALLATION SERVICE POINT ...	21-8