

2 SINGLE PART INSTALLATION POSITION

CONTENTS

RELAY	2-2	EARTH	
ECU	2-5	SHORT WHEELBASE	
SENSOR	2-9	<L.H. drive vehicles>	2-24
SOLENOID VALVE	2-16	SHORT WHEELBASE	
DIODE	2-19	<R.H. drive vehicles>	2-24
INSPECTION CONNECTOR	2-20	LONG WHEELBASE	
FUSIBLE LINK AND FUSE	2-21	<L.H. drive vehicles>	2-25
EARTH CABLE	2-22	LONG WHEELBASE	
		<R.H. drive vehicles>	2-25