
55B HEATER, AIR CONDITIONER & VENTILATION <AUTOMATIC A/C>

CONTENTS

SERVICE SPECIFICATIONS	55B-2	PTC HEATER <4M41>	55B-29
LUBRICANTS	55B-2	BLOWER LINEAR CONTROLLER ...	55B-30
SPECIAL TOOLS	55B-3	AIR MIX DAMPER MOTOR AND AIR OUTLET CHANGE OVER DAMPER MOTOR	55B-31
TROUBLESHOOTING <FRONT A/C>	55B-3	AIR THERMO SENSOR AND HEATER WATER TEMPERATURE SENSOR ..	55B-33
TROUBLESHOOTING <REAR A/C>	55B-22	PHOTO SENSOR	55B-34
ON-VEHICLE SERVICE	55B-27	OUTSIDE AIR TEMPERATURE SENSOR	55B-34
PTC HEATER RELAY CONTINUITY CHECK <4M41>	55B-27	REAR A/C	55B-35
IDLE-UP OPERATION CHECK	55B-27	ELECTRIC MOTOR FOR THE AIR OUTLET CHANGE OVER DAMPER ..	55B-35
FRONT A/C	55B-29	COMPRESSOR	55B-35
AUTOMATIC A/C CONTROL PANEL ASSEMBLY (A/C-ECU)	55B-29		
HEAT SWITCH <4M41>	55B-29		
