

# WIRING HARNESS CONFIGURATION DIAGRAMS

## CONTENTS

### ENGINE COMPARTMENT

L.H. drive vehicles ..... 2

### ENGINE

4M41 <R.H. drive vehicles> ..... 4

MPI <L.H. drive vehicles> ..... 6

MPI <R.H. drive vehicles> ..... 8

GDI ..... 12

### DASH PANEL

L.H. drive vehicles ..... 14

R.H. drive vehicles ..... 20

### FLOOR CONSOLE

L.H. drive vehicles ..... 26

R.H. drive vehicles ..... 30

### FRONT FLOOR AND ROOF

Short wheelbase models  
<L.H. drive vehicles> ..... 34

Short wheelbase models  
<R.H. drive vehicles> ..... 36

Long wheelbase models  
<L.H. drive vehicles> ..... 38

Long wheelbase models  
<R.H. drive vehicles> ..... 40

REAR FLOOR AND UNDERFLOOR ..... 42