

# 17 ENGINE AND EMISSION CONTROL

## CONTENTS

### AUTO-CRUISE CONTROL SYSTEM ..... 2

GENERAL ..... 2

TROUBLESHOOTING <4M41> ..... 2

ON-VEHICLE SERVICE <4M41> ..... 3

Auto-cruise Control Component Check ..... 3

### EMISSION CONTROL SYSTEM <6G7-GDI> ..... 4

GENERAL ..... 4

VACUUM HOSE ..... 4

Vacuum Hose Piping Diagram ..... 4

### EMISSION CONTROL SYSTEM <6G7-MPI> ..... 5

GENERAL ..... 5

VACUUM HOSE ..... 5

Vacuum Hose Piping Diagram ..... 5

Vacuum Circuit Diagram ..... 6

### EVAPORATIVE EMISSION CONTROL SYSTEM ..... 7

System Diagram ..... 7

Component Location ..... 7

Purge Control System Check ..... 8

Purge Port Vacuum Check ..... 8

### EXHAUST GAS RECIRCULATION (EGR) SYSTEM ..... 9

System Diagram ..... 9

Component Location ..... 9

Exhaust Gas Recirculation (EGR) Control System Check ..... 10

EGR Port Vacuum Check ..... 10

### EMISSION CONTROL SYSTEM <4M41> ..... 11

GENERAL ..... 11

EGR VALVE ..... 11