

52B SRS

(SUPPLEMENTAL RESTRAINT SYSTEM)

CONTENTS

GENERAL	2	SRS MAINTENANCE	7
Outline of changes	2	AIR BAG MODULES	
SPECIAL TOOLS	2	AND CLOCK SPRING	8
TEST EQUIPMENT	2	AIR BAG MODULE	
TROUBLESHOOTING	3	DISPOSAL PROCEDURES	12
		Undeployed Air Bag Module	12

CAUTION

- Carefully read and observe the information in the SRS SERVICE PRECAUTIONS prior to any service.
- For information concerning troubleshooting or maintenance, always observe the procedures in the Troubleshooting (P.52B-3.) section.
- If any SRS components are removed or replaced in connection with any service procedures, be sure to follow the procedures in the INDIVIDUAL COMPONENT SERVICE section for the components involved.
- If you have any questions about the SRS, please contact your local distributor.