

WIRING HARNESS CONFIGURATION DIAGRAMS

CONTENTS

ENGINE COMPARTMENT

L.H. drive vehicles 2

ENGINE

4M41 <R.H. drive vehicles> 4

MPI <L.H. drive vehicles> 6

MPI <R.H. drive vehicles> 8

GDI 12

DASH PANEL

L.H. drive vehicles 14

R.H. drive vehicles 20

FLOOR CONSOLE

L.H. drive vehicles 26

R.H. drive vehicles 30

FRONT FLOOR AND ROOF

Short wheelbase models
<L.H. drive vehicles> 34

Short wheelbase models
<R.H. drive vehicles> 36

Long wheelbase models
<L.H. drive vehicles> 38

Long wheelbase models
<R.H. drive vehicles> 40

REAR FLOOR AND UNDERFLOOR 42