

17 ENGINE AND EMISSION CONTROL

CONTENTS

AUTO-CRUISE CONTROL SYSTEM 2

GENERAL 2

TROUBLESHOOTING <4M41> 2

ON-VEHICLE SERVICE <4M41> 3

Auto-cruise Control Component Check 3

EMISSION CONTROL SYSTEM <6G7-GDI> 4

GENERAL 4

VACUUM HOSE 4

Vacuum Hose Piping Diagram 4

EMISSION CONTROL SYSTEM <6G7-MPI> 5

GENERAL 5

VACUUM HOSE 5

Vacuum Hose Piping Diagram 5

Vacuum Circuit Diagram 6

EVAPORATIVE EMISSION CONTROL SYSTEM 7

System Diagram 7

Component Location 7

Purge Control System Check 8

Purge Port Vacuum Check 8

EXHAUST GAS RECIRCULATION (EGR) SYSTEM 9

System Diagram 9

Component Location 9

Exhaust Gas Recirculation (EGR) Control System Check 10

EGR Port Vacuum Check 10

EMISSION CONTROL SYSTEM <4M41> 11

GENERAL 11

EGR VALVE 11