
GROUP 52A

INTERIOR

CONTENTS

GENERAL INFORMATION	52A-2	FRONT SEAT	52A-6
		REAR SEAT	52A-9
INSTRUMENT PANEL AND FLOOR CONSOLE			
<L.H. DRIVE VEHICLES>	52A-3	SEAT BELT.....	52A-10
INSTRUMENT PANEL AND FLOOR CONSOLE		TRIMS	52A-12
<R.H. DRIVE VEHICLES>	52A-4	INTERIOR TRIMS	52A-12
SEAT	52A-6	DOOR TRIM	52A-13
		LUGGAGE ROOM.....	52A-14

GENERAL INFORMATION

M2520000100474

The interior has been designed to give the impression of sportiness and warmth by placing special emphasis on functionality, flexibility and safety.

FEATURES

Quality improvement

1. Two-tone interior
2. Full interior trim
3. Plated parts of analogue clock and air outlet
4. WHITE clock <Some models>
5. Genuine leather seats <Option>

Consideration for the optimum driving position

1. Adjustable seat belt anchor (front seat belt)
2. Plate spring (front seatback frame)
3. Height adjuster (driver's side)
4. Lumbar support (driver's side) <L.H. drive vehicles - GLS>

Safety improvement

1. Rear collision protection front seat
2. Upper tether anchor (rear seat) <Vehicles for South Africa, Argentina, Australia and New Zealand>
3. ISO-FIX child seat fixing bar (rear floor) <Vehicles for South Africa and Argentina>
4. ELR three-point seat belt (front)
5. ELR three-point seat belt/child seat fastening mechanism (ALR) switching seat belt (rear - L.H./R.H.)

6. ELR three-point seat belt/child seat fastening mechanism (ALR) switching seat belt (rear - centre) <Vehicles for South Africa, Argentina, Australia and New Zealand>
7. Two-point lap belt (rear - centre) <Except vehicles for South Africa, Argentina, Australia and New Zealand>
8. Front seat belt with force limiter mechanism
9. Shock absorbing/softening pillar trim
10. Use of nonflammable materials (instrument panel, floor console, trim, etc.)

Usability improvement

1. Arm rest (floor console) <L.H. drive vehicles>
2. Arm rest (driver's seat) <R.H. drive vehicles>
3. Seatback pocket (driver's side <Vehicles for South Africa and Argentina>, passenger's side)
4. Heated seat (front) <Option - Vehicles for Argentina>
5. Centre arm rest (rear seat)
6. Full flat seat (front/rear)
7. Luggage hooks (4 places)
8. Convenient hooks (2 places) (quarter trim lower)
9. Retractable tonneau cover <Except LS, GLX>

Convenient boxes


1. Large glove box
2. Console box
3. Cup holder (front/rear)
4. Luggage floor box

Measures for resource recycling

1. Material codes are stamped on resin parts.
2. Recyclable materials (PP) are used.

INSTRUMENT PANEL AND FLOOR CONSOLE <L.H. DRIVE VEHICLES>

M2520001000306




AC212441AD

The instrument panel and floor console have the following features:

- The instrument panel is two-toned.
- An analogue clock with a plated ring has been installed.
- A round easy-to-use air outlet with a simple mechanism has been equipped. The ring has been plated.
- A large glove box with a lamp has been installed.
- The instrument panel garnish with a soft high quality cover is used.
- A large box is provided under the centre panel.
- A storage box that makes use of the fuse box cover has been installed.
- The heater control panel is integrated with the centre panel to improve appearance. Its shape has been designed to support 2-DIN size audio equipment.
- The floor console has an arm rest with a cover, in which there is a box for storing small articles.
- There is a console box that can store 8 cases of CDs under the arm rest.
- An ashtray is installed on the front floor console.
- A coin tray is installed on the front floor console <Vehicles without heated seats>
- Cup holders that can hold various kinds of containers, such as mugs, paper cups and drink bottles, are provided.

INSTRUMENT PANEL AND FLOOR CONSOLE <R.H. DRIVE VEHICLES>

M2520001000317



AC212311 AD

The instrument panel and floor console have the following features:

- The instrument panel is two-toned.
- Integrating the passenger air bag door with the instrument panel improves the noise level and its appearance.
- Installing the accessory box <Vehicles for South Africa> or ashtray <Except vehicles for South Africa> to the user-friendly position improves marketability.
- Adopting the instrument panel shifting allows the generous interior space.

- An analogue clock with a plated ring has been installed. A WHITE clock is used <Some models>. The clock panel is overcoated with pearl white paint. When you see this clock from a certain direction, a pattern will emerge on the clock panel.
- A round easy-to-use air outlet with a simple mechanism has been equipped. The ring has been plated.
- Installing the large size glove box with a lighting and a rubber band improves usability.
- The instrument panel garnish with a soft high quality cover is used.
- A storage box that makes use of the fuse box cover has been installed.
- The slide lid type floor console is adopted.
- A cup holder and a tray are installed on the console front, and 16 CD cases can be stored on the main storage.
- A ashtray for rear passengers is installed on the floor console.






SEAT

FRONT SEAT

M2520004000587

<R.H. drive vehicles>

<L.H. drive vehicles>




- Genuine leather seats are offered as an option.
- The driver's seat has a height adjustment mechanism.
- The seatback frame uses a plate spring to improve fitting, holding and vibration resistance and enhance comfort.
- The driver's seat has a lumbar support adjustment mechanism to reduce fatigue during long drives <L.H. drive vehicles - GLS>.
- Adopting the four level angle-comfortable large-size armrest for the driver's seat improves ride comfort <R.H. drive vehicles>.
- The rear collision protection seat mechanism (installation of the seat back frame at the rear and head restraint position optimisation) improves safety in the event of a rear collision at low speeds.
- The front seat has a seatback pocket (driver's side <Vehicles for South Africa and Argentina>, passenger's side).
- The standard type headrests <20V, GLX (Except vehicles for South Africa) and LS> or the see-through type headrests <Except 20V, GLX (vehicles for South Africa) and LS> is installed.
- Adjusting to up and down optimises the head restraints position.
- Adjusting to back and forth <Vehicles for South Africa, Argentina> optimises the head restraints position.
- Heated seats are available for the driver's and passenger's seats. <Option - Vehicles for Argentina>

SPECIFICATIONS FOR HEATED SEAT

ITEM		SPECIFICATIONS
Energy consumption W	HIGH	60 ±6
	LOW	15 ±2
Thermostat °C	ON→OFF	40 ±4
	OFF→ON	30 ±5


HEATED SEAT SYSTEM CIRCUIT DIAGRAM





REAR SEAT

M2520007000434


<Vehicles for South Africa, Argentina, Australia and New Zealand>



<Except vehicles for South Africa, Argentina, Australia and New Zealand>



<Full flat seat>





AC212316AC


- Genuine leather seats are offered as an option.
- 6:4 rear split seats have a reclining mechanism <Except vehicles for Australia and New Zealand>.
- The folding arm rest has a cup holder.
- The standard type headrests <20V, GLX (Except vehicles for South Africa) and LS> or the see-through type headrests <Except 20V, GLX (vehicles for South Africa) and LS> is installed.
- Headrests have a vertical adjustment mechanism.
- The front and rear seats can be reclined together to form a fully flat floor.
- Child seat anchorage has been installed on the body side <Vehicles for South Africa and Argentina>. The seatback contains an upper tether anchor <Vehicles for South Africa, Argentina, Australia and New Zealand>.

SEAT BELT


M2520010000371



<Vehicles for South Africa, Argentina, Australia and New Zealand>



<Except vehicles for South Africa, Argentina, Australia and New Zealand>



<FRONT SEAT BELT>

- One-touch push button style adjustable seat belt anchors and seat-incorporated buckles ensure optimum belt fitting and placement.
- An ELR three-point seat belt is used.
- Seat belt retractor have a pre-tensioner and force limiter.
- The combination meter has a seat belt warning lamp to prompt the driver to wear the seat belt.

<REAR SEAT BELT>


- A ELR three-point/child seat fastening mechanism (ALR) seat belt is used improve safety (RH, LH).
- The ELR three-point/child seat fastening mechanism (ALR) seat belt <Vehicles for South Africa, Argentina, Australia and New Zealand> or the 2-point lap belt <Except vehicles for South Africa, Argentina, Australia and New Zealand> is installed for the centre seat belt.

SEAT BELT RETRACTOR WITH FORCE LIMITER

The driver's/front passenger's seat belt retractor has been equipped with a force limiter. The force limiter is a device which operates when a predetermined force is applied, and limits the force.

OPERATION

1. If a collision energy is transmitted to the seat belt, the ELR mechanism will operate to lock the seat belt.




2. Then, if the energy increases to a predetermined value, the torsion bar will be distorted. As the spindle rotates together with the torsion bar, the seat belt webbing is pulled out, reducing the impact against the occupants.

TRIMS

INTERIOR TRIMS

M2520012000106




AC200372AB

- The interior trim is a full trim.
- Shock-absorbing ribs have been used in the front pillar trim and center pillar trim upper to protect the heads of occupants in the event of a side collision, and a hard resin material has been adopted to improve safety.
- Material codes are shown on trim to facilitate recycling.


DOOR TRIM

M2520012300237

<Rear door trim>



<Front door trim>







AC212355AB

- A hard resin material is used for the door trim to protect passengers in the event of a side collision.
- The front door trim has a door pocket to store maps, etc.
- The speaker cover is separated from the door trim, to facilitate removal and installation of the door speaker.

LUGGAGE ROOM

M2520013000154



AC503381 AB

- The large luggage floor box is divided into three parts and notched so that long articles can be stored.
- The luggage floor board is also divided into three parts to suit the luggage floor box.
- Each of the centre luggage floor boxes and the centre luggage floor boards has a hook that can be attached to the top of the opening of the tail-gate to facilitate loading and unloading.
- A rear seat board forms a floor on the same level as the luggage floor when the rear seatback is tilted forward.
- In addition to providing luggage hooks (4 places) and convenient hooks (2 places) has been installed on the quarter trim.
- A retractable tonneau cover <Except GLX, LS> provides luggage room privacy. Three positions for installation have been provided according to the reclining angle of rear seats. It can be stored in the luggage floor box when it is not used.